


State of the battery power: the full battery status shows four grid. When only 25% of power is left (you will see the battery status is only one grid left), the brightness is reduced and the power voltage automatically reduce to 60%. When the power is in a blinking state, the brightness is significantly reduced and the power voltage automatically reduce to 10%. At this stage, please charge it immediately if you want to continue using it. If you do not charge it, it will be completely turned off after 20 minutes.

IP: IP20

Net weight: 2.2kg



YELLOWRIVER
MAKE YOUR STAGE TO BE MORE EXCELLENT

LED Battery Par Light

6Wx6PCS RGBWAUV 6IN1



User Manual

Please read these instructions carefully before use

Contents

Section 1. Getting Started

- ◇ Unpacking
- ◇ Safety Instruction

Section 2. Set Up

- ◇ Installation
- ◇ Controlling Board
- ◇ Machine Connection

Section 3. troubleshooting

- ◇ Troubleshooting

Section 4. Reference

- ◇ Control Menu
- ◇ DMX Protocol
- ◇ Dimmer Curve
- ◇ Specification

Specification

Voltage:

AC110V~240V

Frequency: 50/60Hz

Machine Power: 25W

Led Source: 6x6W RGBWA+UV 6IN1

Lithium Battery: Capacity 4.4AH , Recharge 3.5H for full charged , 4H for full color, single color for 15H

Maximum Ambient Temperature: 40°

Beam Angle: 25°

Strobe: 0~20Hz

Dimmer: 1 standard +4 kinds of dimmer methods

Channel: 13/8CH (switchable)

Built-In Program: 5 kinds strobe, 6 kinds auto run, 2 kinds sound active

Control Mode: DMX512/Manual/Master-Slave/Sound active/IR Remote Control

Cooling way: no fan, naturally aluminum cooling

Noise: silent

Power Mode: select half power under high temperature, half power, full power through menu.

Real Time Monitoring: The menu will display the battery percentage, the battery qty, the led source temperature.


Display: LED Display+Four Button

DMX: 3-pin XLR, male for input, female for output, with ONE USB wireless DMX connector.

Power Connect: PowerCON(Blue color for input +White color for output)

POWER INDICATOR: WITH ONE, TURN ON RED DURING CHARGING, TURN ON GREEN WHEN FULL CHARGE.

Dimmer Curves:



Ramp Effect	Menu	$T_{up}(ms)$	$T_{down}(ms)$
Standard Dimmer Curve	dr-0	0	0
Dimmer Curve 1	dr-1	100	320
Dimmer Curve 2	dr-2	120	450
Dimmer Curve 3	dr-3	180	550
Dimmer Curve 4	dr-4	210	600

Section 1. Getting Started

- ◇ Unpacking
- ◇ Safety Instruction

Unpacking

1pc Fixture

1pc User Manual

Thanks for choosing our LED battery par light. Carefully unpack the box and check the contents to ensure that all parts are present and in good conditions. If anything damaged in transit, notify the shipper immediately and keep the packing material for inspection. Again, please save the carton and all packing materials. If a fixture must be returned to manufacturer, it is important that the fixture be returned in the original manufacturer box and packing.

Safety Instruction



For your safe, please read this user manual carefully before turn on the fixture. This machine should be operated by qualified engineer!

- Please conserve this manual as operation guidance. If you sell this product to other user, please make sure that they also receive this user manual.
- Always make sure that you are connecting to the proper voltage and that the line voltage you are connecting to is not higher than that stated on the decal or rear panel of the fixture.
- If the fixture is intended to indoor use only. To prevent risk of fire or shock, do not expose fixture to rain or moisture. Make sure there are no flammable, explosive or corrosive materials surrounded in 10 meters while operating.
- The unit must be installed in a location with adequate ventilation, at least 5m away from adjacent surfaces. Be sure that no ventilation slots are blocked.
- Some fixture may carry high heat, do not aim at objective more than 2 minutes.
- Safe rope should be used to install machine. Bearing of safe rope should be more than 3 times of the machine weight. Complimentary signal cable transmits signals to 20 unit fixtures at most. Signal amplifier is a must to connect more fixtures. And a terminal should be added at the end of last fixtures' DMX sockets, 120 Ohm, 1/4W resistance need welding between Pin 2 and Pin3.
- Always disconnect from the power source before servicing or replacing fuse/lamp and be sure to replace with same fuse/lamp size and type. Cut off power before moving, repairing and cleaning the machine.
- To avoid electric shock, all fixtures must be connected to circuits with a suitable earth connection.
- Always secure fixture using a safety chain and carrying handles.
- Do not operate at ambient temperatures higher than 104°F (40°C).
- The power cable for this fixture is 1 m², please mind the safety requirements in actual using, if any wrong operation, our company takes no responsibility for any loss. Also, make sure the power cord is never crimped or damaged.

CH11	Auto	0-10: N/A; 11-40: 7 color fade; 41-70: R,G,B fade;
------	------	--

	R/Sound Active	71-100 : R,G,B color fade with temperature down ; 101-130: 7 color jump; 131-160: R,G,B jump; 161-190: Yellow,Cyan,Purple jump ; 191-220 : Sound active strobe; 221-255: Sound active jump.
CH12	Auto speed	0-255: Auto speed & sound active, from slow to fast.
CH13	Dimmer	0-20: Standard Dimmer Curve ; 21-40 Dimmer Curve 1; 41-60: Dimmer Curve2; 61-80: Dimmer Curve3; 81-100: Dimmer Curve4; 101-255 N/A

DMX512 Channel Chart: (8CH)

No.	Function	Description
CH1	Dimmer	0-255: R G B W A UV linear dimmer, from dark to bright.
CH2	R Dimmer	0-255: Red linear dimmer, from dark to bright.
CH3	G Dimmer	0-255: Green linear dimmer,from dark to bright.
CH4	B Dimmer	0-255: Blue linear dimmer,from dark to bright.
CH5	A Dimmer	0-255: Amber linear dimmer,from dark to bright.
CH6	P Dimmer	0-255: Purple linear dimmer,from dark to bright.
CH7	W Dimmer	0-255: White linear dimmer,from dark to bright.
CH8	Strobe	0-5: N/A 6-55: random strobe 56-105: pulsed strobe 106-155: equal strobe 156-205: thunder strobe 206-255: standard strobe

CH6	P Dimmer	0-255: Purple linear dimmer,from dark to bright.
CH7	W Dimmer	0-255: White linear dimmer,from dark to bright.
CH8	Strobe	0-5: N/A 6-55: random strobe 56-105: pulsed strobe 106-155: equal strobe 156-205: thunder strobe 206-255: standard strobe
CH9	Color Mix	0-1: N/A; 2-43: red from dark to bright; 44-85: red from bright to dark, green from dark to bright; 86-127: green from bright to dark, blue from dark to bright; 128-169: red from dark to bright, blue full color; 170-211: red full color, green from dark to bright, blue full color; 212-254: R,G,B full color, white from dark to bright; 255: R,G,B,W full color.
CH10	Color preset	0-5: N/A; 6-15: Red 16-25: Green 26-35: Blue 36-45: Lime Green 46-55: Yellow Green 56-65: Yellow 66-75: Congo Red 76-85: Light Orange 86-95: Wine Red 96-105: Pink 106-115: Pink Purple 116-125: Light Purple 126-135 : Pink Blue 136-145 : Light Blue 146-155: Sky Blue 156-165 : Light Cyan 166-175 : Cyan Green 176-185: Water Green 186-195 : Light Green 196-205 : Cold White 206-215: Light Cold White 216-225 : Pure White 226-235 : Purple White 236-245: Cream White 246-255: Warm White

- In case of failure or mis-function occurred, stop using immediately. Never try to repair the fixture by yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center. Buy the same spare parts/components from manufacturer directly.
- Avoid direct eye exposure to the light source while it is on.
- Do not power on and power off the fixture frequently
- When use DMX controller, please make sure that there is no interference sources(e.g. intercom, high frequency radio waves and radiation source)

Caution! There are no user serviceable parts inside the unit. Do not open the housing or attempt any repairs yourself. In the unlikely event your unit may require service, please contact your local distribution or after-sale service center.


Section 2. Set Up

- ✧ Installation
- ✧ Controlling Board
- ✧ Machine connection


Installation

- This machine should be mounted through the screw holes of truss. Safety rope is a must to fix fixture well. Make sure truss and safety rope have strong load capacity to bear more than 3 times of machine weight.
- This machine should be installed by qualified technician.

Controlling Board



Front display panel



1. LED Display Panel
2. Button

Menu	Switch menu function
UP	Scroll upwards
DOWN	Scroll downwards
ENTER	Confirm by pressing ENTER

2.1 Press MENU will display 16 kinds different menu. Press ENTER for confirmation. Press UP or DOWN to revise the DMX value. Press ENTER for save current value, Press MENU 5 seconds, will display the battery percentage, Press ENTER 5 seconds, will display the temperature.

10	F---	F000 to F255: Strobe speed, from slow to fast (strobe color is determined by the menu of r---, g---, b---, n---)
11	C---	C000 to C255: 7color fade, from slow to fast.
12	J---	J000 to J255: 7color jump, from slow to fast.
13	S---	S000 to S255: Sound active speed, from slow to fast.
14	IR---	IRon: infrared remote control On, IRof: infrared remote control off
15	dr--	dr-0: Standard Dimmer Curve; dr-1: Dimmer Curve1; dr-2: Dimmer Curve2; dr-3: Dimmer Curve3; dr-4: Dimmer Curve4;
16	TL--	TL-0: half power under high temperature, when the temperature of the led source hit 75°, the max power will reduce to be 50%; when the temperature decrease to be 65°, the max power will recover to be 100%. TL-1: half power; TL-2: Full power.

DMX protocol

DMX512 Channel Chart: (13CH)

No.	Function	Description
CH1	Dimmer	0-255: R G B W A UV linear dimmer, from dark to bright.
CH2	R Dimmer	0-255: Red linear dimmer, from dark to bright.
CH3	G Dimmer	0-255: Green linear dimmer, from dark to bright.
CH4	B Dimmer	0-255: Blue linear dimmer, from dark to bright.
CH5	A Dimmer	0-255: Amber linear dimmer, from dark to bright.

Section 4. Reference

- ◇ Control Menu
- ◇ DMX Protocol
- ◇ Dimmer Curve
- ◇ Specification

Control Menu

No.	Menu	Function (Press ENTER)
1	d13-	DMX 13 channel control(need connecting controller)
2	d.8--	DMX 8 channel control(need connecting controller)
3	r---	r000 to r255: Red from dark to bright
4	g---	g000 to g255: Green from dark to bright
5	b---	b000 to b255: Blue from dark to bright
6	A---	A000 to A255: Amber from dark to bright
7	P--	P000 to P255: Purple from dark to bright
8	n--	n000 to n255, White from dark to bright
9	pr--	pr01 to pr25: 25 kinds preset color pr0: Red, pr02: Green, pr03: Blue,pr04: Lime Green pr05: Yellow Green, pr06: Yellow pr07 : Congo Red pr08 : light orange, pr09 : Wine Red pr10: Pink pr11: Pink Purple pr12: Light Purple pr13: Pink Blue pr14:Light Blue pr15: Sky Blue pr16: Light Cyan pr17: Cyan Green pr18: Water Green pr19: Light Green pr20: Cold White pr21: Light Cold White pr22: Pure White pr23: Purple White pr24: Cream White pr25: Warm White

2.2 Infrared remote control operation: when operate this infrared remote control, should towards the receiving signal head(the valid distance is within 5 meter),Press the relative button (please pull off the parting slip of the battery before using)

2.2.1 OFF

UP	DOWN	OFF	FULL ON
RED	GREEN	BLUE	WHITE
Amber	Light Green A	Light Blue	Strobe
Brown Yellow	Cyan Green	Purple	Jump
almond	Water Green	Plum	Fade
Yellow	Cyan	Light Purple	Sound Active




2.2.1 OFF belongs to d---menu 。 Connect control signal or under master-slave,press OFF will return menu d,other button no function.

2..2.2 Under the function of color,UP&DOWN button for adjusting the brightness, under strobe, jump,fade function, UP&DOWN button for speed, under sound active, UP&DOWN button for sensitive,under OFF, UP&DOWN adjust the address code.

3. DMX Signal Input
3 PIN XRL port for DMX512 signal input (daisy chain);
4. DMX signal output
3 PINXRL Port for DMX512 signal output (daisy chain);
5. Power Input/output
AC power cable port input/output

Cable Connectors

Cables must have a male XLR connector on one end and a female XLR connector on the other end.



A word on termination: DMX is a resilient communication protocol,

however errors still occasionally occur. Termination reduces signal errors, and therefore best practices include use of a terminator in all circumstances. If you are experiencing problems with erratic fixture behavior, especially over long signal cable runs, a terminator may help improve performance.



To build your own DMX Terminator: Obtain a 120-ohm, 1/4-watt resistor, and wire it between pins 2&3 of the last fixture. They are also readily available from specialty retailers.

Master and slave: select one machine as master, press the menu to choose the function you want. Press other machines' address to be DMX state. Use signal cable to connect machines one by one. Then slave machines will run the same as master machine.

Use controller to control lot of machines: if all machines are set the same menu data, or different manual data, after use signal cable to connect to controller, all machines will be controlled by controller. (before connect to controller, all machines should be in the same channel mode 13CH or 8CH).

Section 3. Troubleshooting

Problem	Probable Cause(s)	Remedy
No response from fixture when power is applied	No power to fixture	Check power cables
	Primary fuse blown	Replace fuse
	Secondary fuse blown	Replace fuse
Fixture resets but does not respond correctly to controller(DMX mode operation)	Controller not connected	Connect controller
	Incorrect addressing of the fixtures	Check address setting on fixture and controller
	Bad data link connection	Inspect cables and correct poor connections and/or broken cables.
	Conflict between tracking and vector control	Eliminate scene cross-fade on controller
	Data link not terminated	Insert termination plug in output of last fixture
	Defective fixture or 2 devices transmitting on link	Bypass fixtures one at a time until normal operation is regained: unplug both connectors and connect them directly together
Colors cannot be mixed	Random color mixing is on	Turn off random color mixing
Fixture does not reset correctly	Electronic or mechanical failure	Contact service technician
No light, lamp cuts out intermittently, or burns out too quickly	Lamp missing or blown	Disconnect fixture and replace lamp
	Fixture or lamp is too hot	Allow fixture to cool. If problem persists, contact service technician