


UFOHJ High Bay Light Datasheet



Key Features

- ⇒ **Design Efficacy:** 160 lm/w
- ⇒ **LED Chip:** SMD2835
- ⇒ **SDCM:** <5
- ⇒ **Adjustable CCT & Power**
- ⇒ **Beam Angle:** 60° | 90° | 120°
- ⇒ **IP Rating:** IP65
- ⇒ **Controls:** Microwave & Daylight | Infrared | 0-10V dimming | Zigbee
- ⇒ **Installation:** Eye Bolt; Bracket
- ⇒ **Certifications:** CE, RoHS
- ⇒ **Warranty:** 5 years




Application


Factory workshops, logistics warehouses, gymnasiums, exhibition halls, large garages, aircraft hangars and maintenance workshops, station waiting areas, toll booths, and other large indoor lighting scenarios.

Photometry


60° PC lens




90° PC lens




120° PC lens



90° PC Reflector



90° AL Reflector



UFOHJ High Bay Light Datasheet

Product Data

Model No.	KML-UFOH100J	KML-UFOH150J	KML-UFOH200J	KML-UFOH240J	KML-UFOH300J
Power	100W	150W	200W	240W	300W
Adjustable Power	60W 80W 100W	80W 100W 150W	100W 150W 200W	150W 200W 240W	/
Lumen Output	16,000lm	24,000lm	32,000lm	38,400lm	48,000lm
Luminous Efficacy	160 lm/w (adjustable CCT: 130 lm/w to 150 lm/w)				
CCT	3000K 4000K 5000K 5700K 6500K; Adjustable CCT: 3000K 4350K 5700K				
CRI	Ra≥70 (Ra≥80 optional)				
Input Voltage	100-277 VAC				
Housing Color	Black				
Housing Material	Aluminum, PC				
Power Factor	PF≥0.95				
Efficiency In	≥93%				
Energy Efficiency Class	D				
Operating Temperature	-30°C to +50°C				
Operating Humidity	10% to 90% RH				
Design Lifespan	100,000 hours				
Warranty	5 years				

Note: 1. The above parameters are all obtained at +25°C and there are errors within the allowable range of relevant standards.
2. This specification book is for reference only. We retains the right to optimize and modify without pre -notification!

UFOHJ High Bay Light Datasheet

Mounting & Accessories

	Eye Bolt <i>Model No.: M10 Steel; Silver</i>
	Safety Rope <i>Model No.: UFO-SR Stainless Steel; Silver</i>
	Bracket <i>Model No.: UFOHJ-ZJ Steel; Black</i>
	Remote Control <i>Model No.: HD06R Plastic; white</i>
	Microwave & Daylight Sensor <i>Model No.: HD07VR-MH-1 PC; Milky white</i>
	Infrared Sensor <i>Model No.: HD07VR-PH-1 PC; Milky white</i>
	AL Reflector <i>Model No.: UFOHJ-DZ; Beam Angle: 90°; Applicable Power: 100W/150W/200W/240W/300W Aluminum; Silver</i>
	PC Reflector <i>Model No.: 310A(100W); 410C(150W); 500A(200W/240W/300W) PC; Transparent & Stripe</i>
	PC Reflector Cover <i>Model No.: 310CBL(310A)/410CBL(410C)/500CBL(500A) PC; Transparent & Stripe</i>

UFOHJ High Bay Light Datasheet

Packaging (No Bracket)

Model No.	PCS/CTN	N.W	G.W	Volumetric Weight	Carton Size and Volume	20GP(28m ³)	40HC/HQ(68m ³)
KML-UFOH100J	1	1.9 kg	2.5 kg	2.5 kg	L285xW285xH155 mm ≈ 0.013 m ³	2,153 CTNS	5,230 CTNS
KML-UFOH150J	1	2.4 kg	3.1 kg	3.7 kg	L338xW338xH160 mm ≈ 0.018 m ³	1,555 CTNS	3,777 CTNS
KML-UFOH200J	1	3.2 kg	4.0 kg	5.0 kg	L390xW390xH165 mm ≈ 0.025 m ³	1,120 CTNS	2,720 CTNS
KML-UFOH240J	1	3.6 kg	4.7 kg	7.0 kg	L445xW445xH175 mm ≈ 0.035 m ³	800 CTNS	1,942 CTNS
KML-UFOH300J	1	3.9 kg	5.0 kg	7.0 kg	L445xW445xH175 mm ≈ 0.035 m ³	800 CTNS	1,942 CTNS

Remarks: The weight of the above products is for reference only, and the weight of different configuration products will be different.

Packaging (Includes Bracket)

Model No.	PCS/CTN	N.W	G.W	Volumetric Weight	Carton Size and Volume	20GP(28m ³)	40HC/HQ(68m ³)
KML-UFOH100J	1	2.1 kg	2.7 kg	2.6 kg	L285xW285xH160 mm ≈ 0.013 m ³	2,153 CTNS	5,230 CTNS
KML-UFOH150J	1	2.6 kg	3.3 kg	4.0 kg	L338xW338xH170 mm ≈ 0.019 m ³	1,473 CTNS	3,578 CTNS
KML-UFOH200J	1	3.4 kg	4.2 kg	5.2 kg	L390xW390xH170 mm ≈ 0.026 m ³	1,076 CTNS	2,615 CTNS
KML-UFOH240J	1	3.8 kg	4.9 kg	8.0 kg	L445xW445xH190 mm ≈ 0.038 m ³	736 CTNS	1,789 CTNS
KML-UFOH300J	1	4.1 kg	5.2 kg	8.0 kg	L445xW445xH190 mm ≈ 0.038 m ³	736 CTNS	1,789 CTNS

Remarks: The weight of the above products is for reference only, and the weight of different configuration products will be different.


Packaging (PC reflector and cover)

Model No.	PCS/CTN	N.W	G.W	Volumetric Weight	Carton Size and Volume	20GP(28m ³)	40HC/HQ(68m ³)
310A	24	0.48 kg/pcs	13.0 kg	20.0 kg	L620xW330xH490 ≈ 0.100 m ³	280 CTNS	680 CTNS
410C	13	0.88 kg/pcs	13.0 kg	22.2 kg	L430xW430xH600 ≈ 0.111 m ³	252 CTNS	612 CTNS
500A	13	1.54 kg/pcs	22.0 kg	32.5 kg	L500xW500xH650 ≈ 0.163 m ³	171 CTNS	417 CTNS
310CBL	100	0.16 kg/pcs	18.0 kg	11.0 kg	L500xW330xH330 ≈ 0.054 m ³	518 CTNS	1,259 CTNS
410CBL	25	0.34 kg/pcs	10.0 kg	5.6 kg	L430xW430xH150 ≈ 0.028 m ³	1,000 CTNS	2,428 CTNS
500CBL	25	0.54 kg/pcs	15.0 kg	7.5 kg	L500xW500xH150 ≈ 0.038 m ³	736 CTNS	1,789 CTNS


Remarks: The weight of the above products is for reference only, and the weight of different configuration products will be different.

UFOHJ High Bay Light Datasheet


Dimension (unit: mm/inch)




KML-UFOH100J



KML-UFOH150J




KML-UFOH200J




KML-UFOH240J | KML-UFOH300J


And AL Reflector Dimension (unit: mm)




UFOH100J-DZ



UFOH150J-DZ




UFOH200J-DZ




UFOH240J-DZ/UFOH300J-DZ


PC Reflector Dimension (unit: mm)




310A




410C




500A



310CBL



410CBL



500CBL

UFOHJ High Bay Light Datasheet


DIP Switch Details



Features


- ⇒ When the DIP switch is in the BHD state, the power and color temperature can be adjusted.
- ⇒ When the DIP switch is in the BHB state, the power can be adjusted.

BHD: DIP power adjustment and DIP color temperature



A: 200W, B:150W, C:100W
CW: 5700K, NW: 4350K, WW: 3000K

BHB: DIP power adjustment



A: 200W, B:150W, C:100W
CW: none, NW: none, WW: none


UFOHJ High Bay Light Datasheet

Microwave Sensor Details



Features

- ⇒ Patent plug-in design structure, sensor part can be easily mount after sale.
- ⇒ IP65 water-proof, long detection range when install 15m height.
- ⇒ Easy to wire inside sensor by screw terminals.






Plug & Play Motion Sensor.



Regular Model.

UFOHJ High Bay Light Datasheet

Microwave Sensor Details



Technical Specification

Items	Specifications
HF System	5.8GHz±75MHz
Detection radius(1m to 8m)	20%/50%/75%/100%
Mounting height	<15 meters
Time setting	2S/1min/5min/10min/15min/20min/30min/60min
Light-control	24hours/10lux/30lux/50lux

UFOHJ High Bay Light Datasheet


Microwave Sensor Details

Corridor Function


This function inside the motion sensor to achieve tri-level control, for some areas which require a light change notice before Switch-off. The sensor offers 3 levels of light: 100% → dimmed light (natural light is insufficient) → off; and 2 periods of selectable waiting time: motion hold-time and stand-by period; selectable daylight threshold and freedom of detection area.



With sufficient natural light, the light does not switch on when presence is detected.



With insufficient natural light, the sensor switches on the light automatically when presence is detected.




After hold-time, the light dims to stand-by level if the surrounding natural light is below the daylight threshold.



Light switches off automatically after the stand-by period elapses.

Daylight Sensor Function

Open the daylight sensor by push  when remote control is in setting condition.



The light switches on at 100% when there is movement detected.




The light dims to stand-by level after the hold-time.




The light remains in dimming level at night.


Settings on this demonstration:
Hold-time: 30min
Setpoint on: 50lux
Setpoint off: 300lux
Stand-by Dim: 10%
Stand-by period: $+\infty$
(When the smart photocell sensor open, the stand-by time is only $+\infty$)




①  ③ goes in cycle at night ...
100% on when movement detected, and dims to 10% in long absence.



When the natural light level exceeds setpoint off to light will turn off even if when the space is occupied.



The light automatically turns on at 10% when natural light is insufficient (no motion).



UFOHJ High Bay Light Datasheet

Infrared Sensor Details



⚠ Warning

- ⇒ Warm up time is 15 seconds. After the sensor connects input power first time, the light will keep on 15 seconds, then go to dimming to work normally.
- ⇒ Factory Default Setting: 100% sensitivity, hold on time 5minutes, daylight sensor is sunshine, dimming level 30%, dimming time 60 minutes.
- ⇒ Any setting changed by remote control, the led light that sensor connect will on/off as confirm.



Technical Specification

Items	Specifications
Remote range	<15 meters, indoor, no backlight
Detection radius(1m to 8m)	20%/50%/75%/100%
Mounting height	<12 meters
Time setting	10S/1min/5min/10min/15min/20min/30min/60min
Light-control	24hours/10lux/30lux/50lux

UFOHJ High Bay Light Datasheet


Infrared Sensor Details

Corridor Function


This function inside the motion sensor to achieve tri-level control, for some areas which require a light change notice before Switch-off. The sensor offers 3 levels of light: 100% → dimmed light (natural light is insufficient) → off; and 2 periods of selectable waiting time: motion hold-time and stand-by period; selectable daylight threshold and freedom of detection area.



With sufficient natural light, the light does not switch on when presence is detected.



With insufficient natural light, the sensor switches on the light automatically when presence is detected.




After hold-time, the light dims to stand-by level if the surrounding natural light is below the daylight threshold.




Light switches off automatically after the stand-by period elapses.

Daylight Sensor Function


Open the daylight sensor by push  when remote control is in setting condition.



The light switches on at 100% when there is movement detected.




The light dims to stand-by level after the hold-time.




The light remains in dimming level at night.


Settings on this demonstration:
Hold-time: 30min
Setpoint on: 50lux
Setpoint off: 300lux
Stand-by Dim: 10%
Stand-by period: $+\infty$
(When the smart photocell sensor open, the stand-by time is only $+\infty$)




①  ③ goes in cycle at night ...
100% on when movement detected, and dims to 10% in long absence.



When the natural light level exceeds setpoint off to light will turn off even if when the space is occupied.



The light automatically turns on at 10% when natural light is insufficient (no motion).



UFOHJ High Bay Light Datasheet

Remote Control Description



Product Data

Power supply: 2xAAA 1.5V battery, Alkaline preferred

Carrying case: UFOHJ-RC100 in carrying case

Communication: 940 nm Infrared Tx & Rx

Upload range: up to 15m (50 ft.)

Op. temperature: 0°C to +50°C (32°F to 122°F)

Dimensions: 123x70x20.3mm(4.84"x2.76"x0.8")

⚠ Warning

Remove the batteries from compartment if the remote will not be used in 30 days.



Overview

The "RC100" Wireless IR Configuration Tool is a handheld tool for remote configuration of IR-enabled fixture integrated sensors.

The tool enables device to modify via pushbutton without ladders or tools, and stores up to four sensor parameter modes to speed configuration of multiple sensors.

The "RC100" uses bidirectional IR communication to send and receive sensor settings at mounting height up to 50 feet. The device can display previously established sensor parameters, copy parameters and send new parameters or store parameter profiles. For projects where identical settings may be desired across a large number of areas or spaces, this capability provides a streamlined method of configuration. Settings can be copied throughout a site, or in different sites.

UFOHJ High Bay Light Datasheet

Remote Control Description

KEY	FUNCTION	KEY	FUNCTION
	Press the on/off button, the light goes to permanent on or permanent off mode, the sensor is locked ,MUST Press "AUTO " to quit from this mode.		Press "Auto"button, the sensor starts to work automatically and all parameters remains the same as the latest status in auto mode.
	Display current parameters		The button "Test" is for testing purpose sensitivity only. the sensor goes to test mode (hold time is only 2s) automatically after commissioning, meanwhile the stand-by period and daylight sensor are disabled. Press "AUTO " to quit from this mode.
	upload the selected parameters to sensors		
	Enter in the setting condition and navigate to UP and Down		
	Navigate to Right and Left		
	Confirm selected parameters and saving		When the light level exceeds this setting, the lights will turn off even when the space is occupied. Once the light level exceeds this setting, the sensor will wait and monitor for 1 mins in order to confirm the light level increase is not temporary before forcing the lights to go off. When light level goes below the settings, the light will turn on even without motion detection after 1min. This feature is disabled by default. if want to open this setting, just press  ,choose daylight sensor setpoint on/off .
	Default settings:      	   	Four modes with existing parameters which are available to be updated and saved in Modes
BRIGHTNESS	Adjust the light brightness during hold time.		
SENSITIVITY	Adjust sensor sensitivity		Select  /10LUX/30LUX/50LUX/  threshold for sensor to turn light fixture ON. Select  , current surrounding lux value as daylight lux threshold, select  , the built-in daylight sensor stops working, and all motions detected could turn the light fixture on,no matter how bright the natural light is.
HOLD TIME	The time of light fixture remains at programmed 70%/80%100% level after motion is not detected		
STAND-BY TIME	Select stand-by period at 1min/30min / 60min/+∞ ; Note: "+∞" means bi-level dimming control, fixture never switches off.		Select the stand-by dimming level at 0%/ 10%/30%/ 50%; Note: "0%" means on/off control;

NOTE:

The "RC100" is a universal remote programmer with ALL available settings and parameters for remote sensors. Some settings and parameters may not be available on specific type of sensor under certain control mode. Please refer to the installation instruction of the sensor for the available settings and control options.

COMMAND BUTTONS

THE COMMAND BUTTONS provides a quick selection of the following operations by pressing respective buttons.

- To turn on/off light manually, press "ON/OFF" button, the sensor is locked ,MUST Press "AUTO " to quit from this mode.
- To test sensitivity only. Press "TEST" button, the sensor goes to test mode (hold time is only 2s) automatically after commissioning, meanwhile the stand-by period and daylight sensor are disabled. Press "AUTO " to quit from this mode.

UFOHJ High Bay Light Datasheet

Remote Control Description

- To send the current parameters to sensor ,aim to the sensor ,and press SEND button.

NOTE: any command button is pressed to sensor, the light will on one time and off as confirm.

SETTING

The **SETTING** Content contains all available settings and parameters for "RC-100" remote sensors. It allows you to change the available control, parameters, and operation of the sensor from factory default or current parameters.

NOTE:the setting works only in Auto mode.

Change multiple settings of sensor(s)

- 1.Press DISP button(if you push ON/OFF button before you push DISP button, the sensor is locked, so please push "AUTO" button to unlock the sensor ,and then push DISP button), the controller leds will show the latest parameters.
- 2.press  or  enter in the setting condition, navigate to the desired setting by pressing   to select the new parameters.
- 3.press ok to confirm all setting and saving.
- 4.aim at the target sensor and press SEND to upload the new parameter. light will be one time and off , as confirm.

NOTE: 1.If you press DISP button, the remote control leds will show the latest parameters which were sent.
2.If you want to learn current surrounding lux value as daylight lux threshold, please choose  when you select daylight sensor lux threshold.

Change multiple settings of sensor(s)(with daylight sensor on/off setpoint)

- 1.Press "DISP" , the remote control leds will show the latest parameters.
- 2.Press     to Select the new parameter.
- 3.press  ,daylight sensor off setpoint led in remote control will flash ,select daylight sensor setpoint for turn light off, and select daylight sensor setpoint for turn the light on .
- 4.press ok to confirm all setting and saving.
- 5.aim at the target sensor and press "SEND" to upload the new parameter.light will be one time and off as confirm.

NOTE:  is disabled by default.

- 1.Open or close daylight sensor on/off setpoint, it only works when remote control in the setting condition, you just push  , daylight sensor setpoint on/off setpoint will be close or open.
- 2-1.when daylight sensor works, the setpoint on lux must be 10lux,30lux,50lux,not  , the light turn on when natural light lower than 10lux,30lux,50lux even without motion detection after 1min.
- 2-2:when daylight sensor works, the setpoint off lux must be 100lux,300lux,500lux,not  , the light turn off when natural light exceeds than 100lux,300lux,500lux even with motion detection after 1min.
- 2-3: when daylight sensor works,the stand-by time is only  .
- 3. is normal for outdoor using,not for indoor .

UFOHJ High Bay Light Datasheet

Remote Control Description

About RESET and MODE(1,2,3,4)

The "RC-100" comes with four MODES which are not default. You may make desired parameters and save as a new MODE(1,2,3,4) to configure the installed sensors.

RESET:

MODE	BRIGHTNESS	SENSITIVITY	HOLD TIME	DAYLIGHT SENSOR	STAND-BY DIM	STAND-BY TIME
MODE1	100%	100%	5m		30%	+∞
MODE 2	70%	20%	10s		0%	+∞
MODE 3	70%	20%	10s		0%	+∞
MODE 4	70%	20%	10s		0%	+∞

Make a new Mode:

1. press / / / / button, the remote control leds show existing parameters.
2. press to select the new parameters.
3. if want to open/close daylight sensor lux setpoint on/off , press ,select right lux setpoint.
4. Press "OK" to confirm all parameters and saving in the mode.

NOTE: if do not know existing parameters in / / / / , repeat Step 1.

UPLOAD

The upload function allows you to configure the sensor with all parameters in one operation. You may select CURRENT SETTING parameters or the MODE for uploading. Current setting parameters or the MODE are displayed in "RC-100" Remote control .

Upload the current parameters to sensor(s), and duplicate the sensor parameters from one to another

1. Press Display button OR press / / / / , all parameters are displayed in "RC100" Remote control.

Note: check if all parameters are correct , if not, change them.

2. Aim at the sensor and press "SEND" button , the light will be one time on and off , as confirm.

Note: if other sensors need same parameters, just aim at the sensor and press "SEND" button.