


# Hybrid Solar Inverter

SSA-HL6K-P1EU\_DO

## User Manual



Please read this manual before use and follow its guidance.  
Keep this manual for future reference.

V1.0

## Table Of Contents

<b>1.Information on this Manual .....</b>	<b>1</b>
1.1 Validity .....	1
1.2 Scope .....	1
1.3 Target Group .....	1
1.4 Label Description .....	1
1.5 Safety Instructions .....	2
<b>2.Introduction .....</b>	<b>3</b>
2.1 Features .....	4
2.2 Product Overview .....	4
<b>3.Installation .....</b>	<b>6</b>
3.1 Unpacking and Inspection .....	6
3.2 Mounting Unit .....	7
3.3 AC Input / Output Connection .....	9
3.4 PV Connection .....	12
3.5 Battery Connection .....	14
3.6 Final Assembly .....	17
3.7 Smart Communication Stick Connection (Optional) .....	17
<b>4.Operation .....</b>	<b>17</b>
4.1 Power ON/OFF .....	17
4.2 Operation and Display Panel .....	18
4.3 Display Information .....	32
<b>5.Fault Reference Code .....</b>	<b>34</b>
<b>6.Alarm Reference Code .....</b>	<b>37</b>
<b>7.Battery Equalization .....</b>	<b>39</b>
<b>8.Specifications .....</b>	<b>41</b>
8.1 Line Specifications .....	41
8.2 Battery Specifications .....	42
8.3 Charger Specifications .....	42
8.4 Output Specifications .....	43
8.5 Switch Time Specifications .....	43
8.6 Efficiency Specifications .....	44
<b>9.Trouble Shooting .....</b>	<b>44</b>

# 1. Information on this Manual

## 1.1 Validity

This manual is valid for the following devices:

- 6000W inverter

## 1.2 Scope

This manual describes the assembly, installation, operation and troubleshooting of this unit.

Please read this manual carefully before installations and operations.

## 1.3 Target Group

This document is intended for qualified persons and end users. Tasks that do not require any particular qualification can also be performed by end users. Qualified persons must have the following skills:

- Knowledge of how an inverter works and is operated
- Training in how to deal with the dangers and risks associated with installing and using electrical devices and installations
- Training in the installation and commissioning of electrical devices and installations
- Knowledge of the applicable standards and directives
- Knowledge of the compliance with this document and all safety information

## 1.4 Label Description

In order to ensure the user's personal safety when using this product, the inverter and manual provides relevant identification information and uses appropriate symbols to alert the user, who should carefully read the following list of symbols used in this manual.

### Labels on Inverter

	<b>CAUTION</b> Do not disconnect under load!
	<b>Danger: High Voltage!</b> <b>Danger: Electrical Hazard!</b>
	Start maintaining the INVERTER at least 5 minutes after the INVERTER disconnected from all external power supplies.
	Read instructions carefully before performing any operation on the INVERTER.
	Grounding: The system must be firmly grounded for operator safety.

## Labels in the documentation

 <b>WARNING!</b>	A high level of potential danger, which, if not avoided, could result in death or serious injury to personnel.
 <b>CAUTION!</b>	A moderate or low level of potential danger, which, if not avoided, could result in moderate or minor injuries to personnel. In some bad situation, it could result in death or serious injury to personnel.

## 1.5 Safety Instructions

### **WARNING!**


This chapter contains important safety and operating instructions.

Read and keep this manual for future reference.

01. Please be clear which kind of battery system you want, lithium battery system or lead-acid battery system, if you choose the wrong system, energy storage system can't work normally.
02. Before using the unit, read all instructions and cautionary marking on the unit, the batteries and all appropriate sections of this manual. The company has the right not to quality assurance, if not according to the instructions of this manual for installation and cause equipment damage.
03. All the operation and connection please professional electrical or mechanical engineer.
04. All the electrical installation must comply with the local electrical safety standards.
05. When install PV modules in the daytime, installer should cover the PV modules by opaque materials, otherwise it will be dangerous as high terminal voltage of modules in the sunshine.
06. CAUTION - To reduce risk of injury, charge only deep-cycle lead-acid type rechargeable batteries and lithium batteries. Other types of batteries may burst, causing personal injury and damage.
07. Do not disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
08. To reduce risk of electric shock, disconnect all wiring before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
09. NEVER charge a frozen battery.
10. For optimum operation of this inverter, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter.

11. Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
12. Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to INSTALLATION section of this manual for the details.
13. GROUNDING INSTRUCTIONS -This inverter should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
14. NEVER cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
15. Make sure the inverter is completely assembled, before the operation.

## 2. Introduction



**Hybrid Solar Energy Storage System**

This is a multifunctional solar inverter, integrated with a MPPT solar charge controller, a high frequency pure sine wave inverter and a UPS function module in one machine, which is perfect for off grid backup power and self-consumption applications. This inverter can work with or without batteries.


The whole system also need other devices to achieve complete running such as PV modules, generator, or utility grid. Please consult with your system integrator for other possible system architectures depending on your requirements. The WiFi module is a plug-and-play monitoring device to be installed on the inverter. With this device, users can monitor the

status of the PV system from the mobile phone or from the website anytime anywhere.

## 2.1 Features


- Rated power 6000W, power factor 1
- MPPT ranges 60V~450V, 500Voc
- High frequency inverter with small size and light weight
- Pure sine wave AC output
- Solar and utility grid can power loads at the same time
- With CAN/RS485 for BMS communication
- With the ability to work without battery
- WIFI remote monitoring(optional)
- Dual ACOutput
- Feed-in to grid

## 2.2 Product Overview



Here are the front and side dimensions of the product, which can be used as a reference when installing the product.

Below is the bottom interface identification diagram of the product, which can help us when we wiring it.



1. Power On/Off Switch
2. AC Input
3. AC Output 1
4. AC Output 2
5. PV Input

6. Battery Input
7. BMS Communication Port
8. COM Port
9. PE
10. AC Input Breaker

## 3. Installation

### 3.1 Unpacking and Inspection

#### 3.1.1 Open-box Inspection

Products have been strictly tested before leaving the factory. Please sign for them after inspection. If the product is damaged, please contact the local distributor. Please open the box to check whether the outer packaging is intact or damaged, whether the internal equipment is damaged.


#### 3.1.2 Installation Tools

Installation Tools	Multi-meter	Protective gloves	Insulated anti-smashing shoes
			
	Safety glasses	ESD wrist strap	Hammer drill
			
	Electric screwdriver	Cross screwdriver	Rubber mallet
			
	Spirit level	Wire cutter/ stripper	Terminal crimping tool
			

#### 3.1.3 Packing List

No.	Item	Quantity	Description	Remarks
1	Inverter	1		
2	User manual	1	English	
3	Expansion Screw	3	M6*80	

### 3.2 Mounting Unit



Consider the following points before selecting where to install:

- Do not mount the inverter on flammable construction materials.
- Mount on a solid surface.
- Install this inverter at eye level in order to allow the LCD display to be read at all times.
- The ambient temperature should be between -10°C and 60°C to ensure optimal operation.
- The recommended installation position is to be adhered to the wall vertically.
- Be sure to keep other objects and surfaces as shown in the diagram above to guarantee sufficient heat dissipation and to have enough space for removing wires.



#### WARNING!


Inverter is suitable for mounting on concrete or other non-combustible surface only.

Follow the installation steps:


1. Use φ8 drilling bit drill holes on the mounting surface. The distance between 2 holes is 200mm. Then insert the expansion screw(M6). The expansion screw\*2 are in packing.
2. Pick up the inverter vertically and align the screws' holes at the top of the inverter with the expansion screw tube already installed on the wall. Fix the inverter on the

mounting surface by screws.

Below is a drawing of the installation dimensions of the product, which can help when using expansion screws to secure the inverter to the wall.



Before connecting all wiring, please take on bottom cover by removing four screws as shown below:



### 3.3 AC Input / Output Connection



#### CAUTION!

Before connecting to AC input power source, please install a separate AC breaker between inverter and AC input power source. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input. The recommended spec of AC breaker is 40A for 6000W inverter.



#### CAUTION!

There are three terminal blocks with "AC IN", "AC OUT 1" "AC OUT 2" markings. Please do NOT mis-connect input and output connectors.



#### CAUTION!

Be sure to connect AC cables with correct polarity. If L and N wires are connected reversely, it may cause utility short-circuited when these inverters are worked in parallel operation.



#### WARNING!

All wiring must be performed by a qualified personnel.



#### WARNING!

It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.

#### Suggestion for AC input wires

Model	Gauge	Cable (mm <sup>2</sup> )
6000W Inverter	10 AWG	5.26



#### WARNING!

It's very important for system safety and efficient operation to use appropriate cable for AC dual output connection. To reduce risk of injury, please use the proper recommended cable size as below.

### Suggestion for AC output wires

Model	Gauge	Cable (mm <sup>2</sup> )
6000W Inverter	12 AWG	4




#### WARNING!

Make sure AC power is disconnected before attempting to connect AC power to the unit.

All operations during the electrical connection process, as well as the specifications of cables and components used, must comply with local laws and regulations. The cable color mentioned below is for typical reference.

Please follow below steps to implement AC input / output connection:

1. Before making AC connection, be sure to open AC circuit breaker first.
2. Remove insulation sleeve 12mm from the head of cables, shorten the conductor part to 10 mm. Insert the cable into the tubular terminal. Then use terminal crimping tool make the terminal and cable connected tightly.




3. Insert AC input/output cables according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE protective cable first.

PE → Protecting Earth (yellow-green)

L → LINE (brown or black)

N → Neutral (blue)



4. Make sure the cables are securely connected.



#### CAUTION!

Appliances such as air conditioner are required at least 2~3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check with manufacturer of air conditioner that if it's equipped with time-delay function before installation. Otherwise, this off grid solar inverter will trig overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air condition.

### 3.4 PV Connection

**CAUTION!**

Before connecting to PV modules, please install a separate DC circuit breaker between inverter and PV modules.

**WARNING!**

Do not ground the positive or negative terminals of the PV modules, as this can severely damage the inverter.

**WARNING!**

Exposure to sunlight can generate lethal high voltages in photovoltaic strings, so strictly adhere to the safety precautions listed in the photovoltaic string and related documents.

**WARNING!**

Make sure to connect the PV terminals to the corresponding ports on the inverter, as reversing the polarity can damage the inverter.

**WARNING!**

All wiring must be performed by a qualified personnel.

**WARNING!**

It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below. The cable color mentioned below is for typical reference.

Model	Gauge	Cable (mm <sup>2</sup> )
6000W Inverter	10 AWG	5.26

#### PV Module Selection:

When selecting proper PV modules, please be sure to consider below parameters:

1. Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
2. Open circuit Voltage (Voc) of PV modules should be higher than start-up voltage.

INVERTER MODEL	6000W Inverter
Max. PV Array Open Circuit Voltage	500Vdc
Start-up Voltage	60Vdc
PV Array MPPT Voltage Range	60Vdc~450Vdc




### WARNING!

Please do not connect any DC switches or AC/DC circuit breakers before completing the electrical connections.

Please follow below steps to implement PV module connection:

1. Before making PV connection, be sure to open DC circuit breaker first.
2. Remove insulation sleeve 12mm from the head of cables, shorten the conductor part to 10 mm. Insert the cable into the tubular terminal. Then use terminal crimping tool make the terminal and cable connected tightly.




3. Use multi-meter check to ensure the polarities are correct.

4. Insert PV cables according to polarities indicated on terminal block and tighten the terminal screws.

+ → PV + (red)

- → PV - (black)



5. Make sure the cables are securely connected.

## 3.5 Battery Connection

### 3.5.1 Lead-acid Battery Connection

User can choose proper capacity lead acid battery with a nominal voltage at 48V. Also, you need to choose battery type as 'AGM or FLD(flooded)'



#### CAUTION!

For safety operation and regulation compliance, it's requested to install a separate DC over-current protector or disconnect device between battery and inverter. It may not be requested to have a disconnect device in some applications, however, it's still requested to have over-current protection installed. The recommended size of protector or disconnect is 150A.



#### WARNING!

All wiring must be performed by a qualified person.



#### WARNING!

It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable and terminal size as below. The cable color mentioned below is for typical reference.



#### WARNING!

Make sure AC power is disconnected before attempting to connect AC power to the unit.

All operations during the electrical connection process, as well as the specifications of cables and components used, must comply with local laws and regulations. The cable color mentioned below is for typical reference.

Recommended battery cable and terminal size:

Model	Gauge	Cable (mm <sup>2</sup> )
6000W Inverter	2 AWG	25


Note: For lead acid battery, the recommended charge current is 0.3C (C<sub>s</sub>battery capacity)

Please follow below steps to implement battery connection:

1. Unscrew the pre-fixed screws on battery poles. Prepare 2 DT terminals (It should fit for AWG2 cables).
2. Remove insulation sleeve 12mm from the head of cables, shorten the conductor part to 10 mm. Insert the cable into the DT terminal. Then use terminal crimping tool make the terminal and cable connected tightly.



3. Pass the battery cable through the battery installation hole on bottom shell, and tighten the terminal screws. Make sure polarity at both the battery and the inverter/charge is correctly connected and DT terminals are tightly screwed to the battery terminals.



4. Connect all battery packs as units requires. It's suggested to connect at least 200Ah capacity battery.



**WARNING! Shock Hazard**

Installation must be performed with care due to high battery voltage in series.



**CAUTION!**

Do not place anything between the flat part of the inverter terminal and the DT terminal. Otherwise, overheating may occur.



**CAUTION!**

Do not apply anti-oxidant substance on the terminals before terminals are connected tightly.



**CAUTION!**

Before making the final DC connection or closing DC breaker/disconnector, be sure positive (+) must be connected to positive (+) and negative (-) must be connected to negative (-).


### 3.5.2 Lithium Battery Connection

If choosing lithium battery for inverter, Please check the compatibility of the protocol first.

There're two connectors on the lithium battery, RJ45 port of BMS and power cable.

Please follow below steps to implement lithium battery connection:

1. Follow section 3.6.1 to implement the power cable connection.
2. Connect RJ45 terminal of battery communication cable to BMS communication port of inverter. The communication protocol should be RS485 or CAN.



3. Insert the other end of RJ45 (battery communication cable) to battery communication port of lithium battery.

Note: If choosing lithium battery, make sure to connect the BMS communication cable between the battery and the inverter. You need to choose battery type as "lithium battery" during inverter setting.

Lithium battery communication and setting:

In order to communicate with battery BMS, you should set the battery type to "Llib" in Section 4.2.2 Program 17.

Make sure the lithium battery BMS port connects to the inverter is Pin to Pin, the inverter BMS port pin assignment shown as below:

Pin number	BMS port
1	RS485B
2	RS485A
3	-
4	CANH
5	CANL
6	-
7	-
8	-

Communicating with battery BMS in parallel system


If need to use communicate with BMS in a parallel system, you should make sure to connect the BMS communication cable between the battery and one inverter of the parallel system.

### 3.6 Final Assembly

After connecting all wiring, please put bottom cover back by screwing four screws mentioned in Section 3.2.

### 3.7 Smart Communication Stick Connection (Optional)


The smart communication stick(WIFI) is used to connect to the cloud platform. Please insert the stick into COM port directly.



## 4. Operation


### 4.1 Power ON/OFF

Once the unit has been properly installed and the batteries are connected well, simply press ON/OFF switch (located on the button of the case) to turn on the unit.




## 4.2 Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes four indicators, four function keys and a LCD display, indicating the operating status and input/output power information.



Three Indicators


LED Indicator			Messages
 AC	Green	Solid On	The mains power is normal and enters the mains power operation.
		Flashing	The mains power is normal, but it has not entered mains power operation.
 INV	Yellow	Solid On	Output is powered by battery or PV in battery
		Flashing	Other states.
 CHG	Yellow	Solid On	Battery is fully charged.
		Flashing	Battery is charging.
 FAULT	Red	Solid On	Fault occurs in the inverter.
		Flashing	Warning condition occurs in the inverter.



Function Buttons

Button	Description
ESC	To exit setting mode
UP	To go to previous selection
DOWN	To go to next selection
ENTER	To confirm the selection in setting mode or enter setting mode

#### 4.2.1 LCD Display Icons



Icon	Description
<b>① Battery Information</b>	
	Battery icon
	Battery type
	There charging period. The CC icon is illuminated during the constant current charging stage, the CV icon is illuminated during the constant voltage charging stage, and the FLOAT icon is illuminated during the float charging stage.
	Indicate battery voltage
	During the constant voltage charging stage, the CV voltage is displayed and the CV icon is illuminated. During the float charging stage, the float voltage is displayed and the FLOAT icon is illuminated. During the discharge stage, the end discharge voltage is displayed and the END icon is illuminated.
	Indicate battery charging/discharging current.
<b>② AC Input Information</b>	
	AC input icon.
<b>UPSAPP</b>	UPS or APP input mode When set to GEN input, it displays as APP.

	AC input voltage and frequency.
<b>③ PV Input Information</b>	
	PV input icon.
	Indicate PV power, PV voltage, PV current, etc.
<b>④ Output Information</b>	
	Indicate output voltage (V), apparent power (VA or KVA), output active power (W or KW) alternately, switching every five seconds. Indicate output frequency.
<b>⑤ Battery Capacity</b>	
	Indicate battery level by 25%, 50%, 75% and 100% in battery mode and charging status in line mode.
<b>⑥ Load Information</b>	
	Indicate power of load, power percentage of load.
	Indicate overload happened.
<b>⑦ AC OUTPUT2 Information</b>	
<b>AC OUTPUT2</b>	Second AC output icon.
	Indicate AC output 2 voltage, power and frequency.
<b>⑧ Parameter Query, Function Setting or Fault/Alarm Information</b>	
	Indicate system information; Function setting; Indicate Fault/Alarm.
<b>⑨ Other Information</b>	
	Mute
	WIFI connected
	If PV+Grid, the left and right icon light at same time; if only PV, the right icon is only light.
	If PV first, the left and right at same time.



For Lead-acid battery, detailed description of battery icon as following:


In battery mode, battery icon will present Battery Capacity		
Load Percentage	Battery Cell Voltage	Display
Load >50%	< 11.146V	
	11.146V ~ 11.685V	
	11.685V ~ 12.224V	
	> 12.224V	
50%> Load > 20%	< 11.795V	
	11.795V ~ 12.334V	
	12.334 ~ 12.873V	
	> 12.873V	
Load < 20%	< 12.112V	
	12.112V ~ 12.659V	
	12.659V ~ 13.198V	
	> 13.198V	

#### 4.2.2 LCD Setting

After pressing and holding ENTER button for 2 seconds, the unit will enter setting mode. Press "UP" or "DOWN" button to select setting programs. Then press "ENTER" button to confirm the selection or ESC button to exit.

Program	Description	Setting Option
01	Output voltage	 230V (default) Adjustable/settable value: 208V, 220V, 230V, 240V
02	Output frequency	 50Hz(default) Adjustable/settable frequency: 50Hz, 60Hz
03	Solar first	 Solar energy provides power to the loads as first priority. If solar energy is sufficient, battery will be charged with solar energy. If solar energy is not sufficient to power all connected loads, Grid will supply power to the loads at the same time. The extra power will charge the battery. If solar energy and grid are not sufficient, battery will supply power to the loads at same time. If solar, grid and battery power is not sufficient to power loads, inverter will go to standby and charge battery.
03	Grid first (default)	 Grid provides power to the loads as first priority. Solar power will charge the battery. If solar is not sufficient to charge battery, grid will charge the battery at the same time. If grid is not sufficient to power all connected loads, solar energy will supply power to the loads at the same time. If solar energy and grid are not sufficient, battery will supply power to the loads at same time. If solar, grid and battery power is not sufficient to power loads, inverter will go to standby and charge battery.


		PBG priority	
03	Output source priority	<p>Solar energy provides power to the loads as first priority. If solar energy is sufficient, battery will be charged with solar energy.</p> <p>If solar energy is not sufficient to power all connected loads, battery will supply power to the loads at the same time.</p> <p>If solar energy and battery are not sufficient, grid will supply power to the loads at same time.</p> <p>If solar, grid and battery power is not sufficient to power loads, inverter will go to standby and charge battery.</p>	
	MKS	Generator provides power to loads as first priority. When generator, PV, battery all exist, the work mode is as PBG. When generator and battery exist (no PV), the work mode is as GPB. When generator and PV exist (no battery), the work mode is as GPB.	
04	Input mode	<p>APP: Appliance (default)</p> <p>Applied to household appliances. Typical switching time is 10ms.</p>	
	UPS	Applied to computer and other devices. Typical switching time is 10ms.	
	GEN	Applied to connect generator from AC IN port. Typically switching time is 20ms.	
05	Charger source priority	<p>PNG: PV and Grid (default)</p> <p>OPV: Only PV</p> <p>PVF: PV first</p>	  



		<p>There are three options for charging priority. The default is PNG (PV and grid) .PV and Grid are charged at the same time. The second is OPV (Only PV) .Only PV charge. The third is PVF (PV first) .If both grid and PV are available,PV charge. If only PV is available,PV charge. If only grid is available, grid charge.</p>
06	Grid charging current	 <p>60A(default) Available options: 2/10/20/30/40/50/60/70/80/90/100/110/120A</p>
07	Maximum charging current	 <p>Set total charging current for solar and grid chargers. The default is 100A. Available options: 2/10/20/30/40/50/60/70/80/90/100/110/120A</p>
08	Menu Default	 <p>During setting: Set to ON. If the current page is not on the first page and no operation with 1 minute, the system will return to display the first page. Set to OFF. If the current page is not on the first page and no operation with 1 minute, the system will stay on the current page.</p>
09	Auto restart when overload occurs	<p>The default is ON.</p> 
10	Auto restart when over temperature occurs	<p>The default is ON.</p> 
11	Main input cut warning	 <p>Enable/Disable Grid or PV loss alarm. The default setting is ON. If the grid input detected lost, the buzzer will sound for 5 seconds. when set to OFF, after the grid input is lost, the buzzer will not sound.</p>
		


12	Energy-saving mode	The default setting is OFF. When set to ON, in battery mode, if the load is lower than 25W, the system will stop output for a period then resume. If the load is still lower than 25W, the system will do the loop stop then resume. If the load is higher than 35W, the system will resume continuous normal output.
13	Overload transfer to bypass	 The default setting is OFF. When set to ON, in the case of PBG (PV priority) or MKS (generator priority) mode, if there is an overload, the system will immediately transfer to bypass mode (grid power output, also known as bypass mode).
14	Silent mode setting	 Enable/disable buzzer sound. The default setting is OFF. When set to ON, in any situation such as alarms or faults, the buzzer will not sound. This setting can be applied to all modes.
15	Battery return to mains voltage point	 When the battery is set to the CUS (Customer Setting Type) mode. The adjustable range is [40V, 50V]. The default is 47.6V, and it can be adjusted within a range of [40,50V]. When the battery is set to the AGM (Lead Acid Battery Type) or FLD (Flooded Battery Type) mode. The default setting is 46V, and it can be adjusted within a range of [44, 52V]. When the battery is set to the LIB (Lithium Battery Type) mode. The default is 47.6V, and it can be adjusted within a range of [40, 50V]. When the battery is set to FEL(Lithium iron battery),the default value is 49.6V.It can be adjusted within a range of [40,50V].
16	Switching back to battery mode voltage points	 When the battery is set to CUS (Customer Set Type) mode, The default setting is 54.4V, The voltage range is [46, 58V]. When the battery is set to AGM (Absorbent Glass Mat) or FLD (Flooded) mode,The default is 52V. It can be adjusted within a range of [48,58V]. When the battery is set to LIB (Lithium Battery) mode, The default setting is 54.4V. It can be adjusted within a range of [46, 58V]. When the battery is set to FEL(Lithium iron battery),the default value is 53.2V.It can be adjusted within a range of [46,58V].

		AGM(default)	
17	Battery type	Flooded	
		Lithium(Ternary Lithium Battery)	
		FEL(Lithium iron)	
		User-Defined	
18	Battery low voltage point		
		Battery low voltage alarm setting. When the battery type is set to LIB, the default setting is 47.6V. The adjustable range for the voltage is [41.2, 50V]. Initial settings for CUS are the same as for LIB.  When the battery type is set to FEL, the default setting is 48V. The adjustable range for the voltage is [41.2, 50V].  It is not possible to set the battery definition mode to AGM or FLD mode. The initial default setting is 44V.	
19	Battery shutdown voltage point		
		The battery low voltage shutdown point setting function cannot be adjusted when the battery is defined as AGM or FLD mode. The default setting is 42V.  When the battery type is set to LIB, the battery shutdown point can be modified. The default setting is 46V, and the adjustable range is [40, 48V]. Initial settings for CUS are the same as for LIB. When the battery type is set to FEL, the battery shutdown point can be modified. The default setting is 42V, and the adjustable range is [40, 48V].	
			

20	Constant voltage mode voltage point setting	<p>When the battery is defined in AGM or FLD mode, the voltage set point cannot be configured. The default setting for AGM mode is 56.4V, for FLD mode is 58V.</p> <p>When the battery type is CUS, It can be set within the range of [48, 60V] for the constant voltage charging set point. It is important to note that the constant voltage set point voltage needs to be higher than the float charge set point voltage.</p> <p>When the battery type is set to LIB, the default constant voltage charging set point is 56.4V, and it can be adjusted within the range of [48,60V]. When the battery type is set to FEL, the default constant voltage charging set point is 55.2V, and it can be adjusted within the range of [48,60V].</p> <p>It is important to ensure that the constant voltage set point voltage is higher than the float charge set point voltage.</p>
21	Floating charge mode voltage point setting	<p>When battery is defined as AGM or FLD mode, the voltage set point cannot be configured. The default setting for AGM/FLD mode is 54V. When the battery type is CUS, It can be set within the range of [50,58V] for the floating charging voltage set point. The default is 55.2V.</p> <p>If the battery type is LIB, the default setting for the floating charging point is 55.2V. The setting range is [50,58V]. If the battery type is FEL, the default setting for the floating charging point is 54.4V. The setting range is [50,58V]. It is important to note that the constant voltage point voltage should always be set higher than the floating charge point voltage.</p>
22	Grid low voltage point setting	<p>22</p> <hr/> <p>LL4154</p> <p>If output mode is APP/GEN, Grid low voltage point can be set within a range of 90V to 154V. The default setting is 154V.</p> <p>If output mode is UPS, Grid low voltage point can be set within a range of 170V to 200V. The default setting is 185V.</p>
23	Grid high voltage point setting	<p>23</p> <hr/> <p>LH4264</p> <p>If output mode is APP/GEN, Grid high voltage point can be set within a range of 264V to 280V. The default setting is 264V.</p> <p>If output mode is UPS, Grid high voltage point is set as 264V.</p>

24	Automatic turn off backlight	 <p>The default setting is ON. If ON, the backlight will turn off after 1minutes of no button operation</p>
25	Inverter soft start setting	 <p>Default setting is OFF. If it set to ON, the inverter output gradually increases from 0 to the target voltage value. If OFF, the inverter output directly increases from 0 to the target voltage value. Setting Condition: It can be set in single-machine operation mode.</p>
26	Reset factory setting	 <p>Restore all settings to factory default values. Before the setting, this interface is displayed as OFF. When set to ON, the system will restore to default settings. After the setting is completed, this interface will display OFF again. The setting can be applied immediately in mains and standby modes, but cannot be set in battery mode.</p>
29	Battery Disconnection Alarm	 <p>Enable/Disable battery disconnection alarm. Default setting is OFF. When set to OFF, there will be no battery disconnection, low battery voltage, or battery under voltage alarms when the battery is disconnected.</p>
31	Equalization Voltage Point Setting	 <p>The default setting for FEL battery type is 56V,setting range is [48,60V].The default setting for AGM/FLD/LIB/CUS battery type is 58.4V,with a configurable range of [48,60V]</p>
		

32	Equalization Charging Time Setting	<p>The function can be set as 'OFF' or active.</p> <p>During the equalization stage, the controller will charge the battery as much as possible until the battery voltage rises to the battery equalization voltage. Then, it will adopt constant voltage regulation to maintain the battery voltage. The battery will remain in the equalization stage until the set battery equalization time is reached. The default setting is OFF, with a configurable range of [5, 900], and an increment of 5 minutes for each setting.</p>
33	Equalization Delay Time Setting	<p>During the equalization stage, if the battery equalization time expires and the battery voltage has not risen to the battery equalization voltage point, the charging controller will extend the battery equalization time until the battery voltage reaches the battery equalization voltage.</p> <p>When the battery equalization delay setting is completed and the battery voltage is still below the battery equalization voltage, the charging controller will stop equalization and return to the floating stage.</p> <p>The default setting is 120 minutes, with a configurable range of [5, 900], and an increment of 5 minutes for each setting.</p>
34	Equalization Interval Time Setting	<p>33</p>  <p>When the battery connection is detected during the float phase with the equalization mode turned on, the controller will start to enter the equalization phase when the set equalization interval (cell equalization period) is reached. The default setting is 30 days, the settable range is [1,90], and the increment of each setting is 1 day.</p>
35	Enable Equalization Immediately	<p>34</p>  <p>35</p>  <p>The default setting is OFF, the function is not turned on; when it is set to ON, in the float charging stage when the equalization mode is turned on and the battery connection is detected. The balance charging is activated immediately, and the controller will start to enter the equalization stage.</p>
		<p>36</p> 


36	Grid-tie inverter function	<p>Set whether the inverter is grid fed or not. If the value is INT' the inverter can feed to grid according to different output source priority. In PGB mode when battery level is sufficient, as long as grid is connected, PV can feed energy to grid as much as possible and surplus energy of PV charges the battery.</p> <p>In PGB mode when battery level is NOT sufficient, PV charges battery as much as possible and surplus energy of PV feeds to grid. In GPB mode and PBG mode, as long as grid is connected, PV charges battery as much as possible and surplus energy of PV feeds to grid. In MKS mode, inverter does not feed to grid.</p>
37	Max Grid Tie Power	 <p>Setting the output power value to grid. The default is 6.0kW. The setting range is [0,6.0]kW. Every setting step is 0.5kW.</p>
38	Battery dual output low Voltage Shutdown point	 <p>When enabled, the secondary output of the inverter is enabled by default. In battery mode, when the battery voltage drops below the set point, the secondary output is turned off. When the battery voltage rises above the set value plus 1V per additional battery cell, the secondary output is turned on.</p> <p>The default setting of 48V, with a configurable range of [44,60]V. When the set point is higher than the constant voltage charging (CV) point-1V per cell, the recovery voltage is set to the constant voltage charging point.</p>
39	Battery dual output duration	 <p>When enabled, the secondary output of the inverter is enabled by default. In battery mode, when the battery discharge time reaches the set point, the secondary output is turned off.</p> <p>Default setting is OFF, the function is not enabled. The configurable range is [5,900] in minutes.</p> <p>When set to FUL, the secondary output has unlimited output time.</p>
40	Dual output battery mode cut-off SOC	 <p>When enabled, the secondary output of the inverter is enabled by default. In battery mode, when the battery SOC is lower than the set value, the secondary output is turned off. After the battery voltage is 5% higher than set value, the secondary output will turn on.</p> <p>Default value is 20. The setting range is [5,90] and OFF.</p>

		 <del>b5UOFF</del>
44	BMS Communication Function	<p>The default setting is OFF, and the function is not enabled. When set to a specific BMS protocol, the inverter communicates with the lithium battery BMS through the centralized control board and obtains battery information.</p> <p>If the communication is abnormal after the function is enabled, alarm 56 is generated, and the inverter does not determine the running logic based on the BMS information.</p> <p>CVT:CVTE protocol(485)</p> <p>PYL:PYLON protocol(485 and CAN)</p> <p>GRO:GROWATT protocol(485 and CAN)</p> <p>VOL:VOLTRONIC protocol(485)</p> <p>RO:China Tower protocol(485)</p> <p>PAR:PACE RTU protocol(485)</p>
45	BMS ID	 <del>b1 AEO</del>
46	Low SOC Shutdown	 <del>b5UOFF</del> <p>Set the inverter to shut down when the State of Charge (SOC) of the battery is low.</p> <p>Default setting is 20, with a configurable range of [5, 50]. When the lithium battery SOC reaches the set value in battery mode, the inverter shuts down and generates alarm 68. The alarm 68 is cleared when the SOC returns to the set value + 5%. In standby mode, the inverter can switch to battery mode only when the SOC reaches the set value + 10%. If it does not reach this threshold, alarm 69 is generated. Once the function is enabled, alarm 69 is triggered when the lithium battery SOC reaches the set value + 5%, and it is cleared when it returns to the set value + 10%.</p> <p>It can be set to OFF, in which case the inverter no longer performs shutdown, startup, or alarm operations based on the SOC condition.</p> <p>Once the function is enabled, if a communication abnormality occurs, the inverter no longer operates based on the SOC information and clears the related alarms.</p>

		 47 SE6OFF
47	High SOC to Battery	<p>Set the SOC value for the inverter to switch to battery mode. Default setting is 9.5, with a configurable range of [10, 100]. In PBG priority mode, when the lithium battery SOC reaches the set value in normal grid mode, the inverter switches to battery mode. Once enabled, the inverter will only switch to battery mode when the SOC is above the set point and the battery voltage is higher than the voltage point to switch back to battery mode.</p> <p>It can be set to OFF, in which case the inverter no longer switches from grid mode to battery mode based on the SOC condition. Once the function is enabled, if a communication abnormality occurs, the inverter no longer operates based on the SOC information and clears the related alarms.</p>
		 48 SE5OFF
48	Low SOC to Grid	<p>Set the SOC value for the inverter to switch to grid mode. The default setting is 50, with a configurable range of [10, 90].</p> <p>In PBG priority mode, when the lithium battery SOC reaches the set value in battery mode, the inverter switches to grid mode. Once enabled, the inverter will switch to grid mode when the SOC is below the set point or the battery voltage is lower than the voltage point to switch back to grid mode.</p> <p>It can be set to OFF, in which case the inverter no longer switches from battery mode to grid mode based on the SOC condition. Once the function is enabled, if a communication abnormality occurs, the inverter no longer operates based on the SOC information and clears the related alarms.</p> <p>When this setting is higher than the STB point, STB and STG will no longer take effect after the next activation.</p>
		 61 ndE OFF
61	Battery Max. Discharge Current	<p>The default setting is OFF. The inverter will not limit the battery discharging current when setting to OFF.</p> <p>When set to a numerical value, it indicates the limitation current value. The setting range is [10, 140A] with a setting step of 5A. If the discharging current is over the limitation, alarm 60 will occur. If the continuous over-current time reaches 5 seconds, fault 14 will occur and inverter goes into fault mode.</p>

#### 4.3 Display Information

The LCD display information will be switched in turns by pressing "UP" or "DOWN" key. If there is no operation for a long time, the daily PV power generation will be displayed at the bottom of the screen. For example the following screen displays 2.5kWh.



The selectable information is switched as below.

LCD display	Information
P1 — 25 kWh	Display the daily power generation from solar.
P2 — 893 kWh	Display total power generation from solar.
P3 — 52.9 10.7	Display lithium battery voltage and current. Display ERR when BMS communication fails. If BMS function is disabled, the page will not display.
P4 — 24.6 51	Display lithium battery temperature and SOC. Display ERR when BMS communication fails. If BMS function is disabled, the page will not display.
P5 — 10050.8	Display lithium battery rated capacity and remaining capacity. Display ERR when BMS communication fails. If BMS function is disabled, the page will not display.
P6 — 58.444.8	Display lithium battery maximum charging voltage and minimum discharging voltage. Display ERR when BMS communication fails. If BMS function is disabled, the page will not display.
P7 — 88.0 100	Display lithium battery maximum charging current and maximum discharging current. Display ERR when BMS communication fails. If BMS function is disabled, the page will not display.
P8 — NUL NUL	Display lithium battery alarm and fault information. Display ERR when BMS communication fails. If BMS function is disabled, the page will not display.
P9 — U	Display inverter firmware version.

## 5. Fault Reference Code

Fault display:



**Function description:** If alarm occurs, Fault indicator flashes and buzzer sounds every one second for 1 minute, then stop. If fault occurs, the fault indicator is always on, the buzzer sounds 10 seconds then stops. System will try restart automatically. If the machine does not work after six times' restart, the machine and LCD display will always in the fault status. You need to completely power off (off the screen) or wait for 30 minutes to restart the machine. The fault LCD display is shown in the figure above. In fault mode fault icon is bright, in alarm state alarm icon is flashing, and contact the manufacturer to troubleshoot the abnormal situation according to the fault information.

**Fault:** The inverter enters fault mode, with a constant red LED light and LCD displaying a fault code.

Fault code sheet

Fault code	Meaning	Relevant action	Trigger conditions	Resume conditions	Fault/Warning
1	Grid soft start failed	Turn fault mode	Grid soft start process starts but bus voltage does not reach set value	Restore after reaching the set voltage for 15 seconds	Fault
2	Bus over voltage	Turn fault mode	Bus voltage is higher than set value	Restore after reaching the set voltage for 15 seconds	Fault
3	Bus below voltage	Turn fault mode	Bus voltage is lower than set value	Cannot restore	Fault

Fault code	Meaning	Relevant action	Trigger conditions	Resume conditions	Fault/Alarm
4	Battery over current	Turn fault mode	Battery current is higher than set value	Cannot restore	Fault
5	System over temperature	Turn fault mode	PFC temperature is higher than set value or fan is not connected	Restore after temperature lower than set value and fan connected for 15 minutes	Fault
6	Battery over voltage	Turn fault mode	Battery voltage is higher than set value	Restore after reaching the set voltage for 15 seconds	Fault
7	Bus soft start failed	Turn fault mode	Battery soft start process starts but the bus voltage has not reached set value	Restore after reaching the set voltage for 15 seconds	Fault
8	Bus short circuit	Turn fault mode	Bus voltage is lower than set value	Cannot restore	Fault
9	Inverter soft start failed	Turn fault mode	Inverter soft start process starts but the inverter voltage has not reached set value	Restore after reaching the set voltage for 15 seconds	Fault
11	Inverter under voltage	Turn fault mode	The inverter voltage is lower than the set value in battery mode	Restore after reaching the set voltage for 15 seconds	Fault

Fault code	Meaning	Relevant action	Trigger conditions	Resume conditions	Fault/ Alarm
12	Inverter short circuit	Turn fault mode	Inverter voltage is less than the set value and current is higher than the set value	Restore after reaching the set value for 15 seconds	Fault
13	Inverter negative power	Turn fault mode	The inverter power is negative and exceeds the set value for a period of time	Restore after reaching the set value for 15 seconds	Fault
14	Over load	Turn fault mode	The load current is higher than the set value	Restore after reaching the set value for 15 seconds	Fault
17	Program updating	Turn fault mode	Inverter updating or OTA	Restore after updating	Fault
18	PV reverse connection	Turn fault mode	PV reverse connection	Restore after connecting correctly for 15 seconds	Fault
26	BMS fault	Turn fault mode	Error code in BMS message.	Restore after BMS fault resolved	Fault
29	Inverter load abnormal	Turn fault mode	Abnormal inverter load leads to abnormal voltage	Restore after voltage returning normal for 15 seconds	Fault

## 6. Alarm Reference Code

Alarm: the inverter does not enter the fault mode, LED red light flashing, LCD displays the Alarm code.



### Alarm code sheet

Alarm code	Meaning	Relevant action	Trigger conditions	Resume conditions	Fault / Alarm
50	Battery open	Alarm	Battery disconnected for no more than 10 minutes	Restore after battery connected and charging for 2 minutes	Alarm
51	Battery under voltage	Alarm, battery low voltage shutdown or cannot power on	Battery voltage is lower than BAU set value	Restore after the battery voltage exceeding the BAU set value by 2V	Alarm
52	Battery low voltage	Alarm	Battery voltage is lower than BAL set value	Restore after the battery voltage exceeding the BAL set value by 2V	Alarm
53	Battery charge short circuit	Alarm, battery does not charge	The battery voltage is less than 20V and the charging current is higher than 4A	Cannot restore	Alarm
56	BMS loss	Alarm	Communication failure after BMS communication function is enabled	Restore after communication function disabled or communication success	Alarm

Alarm code	Meaning	Relevant action	Trigger conditions	Resume conditions	Fault / Alarm
58	Fan error	Alarm,fan operation in full speed	No fan speed signal detected	Restore after fan speed signal detected	Alarm
59	EEPROM error	Alarm	EEPROM read/write exception	Can restore	Alarm
60	Overload	Alarm	Output load is higher than 6KW or battery current is higher than MDC value (Item 61 Battery Max Discharge Current)	Restore after load is lower than 6KW and battery current is lower than MDC	Alarm
62	PV energy weak	Alarm,Turn off the PV output to the load,but keep the PV charging the battery	When the battery is not connected,the bus voltage is lower than the set value	Restore after battery connected or grid connected or bus voltage higher than set value for 10 minutes	Alarm
68	Battery under SOC	Alarm,turn to standby mode	BMS reports SOC lower than BSU set value	"Restore after meeting one of the following three conditions: 1.Disable low SOC shutdown function 2.Disable BMS communication function 3.SOC is higher than the set value by 5%"	Alarm
69	Battery below SOC	Alarm,if it is in standby mode,it will remain in standby mode.	Lithium battery SOC is lower than set value+5%(grid mode or battery mode), lower than set value+10%(standby mode)	"Restore after meeting one of the following three conditions: 1.Disable low SOC shutdown function 2.Disable BMS communication function 3.SOC is higher than the set value by 10%"	Alarm
72	Battery can not startup	Alarm	During standby, battery voltage is lower than the allowed startup voltage	Restore after the battery voltage is higher than the allowed startup voltage	Alarm

## 7. Battery Equalization

Equalization function is added into charge controller. It reverses the buildup of negative chemical effects like stratification, a condition where acid concentration is greater at the bottom of the battery than at the top. Equalization also helps to remove sulfate crystals that might have built up on the plates. If left unchecked, this condition, called sulfation, will reduce the overall capacity of the battery. Therefore, it's recommended to equalize battery periodically.

Note: \*Don't activate this mode when using lithium batteries.

- How to Apply Equalization Function


You must enable battery equalization function in monitoring LCD setting Program 29 first.

Then, you may apply this function in device by either one of following methods:

1. Set balance mode on Program 29.
2. Set balance voltage point on Program 30.
3. Set balance charging time on Program 31.
4. Set balance delay time on Program 32.
5. Set balance interval time on Program 33.
6. Set immediate balance mode activation on Program 34.


- When to Equalize

In float stage, when the setting equalization interval (battery equalization cycle) is arrived, or equalization is active immediately, the controller will start to enter Equalize stage.




- Equalize charging time and timeout

In Equalize stage, the controller will supply power to charge battery as much as possible until battery voltage raises to battery equalization voltage. Then, constant-voltage regulation is applied to maintain battery voltage at the battery equalization voltage. The battery will remain in the Equalize stage until setting battery equalized time is arrived.



However, in Equalize stage, when battery equalized time is expired and battery voltage doesn't rise to battery equalization voltage point, the charge controller will extend the battery equalized time until battery voltage achieves battery equalization voltage. If battery voltage is still lower than battery equalization voltage when battery equalized timeout setting is over, the charge controller will stop equalization and return to float stage.



## 8.Specifications

### 8.1 Line Specifications

Model	Item	Value	Comments
Input Voltage	Main topology	L + N + PE	
	Nominal voltage	220VAC	Settable: 208/220/230/240 Vac
	Input Voltage Range	90~280Vac	Settable
	Input Low Loss	154Vac (default) Settable: 90-154	APP/GEN mode
		185Vac (default) Settable: 170-200	UPS mode
	Input Low Comeback	Low Loss voltage +9V	
	Input High Loss	264Vac(default) Settable:264-280	APP/GEN mode
		264Vac	UPS mode
	Input High Comeback	High Loss voltage -9V	
Input Frequency	Nominal Frequency	50 / 60Hz	
	Frequency Range	40 / 70Hz	
	Freq. Low loss / Comeback	40/43.5Hz@50Hz(UPS mode) 50/53.5Hz@60Hz(UPS mode) 40/43.5HZ@60HZ(APP/GEN mode)	
	Freq. High loss / Comeback	60/56.5Hz@50Hz(UPS mode) 70/66.5Hz@60Hz(UPS mode) 70/69.5Hz@60Hz(APP/GEN mode)	
Input current	Max Current (RMS)	40A	Bypass current

Note: When the specification of the external circuit breaker is greater than 40A, the maximum input current is 40A.

When the external circuit breaker specification is less than 40A, the maximum input current depends on the external circuit breaker specification.

## 8.2 Battery Specifications

\* N= battery pieces

	Item	Value	Comments
Battery information	Battery Pieces	4pcs	12V/PCS
	Auto Restart Function	Yes	
	Battery test function	No	
	Battery type	AGM/FLD/ LIB/FEL/CUS	
	Nominal Battery voltage	N*12V	@25°C
	Battery management	Yes	
Battery protection	Battery over Voltage	61V	
	Battery under voltage	10.5V*N	Settable:10*N~11*N
	Battery low voltage alarm	10.8V*N	Settable:10.3*N~11.3*N
	Over current protection	Fuse	Fast acting

## 8.3 Charger Specifications

	Item	Value	Comments
Charger(line mode)	Charging voltage	FV MODE: 54V Settable: 53.2~55.6V CV MODE: 56.4V Settable: 56~58V	
	Temperature Compensation	No	
	Charging Current	2~120A	Settable
	Default Charging Current	60A	
	Charging mode	Two/Auto Settable	Three states: CC/CV/Float Two states: CC/Float
	Charge Voltage Accuracy	±5%	Calibrated by RS232
Charger(PV)	PV Charging method	MPPT	
	PV Maximum Input Power	27A/9000W	
	Efficiency	99.5% max	
	MPPT	60~450Vdc	
	Minimum activation voltage	80V	
	Max PV voltage	500Vdc	
	Max PV charge current	120A	
Max charging current	/	120A(Maximum allowable) Default: 100A	Settable

## 8.4 Output Specifications

	Item	Value	Comments
Output power rating	Output topology	L1+N1+L2+N2+PE	
	Output power	6000W	When setting the Output voltage to 208V, the Output Power rating will be reduced to 90%.
Output voltage	Nominal Voltage	208/220/230/240 VAC	Default 230V, manual set by RS232 or LCD
	Waveform	Sinusoidal	
	Voltage Regulation	±5%	
	DC offset	±100mV (Bat mode)	Empty load and linear load mode
Output frequency	Nominal Frequency	50 / 60Hz	50/60Hz auto selection (default on)
	Line Mode	50Hz: (43.5 - 56.5)Hz (UPS mode) (40 - 70)Hz (APP/GEN mode) 60Hz: (53.5 - 66.5)Hz (UPS mode) (40 - 70)Hz (APP/GEN mode)	
	Battery Mode	50 / 60Hz	
	Frequency regulation	0.1%	
Overload capacity (battery mode)	102%<Load ≤120%	1 minute minimum, then alarm and turn off output	
	Load>120%	10 seconds minimum, then alarm and turn off output	
Output short circuit protection	Battery mode	Current limitation	
	Line mode	Breaker (40A)	

## 8.5 Switch Time Specifications

	Item	Value	Comments
Switch time	Line Mode To Battery Mode	10ms(typical)	APP/UPS mode
		20ms(typical)	Generator mode

## 8.6 Efficiency Specifications

	Item	Value	Comments
Efficiency	Line Mode	>99.5%@6Kva	Full R load, without battery connect.
	Battery Mode	94%(Max)	Full R load.
	Standby power	<30W	Empty load mode, battery disconnected.

## 9.Trouble Shooting

Problem	Fault Event	Trigger conditions	What to do
LED screen display fault code 5	Over temperature	1.PFC temperature exceeds the protection threshold for more than 20 seconds 2.Alarm58 lasts for 5 seconds.	Please check if the fan is not connected or if there are loose wiring issues. If the fan is not connected for more than 5 minutes, the machine will report fault code 5.
LED screen display fault code 12	Inverter short circuit	In battery mode or standby mode, if the inverter voltage is lower than 80V and the inverter current is greater than 30A, it should respond within 100-120ms.	1.Check if there is a short circuit at the output terminals (such as a screw piercing through the locking terminal causing a LN short circuit). 2.Verify if the inverter voltage and inverter current meet the triggering conditions.

Problem	Fault Event	Trigger conditions	What to do
LED screen display fault code 58	Fan malfunction	Any of the fans rotating less than 8 times within 2 seconds.	<ol style="list-style-type: none"> <li>1. Check if the fan is not connected properly or if there are any loose connections.</li> <li>2. If the fan is properly connected:           <ol style="list-style-type: none"> <li>a) Check if there is any issue with the fan detection circuit, usually caused by excessive soldering underneath the control board socket.</li> <li>b) Check if the fan itself is damaged.</li> </ol> </li> </ol>
Unable to start	Battery	Due to the need for a voltage of $\geq 11.5V/N$ to start the machine in battery mode, common reasons for failure to start include improper calibration or insufficient battery voltage.	<ol style="list-style-type: none"> <li>1. Check if the battery voltage sampling is functioning properly and if the battery voltage has been calibrated.</li> <li>2. Use a multimeter to measure the voltage at the battery terminals (using a DC power supply or a real battery) to see if it reaches the minimum voltage of 11.5V per cell for startup. Note: It is crucial to configure the battery voltage according to the machine model. Connecting the wrong battery voltage can cause capacitor explosion.</li> </ol>

Problem	Fault Event	Trigger conditions	What to do
	Utility power		<p>1. Check for any short circuits at the mains terminal (such as a screw piercing through and causing a short circuit between the live and neutral terminals).</p> <p>2. Check if there are any wiring errors, such as mistakenly connecting the mains input to the output terminals.</p>
	PV		<p>1. Check if the PV input voltage is too close to the critical threshold.</p> <p>2. For low voltage versions of the machine, check if the software version numbers of the main control is compatible. If the software versions differ significantly, the machine may not be activated.</p>
PV not charging			Connecting the wrong battery voltage can result in damage to the auxiliary power supply on the PV side, causing a loss of power and inability to communicate with the main control.

