


OFF-Grid Single Phase Hybrid Inverter

SSA-HL3K6/5K-P1EU

User Manual



Please read this manual before use and follow its guidance.

Keep this manual for future reference.

CONTENTS

| | |
|--|-----------|
| 1. About This Manual | 1 |
| 1.1 Purpose | 1 |
| 1.2 Scope | 1 |
| 2. Safety Instructions | 1 |
| 3. Product Introduction | 2 |
| 3.1 Product Features | 2 |
| 3.2 Basic System Architecture | 2 |
| 3.3 Appearance | 3 |
| 4. Installation | 5 |
| 4.1 Unpacking and Inspection | 5 |
| 4.2 Preparation | 6 |
| 4.3 Mounting the Unit | 6 |
| 4.4 Battery Connection | 7 |
| 4.5 AC Input/Output Connection | 8 |
| 4.6 PV Connection | 9 |
| 4.7 Final Assembly | 11 |
| 4.8 Communication Connection | 11 |
| 5. Operation | 11 |
| 5.1 Power ON/OFF | 11 |
| 5.2 Operation and Display Panel | 12 |
| 5.3 Function Setting Operation | 19 |
| 5.4 Battery Equalization Description | 38 |
| 5.5 Fault and Alarm Description | 39 |
| 6. Trouble Shooting | 42 |
| 7. Technical Data Sheet | 43 |
| Appendix:Parallel Operation Guide | 44 |
| 1. Parallel Operation | 44 |
| 1.1 Single-phase parallel operation | 44 |
| 1.2 Three-phase parallel operation | 46 |
| 2. Connection Precautions | 51 |
| 2.1 PV connection/Solar Panel Connection | 51 |
| 2.2 Parallel board connection | 51 |
| 3. Parallel Operation | 51 |
| 3.1 Single-phase parallel | 51 |
| 3.2 Parallel as three-phase system | 53 |

1 About This Manual

1.1 Purpose

This manual describes the assembly, installation, operation and troubleshooting of this unit. Please read this manual carefully before installations and operations. Keep the manual for future reference.

1.2 Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.

2 Safety Instructions

WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

1. Before using the unit read all instructions and cautionary markings on the unit, the batteries and all appropriate sections of this manual.
2. **CAUTION**-To reduce risk of injury, charge only deep-cycle lead acid type rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.
3. Do not disassemble the unit, take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
4. To reduce risk of electric shock, disconnect all wiring before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
5. **CAUTION**-Only qualified person can install this device with battery.
6. NEVER charge a frozen battery.
7. For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter/charger.
8. Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
9. Please strictly follow installation procedure when you want to disconnect AC or DC terminals, Please refer to INSTALLATION section of this manual for the details
10. One piece of fuse is provided as over-current protection for the battery supply.
11. **GROUNDING INSTRUCTIONS** -This inverter/ charger should be connected to a permanent grounder wiring system. Be sure to comply with local requirements and regulation to install this inverter.
12. **NEVER** cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
13. **WARNING!!!** Only qualified service people are able to service this device. If errors still persist after following troubleshooting table, please send this inverter/charger back to local dealer or service center for maintenance.

3 Product Introduction

This is a multi-function Inverter/charger, combining functions of inverter, solar charger and battery charger to offer uninterrupted power support with portable size. Its comprehensive LCD display offers user-configurable and easy-accessible button operation such as battery charging current, AC/Solar charger priority, and acceptable input voltage based on different applications.

3.1 Product Features

- Pure sine wave inverter
- Configurable input voltage range for home appliances and personal computers via LCD setting
- Configurable battery charging current based on applications via LCD setting
- Configurable AC/Solar Charger priority via LCD setting
- Compatible to grid voltage or generator power
- Auto restart while AC is recovering
- Overload/Over temperature/Short circuit protection
- Smart battery charger design for optimized battery performance
- Cold start function


3.2 Basic System Architecture

The following illustration shows basic application for this inverter/charger. It also includes following devices to have a complete running system:

- Generator or Utility
- PV modules


Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioner.




3.3 Appearance

3.3.1 LCD Screen




- 1.....LCD display
- 2.....Status indicator
- 3.....Charging indicator
- 4.....Fault indicator
- 5.....ESC
- 6.....UP
- 7.....DOWN
- 8.....ENTER

3.3.2 Product size





Dimensions of the SSA-HL3K6-P1EU



Dimensions of the SSA-HL5K-P1EU


3.3.3 Back Panel

SSA-HL3K6-P1EU back panel



- 1.....PV Input
- 2.....AC Input
- 3.....AC Output
- 4.....WiFi
- 5.....Dry-contact(Optional)
- 6.....BMS Communication Port(Optional)
- 7.....GND
- 8.....Battery Terminal Positive
- 9.....Battery Terminal Negative
- 10....Power ON/ OFF Switch
- 11....Solar Panel Input wiring
- 12....AC input wiring
- 13....AC output wiring
- 14....Fan1
- 15....Fan2

SSA-HL5K-P1EU back panel



| | |
|-------------------------------------|---------------------------------|
| 1.....AC Input | 10....GND |
| 2.....AC Output | 11....Battery Terminal Positive |
| 3.....WiFi | 12....Battery Terminal Negative |
| 4.....USB | 13....Power ON/ OFF Switch |
| 5.....Dry-contact | 14....AC input wiring |
| 6.....BMS | 15....AC output wiring |
| 7.....PV Input | 16....Fan1 |
| 8.....Input Breaker | 17....Fan2 |
| 9.....Parallel Operation (Optional) | 18....Solar Panel Input wiring |

4 Installation

4.1 Unpacking and Inspection


Before installation, please inspect the unit. Be sure that nothing inside the package is damaged.

You should have received the following items inside of the package:

- The unit x 1
- Installation Guide x 1
- USB Communication Cable x 1 (optional)
- User manual x 1
- Warranty Card x 1
- Parallel Communication Cable x 1 (optional)

4.2 Preparation


Before connecting all please take off bottom cover by removing screws as shown below.



4.3 Mount the Unit

Consider the following points before selecting where to install:


- Do not mount the inverter on flammable construction
- The recommended installation position is to be adhered to the wall vertically.
- Install the inverter at eye level in order to allow the LCD display to be read at all times.
- For proper air circulation to dissipate heat, allow a clearance of approx. 20 cm to the side and approx. 50 cm above and below the unit.
- The ambient temperature should be between and to ensure optimal operation.
- Be sure to keep other objects and surfaces as shown in the diagram to guarantee sufficient heat dissipation and to have enough space for removing wires.



SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.

Install the unit by screwing three screws.

Use the **M6*80mm** expansion bolts.



4.4 Battery Connection

CAUTION: For safety operation and regulation compliance, it's requested to install a separate DC over-current protector or disconnect device between battery and inverter. It may not be requested to have a disconnect device in some applications, however, it's still requested to install the over-current protection. Please refer to typical amperage in below table as required fuse or breaker size.

WARNING! All wiring must be performed by a qualified person.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable and terminal size as below.


Recommended battery cable and terminal size:

| Model | Typical Amperage | Battery Capacity | Wire Size | Ring Terminal | | Torque Value |
|-----------------|------------------|------------------|-----------|--------------------|-------------|--------------|
| | | | | Cable | Dimensions | |
| | | | | (mm ²) | D(mm) L(mm) | |
| SSA-HL3K6-P1 EU | 132A | 100AH | 1*4AWG | 22 | 6.4 33.2 | 2~3Nm |
| | | 200AH | 2*8AWG | 9 | 6.4 29.2 | |
| SSA-HL5K-P1EU | 109A | 200AH | 1*2AWG | 38 | 6.4 39.2 | 2~3Nm |
| | | | 2*6AWG | 28 | 6.4 33.2 | |

Please follow below steps to implement battery connection:

Assemble battery ring terminal based on recommended battery cable and terminal size.

Ring terminal:





Please follow below steps to implement battery connection:

1. Assemble battery ring terminal based on recommended battery cable and terminal size.

2. Connect all battery packs as units requires.

3. Insert the ring terminal of battery cable flatly into battery connector of inverter and make sure the bolts are tightened with torque of 2Nm. Make sure polarity at both the battery and the inverter/charge is correctly connected and ring terminals are tightly screwed to the battery terminals.



WARNING: Shock Hazard

Installation must be performed with care due to high battery voltage in series.



CAUTION!! Before making the final DC connection or closing DC breaker/disconnector, be sure positive(+) must be connected to positive(+) and negative(-) must be connected to negative(-).

4.5 AC Input /Output Connection

CAUTION!! Before connecting to AC input power source, please install a separate AC breaker between inverter and AC input power source. This will ensure the inverter can be disconnected during maintenance and fully protected from over current of AC input. The recommended spec of breaker is 32A for SSA-HL3K6-P1EU and 50A for SSA-HL5K-P1EU

CAUTION!! There are two terminal blocks with "IN" and "OUT" marks. Please do NOT misconnect input and output connectors.

WARNING!! All wiring must be performed by a qualified person.

WARNING!! It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.



Suggested cable requirements for AC wires

| Model | Gauge | Torque Value |
|----------------|-------|--------------|
| SSA-HL3K6-P1EU | 10AWG | 1.2~1.6 Nm |
| SSA-HL5K-P1EU | 8AWG | 1.4~1.6 Nm |

Please follow below steps to make AC input/ output connections:

● Before making AC input/output connection be sure to open DC protector or disconnector first.

● Remove insulation sleeve 10mm for six conductors. And shorten **phase L** and neutral **conductor N** about 3 mm.




Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE protective conductor()first.

 →Ground(yellow-green)

L→LINE(brown or black)

N→Neutral (blue)



WARNING:

Be sure that AC power source is disconnected before attempting to hard wire it to the unit.

Make sure the wires are securely connected

CAUTION: Appliances such as air conditioner are required at least 2-3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it's equipped with time-delay function before installation. Otherwise, this inverter/ charger will trig overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

4.6 PV Connection

PV Connection(Only apply for the model with solar charger)**CAUTION:** Before connecting to PV modules, please install separately a DC circuit breaker between inverter and PV modules.

WARNING! All wiring must be performed by a qualified person.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below.

| Typical Amperage | Gauge | Torque Value |
|------------------|-------|--------------|
| 30A | 12AWG | 1.4~1.6Nm |

PV module selection:

When choosing the right PV module, be sure to first consider the following requirements: The open circuit voltage (Voc) of the PV modules do not exceed the maximum PV array open circuit voltage of the inverter. The maximum supply voltage of the PV modules should be close to the optimal PV access voltage range of the inverter for best performance. If one PV module cannot meet this requirement, it is necessary to connect multiple PV modules in series.


PV Module Wire Connection

Please follow below steps to implement PV module connection:


1. Remove insulation sleeve 10 mm for positive and negative conductors.

2. Suggest to put bootlace ferrules on the end of positive and negative wires with a proper crimping tool

3. Fix wire cover to the inverter with supplied screws as shown in below chart




4. Check correct polarity of wire from PV modules and PV input connectors. Then, connect positive pole(+) of connection wire to positive pole(+) of PV input connector. Connect negative pole(-) of connection wire to negative pole(-) of PV input connector. Screw two wires tightly in clockwise direction. Recommended tool: 4mm blade screw driver.



4.7 Final Assembly

After connecting all wirings, please put bottom cover back by screwing screws as shown below.



4.8 Communication Connection


1. Please connect the inverter to the computer via the provided USB cable. We will provide a software upgrade program, which can be used to query the version number and realize the subsequent software upgrade function to help you provide a better user experience, if necessary.(for only SSA-HL5K-P1EU)
2. Wi-Fi cloud communication(option):

Please use supplied communication cable to connect to inverter and Wi-Fi module. Download APP and installed from APP store, and Refer to "Wi-Fi Plug Quick Installation Guideline" to set up network and registering. The inverter status would be shown by mobile phone APP or webpage of computer.

3. GPRS cloud communication(option):

Please use supplied communication cable to connect to inverter and GPRS module, and then applied external to GPRS module. Download APP and installed from APP store, and Refer to " GPRS RTU Quick Installation Guideline" to set up network and registering. The inverter status would be shown by mobile phone APP or web page of computer.

5 Operation



5.1 Power ON/OFF

Once the unit has been properly installed and the batteries are connected well, simply press On/Off switch (located on the bottom of the case) to turn on the unit.

5.1.1 Steps to start up

Connect the battery that meets the requirements (nominal battery voltage) or AC (AC needs to confirm the suitable input range depend on the output mode), then you can start up the inverter.

● Mains power on

Connect to normal AC power, press the switch, the system will automatically turn on. If you set AC output power priority, after waiting for a period of time, the panel will display AC mode that represents turn on the machine successfully, then will enter the AC mode.

When the normal mains power is connected and press the power-on button then the system will automatically power on. If it is set as AC output priority, after a period of time, the panel will display the AC mode to indicate that the power-on is complete and enter the AC mode.

● Battery boot

Connect to battery, press the power-on button to establish a working power source.

The system will automatically turn on, after waiting for a period of time, the panel will display battery mode that represents turn on the machine successfully, then will enter the battery mode.


5.1.2 Shutdown steps

When the system is in battery mode or AC mode output, press the switch again, then the system will be turned off.

5.2 Operation and Display Panel

Four Function Buttons:


The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes three indicators, four function buttons and a LCD display, indicating the operating status and input/output power information.



5.2.1 Buttons function

| Buttons | Descriptions |
|---------------------------------------|--|
| Function settings /ENTER | Function settings: Press the ENTER button on the display page for more than 2 seconds to enter the function setting page. After entering, press the ENTER button to turn the page and select the interface to be set. |
| Page turning / inquiry button UP/DOWN | Page turning: Press UP/DOWN on any page to turn the pages. |
| ESC | After setting up a single item, press ESC and then press UP/DOWN to select other settings. Confirm and save settings: On the function settings page, press ESC for 2 seconds, and then go back to the main interface and set to save. |

5.2.2 LED indicator functions



| LED Indicator | | Messages | |
|--|--------|----------|---|
|  AC/INV | Green | Solid On | Output is powered by utility in Line mode. |
| | | Flashing | Output is powered by battery or PV in battery mode. |
|  CHG | Yellow | Solid On | Battery is fully charged. |
| | | Flashing | Battery is charging. |
|  FAULT | Red | Solid On | Fault occurs in the inverter. |
| | | Flashing | Warning condition occurs in the inverter. |

5.2.3 Inverter working state table corresponding to indicator lamp

| Warning buzzer | Descriptions |
|--|--|
| Long beeping, continuous for 10 seconds then stop. | Failure Mode |
| Stop after beeping for 3 seconds | Loss or recovery of PV/input voltage The main switch is on or off |
| Beep per second, continuous for 1 min then stop | All other alarms (battery low voltage alarm will only beep in battery mode.) |

5.2.4 Checking Parameter Operation

Under normal circumstances, there are ten pages in the display. Press the query button UP/DOWN to draw a page for the display, and display information such as input-output voltage input-output rate, battery, PV electricity and electricity, negative and component versions, etc. If there is an alarm, a page of alarm information will be displayed, and if the inverter fails, a page of trouble code will be displayed. By default, the main panel displays the fault information. When the transformer has no fault or warning, the main page displays the voltage and rate information by default.

Press UP/DOWN for more than 1 second, and LCD will enter polling mode display: automatically turn the page of display every 2 seconds, and long press UP/DOWN key again to exit polling mode.

Display page 1 (main display page): Display the inverter input and output voltage, as shown in Figure 1-1.




Figure 1-1 display page 1

Display Page 2: Display the input and output frequency of the inverter, as shown in Figure 1-2.




Figure 1-2 display page 2

Display page 3: Battery information, showing battery voltage and charging current, as shown in Figure 1-3




Figure 1-3 display page 3

Display page 4: PV information. display PV voltage and PV charging amps, as shown in Figure1-4.




Figure 1-4 display page 4

Display page 5: PV information, display PV voltage and PV charging wattage, show as 1-5.




Figure 1-5 display page 5

Display page 6: Output Information shows the output voltage and output power, as shown in Figure 1-6.




Figure 1-6 display page 6

Display page 7: Output Information shows the output voltage and output power, as shown in Figure 1-7




Figure 1-7 display page 7

Display page 8: Output Information displays output voltage and load percentage, as shown in Figure 1-8.




Figure 1-8 display page 8

Display page 9: Software version displays the inverter system software version, as shown in Figure 1-9(Software Version VER 01)




Figure 1-9 display page 9

Display page 10: The left side of the page information displays the total photovoltaic power generation, and the right side displays the daily photovoltaic power generation, as shown in Figure 1-10,




Figure 1-10 display page 10

Display page 11: Display information. single unit mode, the LCD shows status of single unit mode both on the left and right sides.in parallel connect mode, the LCD shows the master slave relation on the left, shows the parallel status on the right. If parallel connect as three phases use, the LCD shows the phase position on the left shows the status on the right. Shown in Figure 1-12 (applicable to the inverter with parallel function)



Figure 1-11 display page 11

Display page 12: Lithium battery networking status; when the upper right display is a constant SIG, the battery pack is running in a single group; when it is displayed as a PAR constant, the battery pack is running in multiple series and parallel; when the display is PAR flashing, the battery pack is being established Multiple series and parallel state.




Figure 1-12 Display page 12
(lithium battery network status)

Display page 13: Lithium battery voltage and current information; the upper left display is BMS battery voltage information; the upper right display is BMS battery current information. When the BMS communication fails, the upper left and right upper displays are flashing ERR.




Figure 1-13 Display page 13
(lithium battery voltage and current information)

Display page 14: Lithium battery temperature, SOC; the upper left display is BMS temperature information; the upper right display is BMS SOC information. When the BMS communication fails, the upper left and right upper displays are flashing ERR.




Figure 1-14 Display page 14
(battery temperature, SOC information of lithium battery)

Display page 15: Lithium battery capacity; the upper left display is the rated capacity; the upper right display is the current capacity. When the BMS communication fails, the upper left and right upper displays are flashing ERR.



Figure 1-15 Display page 15
(battery capacity information of lithium battery)

Display page 16: Lithium battery constant voltage point; the upper left display is the fixed letter CV; the upper right display is the BMS constant voltage charging point. When the BMS communication fails, the upper right displays a flashing ERR.



Figure 1-16 Display page sixteen
(lithium battery constant voltage information)

Display page 17: Lithium battery failure alarm information; the upper left display is BMS alarm information; the upper right display is BMS failure information. When the BMS communication fails, the upper left and right upper displays are flashing ERR.




Figure 1-17 Display page seventeen
(Lithium battery fault warning information)

5.3 Function setting operation

Function setting operation:

The page for setting the exit function and setting as bellow:

- Long press "ENTER" button for more than 2 seconds, enter into function setting mode. Press "Enter" button to choose function, turn the page to you need to set, the corresponding indicator will flash.
- Press "Enter" button again, enter the function setting, you will see the word of function you choose lighting, on the left of word will occur numerical flashing, then you can press "UP/DOWN" button to use.
- After finish setting, press the enter button again, the data will be on instead of flashing.

Long press "ESC" button for more than 2 seconds, the function will complete setting. Return to function setting, then back to main page. (If you don't exit manually, after 30 seconds, it will be back to main page automatically).

5.3.1 Output Voltage (OPU)




Figure 1-18 Output Voltage Setting

- The default output voltage is 230V, 208V, 220V, 230V, 240V can be set, all working conditions can be set, and it will take effect immediately.
- Press the function setting key "ENTER" key for more than 2 seconds to enter the function setting page, press the query key "UP/DOWN" key for 0.1 to 2 seconds to select the function, after turning the page to the output voltage OPU setting page, the word OPU flashes.
- Press the "ENTER" key for 0.1 to 2 seconds to enter the setting page of the output voltage OPU. At this time, the word OPU is long on, and the value flashes to the right of the word OPU. Press the query key "UP/DOWN" key for 0.1 to 2 seconds to select different output voltage values, the available voltage values are 208V, 220V, 230V, 240V. By default, the output voltage is 230V, and the settings are saved in real time.
- After turning the page to the desired output voltage value, press the "ENTER" key for 0.1-2 seconds, the output voltage OPU setting is completed, and the value on the right side of the OPU will be long on and no longer flashing.
- Press the "ESC" key for more than 0.1 to 2 seconds, the function will be set successfully, exit the function setting page, and return to the main display page (or do not operate, and automatically jump back to the main display page after waiting for up to 30S).

Note: When the output voltage is set to 208V, the output needs to be derated to 90%.

5.3.2 Output frequency

Output frequency setting, the default value is 50Hz.




Figure 1-19 Output Frequency Setting Page

Function description: 50Hz or 60Hz can be adjusted, default value is 50Hz.

Setting conditions: Standby or mains mode can be set and will take effect immediately after the setting is completed, and the frequency will change at a slower rate when you switch back to battery mode.

5.3.3 Output priority settings




Figure 1-20 Output priority settings page

Function description: Set the inverter output priority.

Setting conditions: All states can be set, and they will take effect immediately after setting.

Note:

There are three options for output priority, the default is GRD: mains output priority; the second is PU(PV): photovoltaic output priority; the third is PBG: PV first, battery second, mains third output:

5.3.4 Output Mode Settings (MOD)




Figure 1-21 Output mode setting page

Setting conditions: All states can be set and take effect immediately.

Explanation: There are three options for AC output mode, the default is APP: Appliance which is used for home appliances; the second is UPS mode, which is used for computers and other equipment. The switching time is typically 10ms. The third is the GEN mode, which is used when the AC input side is connected to the generator, and the typical value of the switching time is 60ms(for SSA-HL3K6-P1EU Version)

5.3.5 Charging priority settings (CHP)



Figure 1-22 Charging priority setting page

Function description: Set the inverter charging priority.

Setting conditions: All states can be set and take effect immediately.

Explanation:

There are four options for charging priority, the default is PNG (PV and Grid): PV and Grid are charged at the same time; the second is OPV (Only PV): only photovoltaic charging; the third is GRD (Grid): mains charging priority ;The fourth is PV: PV priority charging.

5.3.6 Mains charging current (RCC)



Figure 1-23 Mains maximum charging setting page

Function description: Set the maximum charging current of the inverter mains.

Setting conditions: All states can be set.

Explanation:

RCC: Grid Charge Current, the default setting of the maximum charging current of the mains is 40A, and the setting range is [2,100A] (for SSA-HL3K6-P1EU Version)

RCC: Grid Charge Current, the default setting of the maximum charging current of the mains is 30A, and the setting range is [1,80A] (for SSA-HL5K-P1EU Version)

5.3.7 Maximum charging current (MCC)




Figure 1-24 Maximum charging current setting page

Function description: Set the maximum charging current value of the inverter.

Setting conditions: All states can be set.

Explanation:

MCC: Maximum Charge Current, the maximum charging current refers to the maximum value of the PV and mains charging current.

SSA-HL3K6-P1EU Version is 2/10/20/30/40/50/60/70/80/90/100Aoptional ;

SSA-HL5K-P1EU version is 2/10/20/30/40/50/60/70/80Aoptional

5.3.8 Menu Front (MDF)




Figure 1-25 Return to the home page setting page

Function description: Return to the main interface settings.

Setting conditions: All states can be set.

Explanation:

The default setting is ON. In the function setting operation, when it is set to ON, if the page is not in the first interface (P1) at this time, it will return to the first interface after 1 minute; if it is set to OFF, if the page is not in the first interface (P1) at this time, the LCD will Always stay on this interface.

5.3.9 Overload restart setting (LrS)




Figure 1-26 Overload restart setting page

Function description: Overload restart setting.

Setting conditions: All states can be set.

Explanation:

Overload restart is set to ON by default.

5.3.10 Over temperature restart setting (TrS)




Figure 1-27 Over temperature restart setting page

Function description: Over-temperature restart settings. Setting conditions: All states can be set.

Explanation:

The default setting for over-temperature restart is ON.

5.3.11 Main input power failure alarm setting (MIP)




Figure 1-28 Main input power failure alarm setting page

Function description: Mains or PV loss alarm long beep setting

Setting conditions: All states can be set, the default is ON, and the mains or PV loss alarm will beep for a while. Can be set to OFF. (All modes can be set)

Explanation:

MIP:Main input cut warning

The default setting is ON, after the main input detection is lost, the buzzer will sound for 3s; when it is set to OFF, after the main input is lost, the buzzer will not sound constantly.

5.3.12 Power Saving Mode (PWS)




Figure 1-29 Power Saving Mode Setting Page

Function description: Set whether the inverter enables low power consumption mode (energy saving mode).

Setting conditions: All states can be set.

Explanation:

PWS: Power Saving

The default setting is OFF, the function is not turned on; when it is set to ON, in battery mode, if the load is lower than 25W, the system will temporarily stop the output, and then continue to output. If the load is higher than 35W, the system will resume continuous normal output.

5.3.13 Overload convert to bypass setting (OLG)




Figure 1-30 Overload convert to bypass setting page

Function description: When overload in the battery mode, set whether to switch to the mains mode (bypass mode) immediately.

Setting conditions: All states can be set.

Explanation:

OLG:Over load to Bypass

The default setting is OFF, the function is not enabled; when it is set to ON, under the condition of PV priority output with load, if overloaded, the system will immediately transfer to bypass (mains output, namely bypass mode).

5.3.14 Silent mode setting




Figure 1-31 Silent mode setting page

Function description: Set whether the buzzer beeps or not.

Setting conditions: All states can be set.

Explanation:

MUE Mute

The default setting is OFF, and the function is not turned on; when it is set to ON, the buzzer does not sound under any circumstances, such as alarms, faults, etc. All modes can be set and function normally, pictures cannot be displayed.

5.3.15 Battery mode to mains mode voltage point



Figure 1-32 Battery mode to mains mode voltage point setting page

Function description: When the battery and mains exists at the same time, the battery will be transferred to the mains when it is discharged to a certain voltage to ensure that the battery will not be empty.

Setting conditions: All states can be set, and the output priority should be set in PV or PBG modes.

Explanation: BTG: Back To Grid

When the battery definition mode is CUS (customer set type) mode:

The default setting of SSA-HL3K6-P1EU model is 23v, and the settable range is [22,26]

The default setting of SSA-HL5K-P1EU model is 46V, and the settable range is [44,52]

When the battery definition mode is AGM (lead-acid battery type), FLD (water injection battery type) mode:

SSA-HL3K6-P1EU model default setting is 23V, and the settable range is [22, 26].

The default setting SSA-HL5K-P1EU model is 46V, and the settable range is [44, 52]

When the battery definition mode is LIB (lithium battery type) mode:

The default setting of SSA-HL3K6-P1EU model is 23.8v, and the settable range is [20,25]

The default setting of SSA-HL5K-P1EU model is 47.6V, and the settable range is [40,50]

When the battery definition mode is Fe (lithium iron battery type) mode:

The default setting of SSA-HL3K6-P1EU model is 24.8V, and the settable range is [20,25]

5.3.16 Switch back to battery mode voltage point(BTB)



Figure 1-33 Setting of battery voltage point when mains switch back to battery mode

Function description: After the battery is turned off at low voltage, it needs to reach a certain battery voltage value before it can be restarted in battery mode.

Setting conditions: All states can be set.

Explanation:

BTB: Back To Battery

SSA-HL3K6-P1EU model is set to 26V by default

SSA-HL5K-P1EU model is set to 52V by default.

When set to FUL, the battery will charge until it is fully charged before restarting in battery mode.

When the battery definition mode is CUS (customer set type) mode:

The SSA-HL3K6-P1EU model of settable range is [24, 29] (when the setting value Vbtb> TCFV-1V, the voltage point of switching back to battery mode remains at TCFV-1V) , and the output priority is set to photovoltaic (PV priority output or photovoltaic battery mains PBG output if it is not in battery mode at this time, if the battery voltage is higher than TCFV-1V, the system will switch back to battery mode).

The SSA-HL5K-P1EU model of settable range is [48,58] (the logic is the same as above)

When the battery definition mode is AGM (lead-acid battery type), FLD(water injection battery type) mode:

SSA-HL3K6-P1EU model default Set to 26v, the settable range is [24, 29] (the logic is the same as above).

SSA-HL5K-P1EU model default setting is 52V, the settable range is (48, 58) (the logic is the same as above).

The battery definition mode is LIB (lithium battery type) mode:

The default setting of SSA-HL3K6-P1EU model is 27 .2V, and the settable range is [23,29] the logic is the same as above).

The default setting of SSA-HL5K-P1EU model is 54.4V, and the settable range is [46,58] the logic is the same as above).

The battery definition mode is Fe (lithium iron battery type) mode:

The default setting of SSA-HL3K6-P1EU model is 26.6V, and the settable range is [23,29] the logic is the same as above).

5.3.17 Battery mode setting



Figure 1-34 Battery mode setting page

Function description: battery type setting function

Setting conditions: All states can be set.

BAT:Battery Type

Explanation:the default setting is AGM (lead-acid battery); the second is FLD (water injection battery); the third is LIB (lithium battery); the fourth is Cus (customer setting type). The fifth is Fe (lithium iron battery), this type of battery is only supported by SSA-HL3K6-P1EU

5.3.18 Battery low voltage point




Figure 1-35 Battery low voltage point setting

Function description: Low voltage alarm point setting.

Setting conditions: All states can be set.

Explanation: bAL: battery Low

The battery definition mode cannot be set when the battery definition mode is AGM (lead-acid battery type) or FLD (water-filled battery type) mode.

SSA-HL3K6-P1EU model is set to 21.6V by default.

SSA-HL5K-P1EU model is set to 44V by default.

The battery low voltage point can be modified when the battery type is set to CUS (customer set type) SSA-HL3K6-P1EU of the settable range is [21,27]

SSA-HL5K-P1EU of the settable range is [42,54]

When the battery type is set to LIB (lithium battery type), the battery low voltage point can be modified.

The default setting of SSA-HL3K6-P1EU model is 23.8V, the settable range is [20.6, 25]

The default setting of SSA-HL5K-P1EU model is 47.6V, and the settable range is [41.2, 50]

When the battery type is set to Fe (lithium iron battery), the battery low voltage point can be modified. The default setting of SSA-HL3K6-P1EU model is 24V, the settable range is [20.6, 25]

5.3.19 Battery low voltage cut off point



Figure 1-36 Battery low voltage cut off point setting page

Function description: Battery low voltage shutdown point setting function.

Setting conditions: All states can be set.

Explanation:

bAU: battery Under

The battery definition mode cannot be set when the battery definition mode is AGM (lead-acid battery type) or FLD (water-filled battery type) mode.

SSA-HL3K6-P1EU model is set to 21V by default.

SSA-HL5K-P1EU model is set to 42V by default.

The battery shutdown point can be modified when the battery type is set to CUS (customer set type)

The SSA-HL3K6-P1EU model has a setting range of [20,24].

The SSA-HL5K-P1EU model has a setting range of [40,48].

The battery shutdown point can be modified when the battery type is set to LIB (lithium battery type)

SSA-HL3K6-P1EU model is set to 23V by default, and the settable range is [20,24]

The default setting of SSA-HL5K-P1EU model is 46V, and the setting range is [40, 48]

The battery shutdown point can be modified when the battery type is set to Fe (lithium iron battery)

SSA-HL3K6-P1EU model is set to 23.2V by default, and the settable range is [20,24]

5.3.20 Constant voltage mode voltage point setting (bCV)



Figure 1-37 Constant voltage mode voltage point setting page

Function description: Constant voltage point setting function

Setting conditions: All states can be set

Explanation:

bCV : battery Constant Voltage

The battery definition mode cannot be set when the battery definition mode is AGM (lead-acid battery type) or FLD (water-filled battery type) mode

The default setting of SSA-HL3K6-P1EU model is 28.2V (AGM) 29 (FLD)

The default setting of SSA-HL5K-P1EU mode is 56.4V (AGM),58V(FLD)

The constant voltage charging point can be modified when the battery type is set to CUS (customer set type).

The setting range of SSA-HL3K6-P1EU model is [24,29]

The constant voltage point voltage needs to be higher than the floating point voltage.

The setting range of SSA-HL5K-P1EU model is [48,60]

The constant voltage point voltage needs to be higher than the floating point voltage.

The constant voltage charging point can be modified when the battery type is set to LIB (lithium battery type).

The default setting of SSA-HL3K6-P1EU model is 28.2, and the setting range is [25,29]

The default setting of SSA-HL5K-P1EU model is 56.4, and the setting range is [48,60]

The constant voltage point voltage needs to be higher than the floating point voltage.

The constant voltage charging point can be modified when the battery type is set to Fe (lithium iron battery)

The default setting of SSA-HL3K6-P1EU model is 27.6, and the setting range is [25,29]

The constant voltage point voltage needs to be higher than the floating point voltage.

5.3.21 Floating charge mode voltage point setting (bFL)



Figure 1-38 Floating charge mode voltage point setting page

Function description: Float voltage point setting function

Setting conditions: All states can be set.

Explanation: bFL : battery Float

The battery definition mode cannot be set when the battery definition mode is AGM (lead-acid battery type) or FLD (water-filled battery type) mode

The default setting of SSA-HL3K6-P1EU model is 27V

The default setting of SSA-HL5K-P1EU model is 54V

Set the battery type to CUS (customer set type) to modify the battery floating point.

The setting range of SSA-HL3K6-P1EU model is [26.6, 27.8].

The setting range of SSA-HL5K-P1EU model is [48, 60].

The constant voltage point voltage needs to be higher than the floating point voltage.

The constant voltage charging point can be modified when the battery type is set to LIB (lithium battery type).

The default setting of SSA-HL3K6-P1EU model is 27.6V, and the setting range is [24,28]

The default setting of SSA-HL5K-P1EU model is 55.2V, and the settable range is [50,58]

The constant voltage point voltage needs to be higher than the floating point voltage.

The constant voltage charging point can be modified when the battery type is set to Fe (lithium iron battery)

The default setting of SSA-HL3K6-P1EU model is 27.6V, and the setting range is [24,28]

The constant voltage point voltage needs to be higher than the floating point voltage.

5.3.22 Mains low voltage point setting (LLV)



Figure 1-39 Mains low voltage point setting page in APP mode

Function description: Set the mains low voltage protection point.

Setting conditions: The inverter is in APP/GEN and UPS mode, all states can be set

Explanation:

LLV: Line Low Voltage

In inverter mode (output mode: MOD needs to be set to APP/GEN), the low-voltage point of mains is set.

the default setting is 154V, and the setting range is [90, 154]. (Output mode: MOD needs to be set to UPS), the low-voltage point setting of mains, the default setting is 185V, and the setting range is [170,200].

5.3.23 Mains high voltage protecting point setting (LHV)




Figure 1-40 Mains high voltage protecting point setting page in APP mode

Function description: Set the mains high voltage protection point. **Setting conditions:** The inverter is in APP/GEN mode, and all states can be set. **Explanation:**

LHV: Line High Voltage

In inverter mode (output mode: MOD needs to be set to APP/GEN), the mains high voltage point setting, the default setting is 264V, and the setting range is [264,280].

5.3.24 Low power discharging time setting (LWD)




Figure 1-41 Low power discharging time setting page

Function description: Low power discharge protection function, when in battery mode, under a low load, the discharge of unlimited time will make the battery empty and affect the battery life. When the inverter is in the low power discharge setting time, the low voltage shutdown point of the SSA-HL3K6-P1EU model battery will increase to 22V. SSA-HL5K-P1EU model battery low voltage shutdown point will be raised to 44V.

Setting conditions: All states of the inverter can be set in APP/GEN mode

Explanation:

LWD : Low Watt Discharge

In inverter mode, the low power discharge time setting, the default is 8 (8 hours), the setting range is [1,8]

In battery mode, after the continuous discharge time exceeds 8 hours and the battery shutdown point has not been reached, the battery voltage shutdown point will be modified to $11V * \text{number of battery cells}$, and the system will alarm for 1 minute when the battery continues to discharge to $1V * \text{number of battery cells}$. Then shut down again.

When the battery voltage exceeds $13.2V * \text{number of battery cells}$ exceeds 30s, the battery discharge time will be reset.

5.3.25 Inverter soft start setting (SRE)




Figure 1-42 Inverter soft start setting page

Function description: When the setting is ON, the inverter output gradually increases from 0 to the target voltage point. This function is very suitable for the motor and the loads with motor. When the setting is OFF, the inverter output is directly increased from 0 to the target voltage point.

Setting conditions: at all states can be set.

Explanation:

SRE: Soft Relay Enable

The default setting is OFF, and the output switch will not be closed until the inverter voltage rises to the rated output. If set to On, the output switch will be closed before the inverter starts boosting

5.3.26 Reset factory settings(STD)



Figure 1-43 Default value settings page

Function description: Restore all setting to factory settings.

Setting conditions: It can be set in mains mode and Standby (no output but screen on state).

It cannot be set when the battery mode.

Explanation:

STD :Set Default

Before the setting, this interface is displayed as OFF. When it is set to ON, the system will restore to factory settings. After the setting is completed, this interface will display OFF again.

5.3.27 Parallel Mode Settings(MOD)



Function description: All states of the SSA-HL5K-P1EU can be set, but not for other models

Setting conditions: Mains Mode and Standby (Standby: No output but screen turn on) can be set. It cannot be set in battery mode. It cannot be set on other models.

Explanation: **MOD:**Operation mode.

The default set is SIG (single mode) Standalone mode, it can be set as PAR (parallel mode) Single-phase parallel mode, 3P1 (R phase mode), 3P2 (S phase mode), 3P3 (T phase mode) When using the parallel function, first connect the parallel system in the correct way, and then set the parallel mode of each machine correctly. If there is a machine set to SIG in the parallel system, the machine reports fault 24. If there are machines set to 3P1, 3P2, 3P3 in the parallel system, all machines must be set to one of these three modes, and at least one machine exists in each mode otherwise all the machines set to these three modes must be set to one of the three modes. The machine reports fault 24.

Mains mode and standby mode can be set and take effect immediately, but cannot be set in battery mode and cannot be displayed in pictures

5.3.28 Missing battery alarm (SBA)



Figure 1-45 Missing battery alarm page

Function description: Set turn on no battery alarm

Setting conditions: Can be set in all states

Explanation: **SBA:**Set battery alarm.

Default is OFF. If it is set to OFF, when the battery is not connected, there will be no battery-missing, low-battery, and under-battery alarms. All states of the SSA-HL5K-P1EU can be set, but not for other models.

5.3.29 Equalization Mode (EQM)



Figure 1-46 Equalization Mode Settings Page

Function description: Setting whether the inverter turn on equalization mode

Setting conditions: Can be set in all states

Explanation: **EQM:**Equalization Mode

The default setting is OFF, the function is not turned on; if it is set to ON, the controller will start to enter the equalization phase when the set equalization interval (battery equalization period) is reached during the float charging stage, or the equalization is activated immediately.

5.3.30 Equalization voltage point setting (EQV)



Figure 1-47 Equalization voltage point setting page

Function description: Equilibrium voltage point setting function

Setting conditions: Can be set in all states

Explanation:

bCV: Equalization Voltage

Can be set in all states

SSA-HL3K6-P1EU The default setting is 29.2, and the settable range is [25, 31.5]

SSA-HL5K-P1EU The default setting is 58.4, and the settable range is [48, 60].

5.3.31 Equalization charging time setting (EQT)



Figure 1-48 Equalization charging time setting page

Function description: Equalization charging time setting

Setting conditions: Can be set in all states

Explanation:

EQT: Equalization Time

During the equalization phase, the controller will charge the cells as much as possible until the cell voltage rises to the cell equalization voltage. Then use constant voltage regulation to maintain the battery voltage to maintain the battery balance voltage. The cells will remain in the equalization phase until the set cell equalization time is reached. The default setting is 60 minutes, the settable range is [5,900], and the increment is 5 minutes each time.

5.3.32 Equalization Delay Time Settings (EQO)



Figure 1-49 Equalization Delay Time Settings Page

Function description: Equalization Delay Time Settings

Setting conditions: Can be set in all states

Explanation:

EQT: Equalization Time out In the equalization stage, when the cell equalization time expires and the cell voltage does not rise to the cell equalization voltage point, the charge controller will extend the cell equalization time until the cell voltage reaches the cell equalization voltage. When the battery balancing delay setting ends, the battery voltage is still lower than the battery balancing voltage, the charge controller will stop balancing and return to the floating charge stage. The default setting is 120 minutes, the settable range is (5,900), and the increment is 5 minutes each time.

5.3.33 Equalization interval setting (EQI)




Figure 1-50 Equalization interval setting

Function description: Equalization interval setting

Setting conditions: Can be set in all states

Explanation:

EQI: Equalization interval

When the battery connection is detected during the float phase with the equalization mode turned on, the controller will start to enter the equalization phase when the set equalization interval (cell equalization period) is reached.

The default setting is 30 days, the settable range is [1,90], and the increment of each setting is 1 day

5.3.34 Turn on equalization settings immediately



Figure 1-51 Turn on equalization settings immediately

Function description: Turn on equalization settings immediately

Setting conditions: Can be set in all states

Explanation:

EQN: Equalization Now

The default setting is OFF, the function is not turned on; when it is set to ON, in the float charging stage when the balance mode is turned on and the battery connection is detected, the balance charging is activated immediately, and the controller will start to enter the balance stage.

5.3.35 Grid-connected inverter function(GTI)




Figure 1-52 The grid-connected inverter function setting page

Function description: Set whether the inverter is connected to the grid in PV priority mains mode or PBG mains mode.

Set conditions: All states of the SSA-HL5K-P1EU can be set, but not for other models

Explanation:

GTI:Grid Tie Invert

The default setting is OFF, and the function is not enabled; When set to ON, the inverter tracks the maximum power point, and the excess energy is fed into the mains.After the function is turned on, if a communication abnormality occurs, an alarm 56 is generated and the inverter no longer determines the operation logic according to the BMS information.

5.3.36 Battery Dual Output Low Voltage Shutdown Point(DBV)




Figure 1-53 Battery dual output low voltage shutdown point page

Function description: When enabled, the secondary output of the inverter is enabled by default After entering the battery mode, when the battery voltage is lower than the set point, the secondary output is turned off When the battery voltage is higher than the set value + 1V/cell again, the secondary output is turned on.

Setting conditions: All states can be set.

Explanation: **DBV:** Dual output battery mode cut-off voltage

The default setting of SSA-HL3K6-P1EU is 24V, and the setting range is [22,32]

The default setting of SSA-HL5K-P1EU is 48V, and the setting range is [44,60]

When the set point is higher than the constant voltage charging (CV) point- 1V/cell, the constant voltage charging point is used as the recovery voltage.

*This function needs to be used in conjunction with the dual output auxiliary board.

5.3.37 Battery Dual Output Duration (DBT)



Figure 1-54 Battery dual output low voltage shutdown point page

Function description: When enabled, the secondary output of the inverter is enabled by default After entering the battery mode, when the battery discharge time reaches the set point, the secondary output will be turned off.

Setting conditions: all states can be set.

Explanation:**DBT:**Dual output battery mode cut-off time

The default setting is OFF, the function is not enabled, the setting range is [5,890], and the unit is minute When it is set to FUL, the output time of the secondary output is not limited.

This function needs to be used in conjunction with the dual output auxiliary board.

5.3.38 BMS communication function (BMS)




Figure 1-55 BMS management function setting page

Function description: Set whether the inverter communicates with the lithium battery BMS

Setting conditions:All states can be set. **Explanation:** **BMS:**Battery Manage System

The default setting is OFF, and the function is not enabled; when it is set to ON, the inverter communicates with the lithium battery BMS through the central control board and obtains battery information.After the function is enabled, if a communication abnormality occurs, an alarm 56 will be generated.and the inverter will no longer determine the operation logic based on the BMS information.

The SSA-HL3K6-P1EU can be selected from four protocols: "VOL 485", "GRO 485", "PYL 485+PYL CAN", "IRO 485".This feature needs to be used in conjunction with a central control board.

5.3.39 Low SOC shutdown function (SBU)



Figure 1-56 Low SOC shutdown function setting page

Function description: Set the inverter to shut down when the SOC is low

Setting conditions: All states can be set.**Explanation:**

BSU:Battery SOC (capacity) under lock

The default setting is 20, and the settable range is [5,50]. In battery mode, when the SOC of the lithium battery reaches the set value, it will shut down and alarm 68 will be issued at the same time, and the alarm 68 will be cleared when it returns to the set value + 5%. When in standby mode, it will switch to battery mode only when it reaches the set value + 10%, and it will alarm 69 if it is not reached. After the function is turned on, when the SOC of the lithium battery reaches the set value + 5%, the alarm 69 will be issued, and the alarm 69 will be cleared when it returns to the set value + 10%.

It can be set to OFF,At this time, the inverter will no longer perform shutdown, startup, and alarm operations according to the SOC situation.

After the function is enabled if a communication abnormality occurs. the inverter no longer determines the operation logic based on the SOC information, and clears the relevant alarm.

5.3 .40 High SOC to battery function (STB)



Figure 1-57 Low SOC to mains function setting page

Function description: Set the SOC value of the inverter to battery mode

Setting conditions: All states can be set. Explanation:

STB: Battery SOC turn to battery mode.

The default setting is 95, and the settable range is [10,100]. PBG priority mains normal mains modes switch to battery mode when the lithium battery SOC reaches the set value. After it is turned on, the inverter will switch to battery mode only when the SOC is higher than the set point and the battery voltage is higher than the voltage point for switching back to battery mode. It can be set to OFF. At this time, the inverter will no longer switch from mains mode to battery mode according to the SOC.

After the function is enabled, if a communication abnormality occurs, the inverter no longer determines the operation logic based on the SOC information, and clears the relevant alarm.

5.3.41 Low SOC transfer function (STG)



Figure 1-58 Low SOC to mains function setting page

Function description: Set the SOC value of the inverter to the mains mode.

Setting conditions: All states can be set.

Explanation: STG: Battery SOC turn to grid mode.

The default setting is 50, and the settable range is [10,90]. PBG priority Mains normal battery mode Switch to mains mode when the lithium battery SOC reaches the set value. After it is turned on, when the SOC is lower than the set point or the battery voltage is lower than the return-to-mains voltage point, the inverter will switch to the mains mode. It can be set to OFF. At this time, the inverter will no longer switch from battery mode to mains mode according to the SOC.

After the function is enabled, if a communication abnormality occurs, the inverter no longer determines the operation logic based on the SOC information, and clears the relevant alarm. When this setting is higher than the STB point, STB and STG will not take effect after the next time they take effect.

5.4 Battery Equalization Description

Equalization function is added into charge controller. It reverses the buildup of negative chemical effects like stratification, a condition where acid concentration is greater at the bottom of the battery than at the top. Equalization also helps to remove sulfate crystals that might have built up on the plates. If left unchecked, this condition, called sulfation, will reduce the overall capacity of the battery. Therefore, it's recommended to equalize battery periodically.


* How to Apply Equalization Function

You must enable battery equalization function in monitoring LCD setting program 30 first. Then, you may apply this function in device by either one of following methods:

1. Setting equalization interval in program 35.
2. Active equalization immediately in program 36


* When to Equalize

In stage, when the setting equalization interval (battery equalization cycle) is arrived, or equalization is active immediately, the controller will start to enter Equalize stage.




* Equalize charging time and timeout

In Equalize stage, the controller will supply power to charge battery as much as possible until battery voltage rises to battery equalization voltage. Then, constant-voltage regulation is applied to maintain battery voltage at the battery equalization voltage. The battery will remain in the Equalize stage until setting battery equalized time is arrived.



However, in Equalize stage, when battery equalized time is expired and battery voltage doesn't rise to battery equalization voltage point, the charge controller will extend the battery equalized time until battery voltage achieves battery equalization voltage. If battery voltage is still lower than battery equalization voltage when battery equalized timeout setting is over, the charge controller will stop equalization and return to float stage



5.5 Fault and Alarm Description



Function description: The alarm code ALA flashes and the buzzer beeps once for 1s and stops after 1 minute. The fault indicator code is always on, the buzzer beeps for 10 seconds and then stops. After the fault is stopped and the fault is eliminated, Then try to restart the inverter, If the restart fails for six times, it will continue to be in the fault state. The fault and alarm LCD display is as shown in the figure above, the fault icon in the fault mode is always on, and the alarm icon in the alarm state flashes. Kindly contact the manufacturer to eliminate the abnormal condition according to the fault information.

5.5.1 Faults Descriptions

Fault: The inverter enters the fault mode, the red LED light is always on and the LCD displays the fault code.

Fault Code Descriptions

| Fault code | English meaning | Recovering conditions | Alarm warning |
|------------|-------------------------|--|---------------|
| 1 | Bus soft start fail | Unrecoverable | Fault |
| 2 | Bus high | Unrecoverable | Fault |
| 3 | Bus low | Unrecoverable | Fault |
| 4 | Battery Over Current | Unrecoverable | Fault |
| 5 | Over temperature | Unrecoverable | Fault |
| 6 | Battery high | Recoverable | Fault |
| 7 | Bus soft Fault | Unrecoverable | Fault |
| 8 | Bus short Fault | Unrecoverable | Fault |
| 9 | INV soft Fault | Unrecoverable | Fault |
| 10 | INV over voltage | Unrecoverable | Fault |
| 11 | INV under voltage | Unrecoverable | Fault |
| 12 | INV short circuit | Unrecoverable | Fault |
| 13 | Negative power | Unrecoverable | Fault |
| 14 | Overload fault | Unrecoverable | Fault |
| 15 | Model Fault | Unrecoverable | Fault |
| 16 | No boot loader | Unrecoverable | Fault |
| 17 | Panel Flash Fault | Recoverable after Flash | Fault |
| 19 | Same Serial | Unrecoverable | Fault |
| 20 | CAN Fault | Unrecoverable | Fault |
| 21 | BAT Volt Different | Unrecoverable | Fault |
| 22 | Line Volt Different | Unrecoverable | Fault |
| 23 | Line Freq Different | Unrecoverable | Fault |
| 24 | Output Config Different | Recover when set to stand-alone operation or meet the three-phase operation setting conditions | Fault |
| 25 | Output Syn Loss | Unrecoverable | Fault |
| 26 | BMS Fault | Close the BMS communication function, or BMS failure recovery | Fault |
| 28 | NTC Fault | Unrecoverable | Fault |
| 29 | INV over Current | Unrecoverable | Fault |

5.5.2 Warning Descriptions

* Alarm: The Red LED flashes, and the LCD displays an alarm code, the inverter does not enter the failure mode.

Alarm code descriptions

| Code | English meaning | Inverter action | Recovering conditions | Warning |
|------|---|--|---|---------|
| 50 | Battery not connected | Alarm, no charging | Battery voltage 10V*N | Alarm |
| 51 | Low battery shutdown | Alarm, battery low voltage shutdown or unable to boot | Auto-restart when battery voltage more than $(10V+0.2V)*N$, N for numbers of battery serial group. | Alarm |
| 52 | Battery low | Warning, battery not charging | Recoverable (action point + 0.2v/piece) | Alarm |
| 53 | Battery charge short | Alarm, low battery shutdown or no engine startup | Unrecoverable | Alarm |
| 54 | Low watt discharge | Warning | Recoverable (battery voltage higher than 13.2V/cell) | Alarm |
| 55 | Over charge | Alarm, no charging | Recoverable | Alarm |
| 56 | BMS Loss | Alarm, lock standby mode | Recoverable | Alarm |
| 57 | Over temperature | Alarm, no charging | The temperature sensor of PFC or INV is lower than setpoint | Alarm |
| 58 | Fan lock | Alarm, If one fan fails, the other fan rotates at full speed | Recoverable | Alarm |
| 59 | EEPROM fail | Alarm | Unrecoverable | Alarm |
| 60 | Overload warning | Alarm | Reduce the load lower than 97% | Alarm |
| 61 | Abnormal generator waveform | Alarm, keep working in battery mode | Recoverable | Alarm |
| 62 | Weak energy from PV (For 5KVA high PV voltage type) | Turn off the PV output and charging | Recover after 10 mins | Alarm |
| 63 | Synchronization signal fail | Alarm, switch to failure mode | Switch to stand-alone mode recovery Disconnect Troubleshooting Recovery | Alarm |
| 64 | Parallel configuration incompatible | Alarm, switch to standby mode | Resume when three-phase setting is correct | Alarm |

| Code | English meaning | Inverter action | Recovering conditions | Warning |
|------|-------------------------------|---|---|---------|
| 65 | Parallel version incompatible | Alarm, switch to standby mode | Restore when all machine versions in a parallel system are compatible with each other | Alarm |
| 66 | Parallel Communication Fault | Alarm, switch to standby mode | In the parallel system, it is detected that the slave machine is connected and then recovered, and it is set to stand-alone mode to recover | Alarm |
| 67 | Parallel Line Differ | Warning | Recover when it detects that the mains voltage and frequency errors of each machine are reasonable | Alarm |
| 68 | SOC Under | Alarm, switch to standby mode | Turn off the low SOC shutdown function, or turn off the BMS communication function. | Alarm |
| 69 | SOC Low | Alarm, if it is in standby mode, it will remain in standby mode and not turn on | Turn off the low SOC shutdown function, or turn off the BMS communication function. | Alarm |
| 70 | Battery Terminal Source Fail | Alarm, Turn to standby mode | The battery is connected, or the battery terminal voltage is higher than the set value for 1 minute | Alarm |

6 Trouble Shooting

| Problem | LCD/LED/Buzzer | Explanation Possible cause | What to do |
|---|---|--|---|
| Unit shuts down automatically during startup process | LCD/LEDs and buzzer will be active for 3 seconds and then complete off. | The battery voltage is too low (<1.91v/Cell) | Recharge battery Replace battery |
| No response after power on. | No indication | The battery voltage is far too low. (<1.4V/Cell) Internal fuse tripped. | 1. Contact repair center for replacing the fuse. 2. Recharge battery 3. Replace battery |
| | Input voltage is displayed as on the LCD and green LED is flashing | Input protector is tripped | Check if AC breaker is tripped and AC wiring is connected well. |
| Mains exist but the unit works in battery mode. | Green LED is flashing | Insufficient quality of AC power. (Shore or Generator) | 1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied) is working well or if input voltage range setting is correct. (UPS to Appliance) |
| | Green LED is flashing | Set" SBU "as the priority of output source | Change output source priority to Utility first. |
| When the unit is turned on, internal relay is switched on and off repeatedly. | LCD display and LEDs are flashing | Battery is disconnected | Check if battery wires are connected well. |

7. Technical Data sheet

| Model | SSA-HL3K6-P1EU | SSA-HL5K-P1EU |
|-------------------|--|---|
| Product Type | Off-grid Single Phase Hybrid Inverter | |
| Battery | Battery Type | lithium /Lead-acid |
| | Voltage (range) | 21-30.2 d.c.V |
| | Nominal battery voltage | 24 d.c.V |
| | Charge Current (maximum continuous) | 100 d.c.A |
| PV Input | MAX.PV Input Power | 5000W |
| | MPPT Tracking Range | 40-450Vd.c. |
| | Best voltage | 300-340Vd.c. |
| | Vmax PV (absolute maximum) | 500 d.c.V |
| | Maximum operating PV input current | 18 d.c.A |
| | Isc PV (absolute maximum) | 22 d.c.A |
| | Max. inverter back feed current to the array | / |
| AC Input | Voltage (nominal) | 220/230 a.c.V |
| | Current (maximum continuous) | 20 a.c.A |
| | Frequency (nominal) | 50/60 Hz |
| AC Output | Voltage (nominal) | 220/230 a.c.V |
| | Current(maximum continuous) | 15.6 a.c.A |
| | Frequency (nominal) | 50/60 Hz |
| | Power(maximum continuous) | 3600 VA |
| | Power factor | 1 |
| | Maximum output overcurrent protection | 1min@102%~110% Load 10s@110%~130% Load 3s@130%~150% Load 0.2s@>150% Load |
| General Parameter | Operating Temperature | -10 - +50°C (output power linely derating when exceed +50°C) |
| | Humidity | 20%-95%(Non-condensing) |
| | Storage Temperature | -15 - 60°C |
| | Altitude | Not Over 1000m, Derating over 2000m, Max 4000m. Refer to IEC62040 |
| | Noise | ≤50dBA |

| Model | SSA-HL3K6-P1EU | SSA-HL5K-P1EU |
|---------------------------|-----------------------|---|
| Display and communication | LCD Display | Display Running Mode/Loads/Input/Output etc. |
| | RS232 Communication | Baud Rate 2400 (9600 for 3K6) |
| | Port Parallel Connect | Lithium Battery BMS Communication Card. Dry Contact |
| | Interface Operating | Without Parallel Connect With Parallel |

Appendix:Parallel Operation Guide

1. Parallel operation

Note:


Before paralleling, each machine needs to calibrate the inverter output voltage, DC component, and battery voltage. In theory, The more accurate the calibration, the better, but at least meet the inverter output voltage and battery voltage calibration deviation within ±0.3V, DC component calibration within ±50 mV.

The shutdown state, that is, the standby state, refers to the state in which the inverter has no output, but the LCD screen is on.


The method of entering standby state: when the switch is closed, quickly turn on and then immediately (1 second) turn off, then the inverter enters the standby state.

1.1 Single-phase parallel operation

Two inverters in parallel
System Connection




Communication Connection




1.1.1 Three inverters in parallel

System Connection



Communication Connection




Multiple single-phase parallel systems can follow the extended wiring method of 2 single-phase parallels to three single-phase parallels


1.2 Three-phase parallel operation

1.2.1 One inverter per phase:

System Connection




Communication Connection




1.2.2 Two inverters for the first phase, only one inverter for the remaining phases:

System Connection




Communication Connection




1.2.3 Two inverters for the first and second phases, and one inverter for the third phase:

System Connection




Communication Connection




1.2.4 Three inverters for the first phase, only one inverter for the other two phases:


System Connection




Communication Connection




1.2.5 Two inverters per phase: System Connection




Communication Connection




1.2.6 Three inverters for the first phase, two inverters for the second phase, and one inverter for the third phase: System Connection




Communication Connection



1.2.7 Four inverters for the first phase and one inverter for the other two phases: System Connection



Communication Connection




2. Connection Precautions

2.1 PV connection/Solar Panel Connection

Each inverter is connected to the solar panel separately, and the PVs of each inverter cannot be wired in parallel.

2.2 Parallel board connection

Note: In each set of parallel systems, select the two sets of machines with the farthest distance and short-circuit the positions A of the parallel board with jumper caps.



3. LCD Setup and Display

For the parallel setting operation, refer to the main manual - function setting operation, item 27 parallel mode setting.


3.1 Single-phase parallel

Step 1: Before commissioning, please check the following requirements: Is the wiring correct?

Make sure all circuit breakers in the load side line are open And each neutral line (N line) of the inverter is connected together, and the live line (L line) at the load side should also be connected together.

Step 2: Go into Inverter setting mode and set "PAR" in program 27 on the LCD. Then turn off all inverters.

Note: When setting on the LCD, the power-on switch must be turned off. Otherwise, settings cannot be made.




Notice: Automatic identification of primary and secondary inverters in the system


Step 3: Close the AC circuit breakers of all lines in the AC input, keep the rocker switch not closed, and wake up the parallel system. There are instructions on the next page of P9 on the LCD display interface. It is best to have all inverters connected to mains at the same time. If not, it will show fault 23 or 22.

Step 4: If there are no more fault alarms and the indicating interface is normal, the parallel system is fully installed.


Step 5: Close the circuit breaker on the load side. Turn on the system and start supplying power to the load.



The parallel setting is successful, the communication is successful interface.



The parallel setting is successful, but the communication failure interface



Parallel setting failure interface

3.2 Parallel as three-phase system


Step 1: Before commissioning, please check the following requirements: Is the wiring correct?

Make sure that all circuit breakers on the load side are disconnected, and the neutral wires (N/neutral) of each inverter are connected together, the live wires (L wires) on the load side of the same phase are connected together, and the different phases are connected together. The live wires (L wires) are not connected together. Confirm that the output inverter voltage of each machine, the DC component and the battery voltage are all successfully calibrated.

Step 2: Wake up the inverter to put it into shutdown state, then use program 27 on the LCD to configure each Inverter as 3P1, 3P2, 3P3 in turn.

When using the LCD for program setting, the power-on switch must be turned off.


Otherwise, settings cannot be made.



Step 3: Turn on the AC circuit breakers for all lines in the AC input. If an AC connection is detected and matches the device settings, the system is working properly. Otherwise, The system will display an alarm or fault, and will not operate in mains mode.

Step 4: Close the AC circuit breakers of all lines in the AC input, keep the rocker switch not closed, and wake up the parallel system. There are instructions on the next page of P9 on the LCD display interface, which means three-phase power supply System installation is complete.

Step 5: Please close the circuit breakers of all power lines on the load side, close the rocker switch, and the system will start supplying power to the load.



The parallel setting is successful, the communication is successful interface.

The parallel setting is successful, but the communication failure interface

Parallel setting failure interface

Note 1: To avoid overloading, it is best to let the whole system operate normally before closing the circuit breaker on the load side.

Note 2: There is a switching time for this power supply system. Power outages may occur for critical equipment with high power requirements.

Note 3: The right to interpret the manual belongs to the company, and the product is upgraded and updated without prior notice.