


User Manual

Hybrid Inverter SSE-HL8-15K-P2SA-S Series



SSE-HL8K-P2SA-S
SSE-HL10K-P2SA-S
SSE-HL12K-P2SA-S
SSE-HL15K-P2SA-S

Please read this manual before use and follow its guidance.
Keep this manual for future reference.

Content

| | |
|---|----|
| 1.About This Manual | 1 |
| 1.1 Applicable Model | 1 |
| 1.2 Target Group | 1 |
| 1.3 Symbol Definition | 1 |
| 1.4 Updates | 1 |
| 2. Safety Precaution | 2 |
| 2.1 General Safety | 2 |
| 2.2 PV String Safety | 2 |
| 2.3 Inverter Safety | 3 |
| 2.4 Battery Safety | 4 |
| 2.5 Personal Requirements | 4 |
| 3. Product Introduction | 4 |
| 3.1 Product Features | 4 |
| 3.2 Working Mode | 7 |
| 3.3 Appearance | 8 |
| 4. Check and Storage | 13 |
| 4.1 Check Before Receiving | 13 |
| 4.2 What's in the box? | 13 |
| 4.3 Storage | 13 |
| 5. Installation | 14 |
| 5.1 Installation Requirements | 14 |
| 5.2 Inverter Installation | 17 |
| 6. Electrical Connection | 18 |
| 6.1 Safety Precaution | 18 |
| 6.2 Connection Requirements | 19 |
| 6.3 System Integration | 20 |
| 6.4 PE Cable Connection | 22 |
| 6.5 PV Connection | 23 |
| 6.6 Battery Connection | 24 |
| 6.7 Grid& EPS Load Connection | 27 |
| 6.8 Use a Generator | 31 |
| 6.9 System Parallel Operation | 34 |
| 7.Operating Modes and Functions | 40 |
| 7.1 Operate the inverter and conduct a test | 40 |
| 7.2 Operating Modes and Functions | 41 |
| 7.3 Generator Function | 45 |
| 7.4 Smart Load Function | 46 |
| 7.5 Off-Grid Installation Tips | 46 |
| 7.6 Battery Charge Controller | 47 |
| 8. Wi-Fi&BLE stick installation | 48 |
| 8.1 Indication | 48 |
| 8.2 Install the Wi-Fi&BLE stick | 48 |
| 8.3 Web/APP | 49 |
| 8.4 Wi-Fi Connection | 49 |
| 8.5 LED indication and trouble shooting | 53 |
| 9.Operation | 54 |
| 9.1 Indicator panel | 54 |
| 9.2 LCD operation flow chart | 55 |
| 9.3 LCD Display Icons | 56 |
| 9.4 System Setup Menu | 58 |
| 9.5 Basic Settings Menu | 59 |
| 9.6 Work Mode Settings Menu | 60 |

| | |
|---|----|
| 9.7 Battery Settings Menu | 62 |
| 9.8 Grid Settings Menu | 63 |
| 9.9 Generator Port Settings Menu | 67 |
| 9.10 Advanced Settings Menu | 69 |
| 9.11 Record Menu | 71 |
| 9.12 Device Info Setup Menu | 72 |
| 9.13 Factory Setting Menu | 73 |
| 10.Trouble Shooting | 74 |
| 11.Maintenance | 79 |
| 11.1 Power ON the Inverter for first time | 79 |
| 11.2 Power Off the Inverter | 79 |
| 11.3 Removing the Inverter | 79 |
| 11.4 Disposing of the Inverter | 80 |
| 12 Appendix | 80 |
| 12.1 Routine Maintenance | 80 |
| 12.2 Limited Warranty | 80 |

READ THE INSTRUCTIONS COMPLETELY BEFORE OPERATING THE EQUIPMENT

Check the utility voltage before turning ON the unit.

Verify the inviter's programmed grid type before connecting to the utility.

The unit will be programmed in 120/240V Split-Phase at 60Hz by default.

Disregarding these instructions could result in permanent damages to the unit



DISCLAIMER

UNLESS SPECIFICALLY AGREED TO IN WRITING:

We assume no responsibility or liability for any damages, property loss, personal injury, or any adverse consequences resulting from improper use and installation of the product or the failure to adhere to the guidelines provided in this document. Users are expressly advised to follow the instructions and guidelines outlined in the documentation accompanying the product. We shall not be liable for any damages or losses incurred due to deviations from recommended usage, installation, or maintenance procedures. By using the product, users acknowledge their understanding of these disclaimers and agree to use the product at their own risk. We reserve the right to update or modify product information, specifications, and guidelines without prior notice.

We retain the right to final interpretation of this document and all related materials pertaining to this product. This document is subject to modifications, updates, revisions, or termination without prior notice. For the latest product information, please visit <https://www.soseninverter.com/>.

1.About This Manual

This manual describes the product information, installation, electrical connection, commissioning, troubleshooting, and maintenance. Read through this manual before installing and operating the product. All the installers and users have to be familiar with the product features, functions, and safety precautions. This manual is subject to update without notice. For more product details and latest documents, visit <https://www.soseninverter.com/>.

1.1 Applicable Model





| Model | Nominal Output Power | Nominal Output Voltage |
|------------------|----------------------|--|
| SSE-HL8K-P2SA-S | 8kW | 120Vac / 240Vac (Split phase) ; 208Vac (2/3 phase) 2L/N/PE |
| SSE-HL10K-P2SA-S | 10kW | |
| SSE-HL12K-P2SA-S | 12kW | |
| SSE-HL15K-P2SA-S | 15kW | |

1.2 Target Group

This manual is intended for qualified and knowledgeable electrical technical personnel who are responsible for hybrid inverter installation and commissioning in the energy storage system and electric system.

1.3 Symbol Definition

The following types of safety instructions and general information appear in this document as described below:

|  DANGER |  WARNING |  CAUTION |  NOTICE |
|--|--|--|---|
| “Danger” indicates a hazardous situation with a high level of risk that, if not avoided, will result in death or serious injury. | “Warning” indicates a hazardous situation with a medium level of risk that, if not avoided, could result in death or serious injury. | “Caution” indicates a hazardous situation with a low level of risk that, if not avoided, could result in minor or moderate injury. | “Notice” provides some tips and methods to solve product-related problems to save time. |

1.4 Updates

The latest document contains all the updates made in earlier issues.

- V1.0 2025-9-1 • First Issue
- V1.1 2026-3-23 • Second Issue

2. Safety Precaution

Please strictly follow these safety instructions in the user manual during the operation.

2.1 General Safety

NOTICE

- The information in this user manual is subject to change due to product updates or other reasons. This guide cannot replace the product labels or the safety precautions in the user manual unless otherwise specified. All descriptions here are for guidance only.
- Before installations, read through the quick installation guide. For additional information, please see the user manual.
- All installations should be performed by trained and knowledgeable technicians who are familiar with local standards and safety regulations.
- Use insulating tools and wear personal protective equipment when operating the equipment to ensure personal safety. Wear anti-static gloves, cloths, and wrist strips when touching electron devices to protect the inverter from damage.
- Strictly follow the installation, operation, and configuration instructions in this manual. The manufacturer shall not be liable for equipment damage or personal injury if you do not follow the instructions. For more warranty details, please visit <https://www.soseninverter.com/>.

2.2 PV String Safety

DANGER

Connect the DC cables using the delivered PV connectors. The manufacturer shall not be liable for the equipment damage if other connectors or terminals are used.










WARNING

- Ensure the component frames and the bracket system are securely grounded.
- Ensure the DC cables are connected tightly, securely, and correctly.
- Measure the DC cables with a multimeter to avoid reverse polarity connection. Also, the voltage should be under the permissible range.
- Do not connect one PV string to more than one inverter at the same time. Otherwise, it may cause damage to the inverter.
- The PV modules used with the inverter must have an IEC61730 class A rating.
- When the photovoltaic array is exposed to light, it supplies a d.c. voltage to the inverter.

2.3 Inverter Safety

⚠ WARNING

- The voltage and frequency at the connecting point should meet the on-grid requirements.
- Additional protective devices like circuit breakers or fuses are recommended on the AC side. Specification of the protective device should be at least 1.25 times the AC rated output current.
- Make sure that all the groundings are tightly connected. When there are multiple inverters, make sure that all the grounding points on the enclosures are equip Potential bonding.
- Off-grid function is not recommended if the PV system is not configured with batteries. Otherwise, the risk in system power usage is beyond the equipment manufacturer's warranty scope.
- It should be taken into account the characteristics of photovoltaic power instability, if the battery is not connected, there is no EPS function.
- DO NOT connect the grid to the "LOAD" output terminal.

| ⚠ DANGER | | | |
|--|---|---|--|
| <ul style="list-style-type: none"> • All labels and warning marks should be visible after the installation. Do not cover, scrawl, or damage any label on the equipment. • Warning labels on the inverter are as follows: | | | |
|  | DANGER High voltage hazard. Disconnect all incoming power and turn off the product before working on it. |  | Delayed discharge. Wait 5 minutes after power off until the components are completely discharged. |
|  | Read through the user manual before working on this device. |  | Potential risks exist. Wear proper PPE before any operations. |
|  | High-temperature hazard. Do not touch the product under operation to avoid being burnt. |  | Grounding point. |
|  | With CE mark & the inverter fulfills the basic requirements of the guideline governing Low-Voltage and electromagnetic compatibility. |  | Do not dispose of the inverter as household waste. Discard the product in compliance with local laws and regulations, or send it back to the manufacturer. |
|  | RCM marking | | |

2.4 Battery Safety

WARNING

- The battery used with the inverter shall be approved by the inverter manufacturer. The approved battery list can be obtained through the official website.
- Before installations, read through the corresponding battery's User Manual to learn about the product and the precautions. Strictly follow its requirements.
- If the battery discharged completely, please charge it in strict accordance with the corresponding model's User Manual.
- Factors such as: temperature, humidity, weather conditions, etc. may limit the battery's current and affect its load.
- Contact after-sale service immediately if the battery is not able to be started. Otherwise, the battery might be damaged permanently.
- Use the multimeter to measure the DC cable to avoid reverse polarity connection. Also, the voltage should be under the permissible range.
- Do not connect one battery group to several inverters at the same time. Otherwise, it may cause damage to the inverter.
- Lead-acid battery types—including but not limited to Flooded Lead Acid (FLA), Gel, and Absorbent Glass Mat (AGM) batteries—typically require specific charging methods and may perform optimally only under certain operating conditions. The inverter may not fully support these requirements by default, and adjustments to its charging and discharging parameters may be necessary.
- If you intend to use any of these battery types, it is strongly recommended to consult the battery manufacturer for guidance on best practices, compatibility, and overall system sizing specific to your application.

2.5 Personal Requirements

NOTICE

- Personnel who install or maintain the equipment must be strictly trained, learn about safety precautions and correct operations.
- Only qualified professionals or trained personnel are allowed to install, operate, maintain, and replace the equipment or parts.

3. Product Introduction


3.1 Product Features

Intended usage


This is a multifunctional inverter, combining functions of inverter, solar charger and battery charger to offer uninterrupted power support with portable size. The inverter is equipped with a powerful APP. Users can view the operating status of the inverter in real time through the APP, including but not limited to battery information, photovoltaic power generation information, alarm information, etc. The brief operation interface makes it easier to set the appropriate working mode in different application scenarios to meet the diversified needs of users.

This unit and its associated system are suitable for the following applications:


A: Solar and battery storage system




B: AC Coupling with existed solar system




C: On-grid solar system without battery (Support EPS even without battery)




D: off-grid and back-up applications



E: Single and three phase paralleling system



F: Energy storage system with peak shaving Function




Model

This manual applies to the listed inverters below:

SSE-HL8K-P2SA-S SSE-HL10K-P2SA-S SSE-HL12K-P2SA-S SSE-HL15K-P2SA-S

Model description



Series Code:

SN: SXXXXXXXX2401100001

Series Code description

| No. | Referring to | Code | Description |
|-----|--------------------------|----------|-------------------------|
| 1 | Brand name | S | SOSEN |
| 2 | Product category | XXXXXXXX | Inverter model ID |
| 3 | Production date | 24 | The year of production |
| 4 | Production date | 01 | The month of production |
| 5 | Production date | 11 | The day of production |
| 6 | Production serial number | 00001 | |

3.2 Working Mode

The SSE-HL8-15K-P2SA-S Series hybrid inverter has the following work modes based on your configuration and layout conditions.

| Work modes | Description |
|--------------------------------|--|
| Self Use (with PV Power) | Priority: load>battery>grid The energy produced by the PV system is used to optimize self-consumption. The excess energy is used to charge the batteries, then exported to grid. |
| Self Use (without PV Power) | Priority: load>battery When no PV supplied, battery will discharge for local loads firstly, and grid will supply power when the battery capacity is not enough. |
| TOU ¹ Eco | This mode can be used to meet users' demand for peak cutting and valley filling and achieve maximum economic benefit in areas with large difference of peak and valley electricity price. Peak price: The battery is discharged at full power to sells electricity to the grid at a high price Flat price: Run spontaneous self-use mode. Valley price: Buy electricity from the grid at a low price to charge the battery at full power |
| Back up only | Priority: load>battery When entering this mode, the system will start to charge the battery until it is fully charged and remains fully charged, waiting for the power grid to fail. When the grid is off, system will supply emergency power from PV or battery to supply the home loads . |
| Grid Priority | Priority: load>grid When the system works in this mode, the electricity generated by the photovoltaic will be preferentially connected to the grid. Users can send requests to the grid at peak times, and in this mode, users can set the end of the battery SOC point. |

1.TOU means time of use.




Make sure the load powering rating in within the EPS's output rating. Or the inverter will shut down with an 'over load' warning. When an “over load” is appeared, adjust the load power make sure it is with the range of the EPS output, and turn the inverter on. For the nonlinear load, please pay attention to the inrush power make sure it is within the range of the EPS output.

3.3 Appearance

3.3.1 Dimensions


Considering the dimensions of the inverter, find a suitable location for the system. The upper, lower and left and right sides of the inverter must leave a suitable distance to ensure heat dissipation.



PROTECT THE LCD SCREEN from direct exposure to UV light.

The SSE-HL8-15K-P2SA-S is a IP66 enclosure that is rated for outdoor installation but can also be installed indoors.





3.3.2 General Description



| Component | Name | Component | Name |
|-----------|---|-----------|-------------------|
| A | PV DC disconnect | J | Wi-Fi |
| B | LCD Screen | K | ON/OFF Button |
| C | BAT Breaker | L | Battery terminals |
| D | Parallel RJ45 ports | M | 3*PV Inputs |
| E | Input pinouts for sensors & accessories | N | Neutral busbar |
| F | BMS RJ45 ports (RS485/CAN) | O | Ground busbar |
| G | Generator Terminals | | |
| H | Load Terminals | | |
| I | Grid Terminals | | |

3.3.3 Nameplate

The nameplate is for reference only.

| | |
|---|---|
|  <h1 style="text-align: center;">Hybrid Inverter</h1> | |
| Model | SSE-HL15K-P2SA-S |
| Max PV input voltage | 550V d.c |
| PV input operating voltage range | 120-520V d.c |
| Max operating PV input current | 26A d.c*3 |
| Isc PV | 39A d.c*3 |
| Grid rated voltage | 120V/240V,208V a.c, 2L+N+PE |
| Grid rated frequency | 60Hz |
| Grid rated input/output current | 62.5A a.c |
| Grid rated input/output apparent power | 15000VA |
| Power Factor | 0.8Leading-0.8Lagging |
| EPS rated output voltage | 120V/240V,208V a.c, 2L+N+PE |
| EPS rated output frequency | 60Hz |
| EPS rated output current | 62.5A a.c |
| EPS rated output apparent power | 15000VA |
| Battery operation voltage range | 40-60V d.c |
| Max.charge and discharge current | 275A d.c |
| Battery type | Li-ion/Lead-acid |
| Ingress protection degree | IP66 |
| Inverter topology | Non-isolated |
| Operating temperature range | -25℃ ~+60℃ (>45℃ derating) |
| Manufacturer: Shenzhen SOSEN Innovation Technology Co.,Ltd | |
| Address: Room 601,Pengzhanhui No 1 Building, Zhongxin Road No 233, Xinqiao Community,Xinqiao Street, Baoan District, Shenzhen, China | |
| SN: | <div style="border: 1px solid black; width: 150px; height: 40px; display: flex; align-items: center; justify-content: center;">   </div> |
|  | <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p style="text-align: center;">Made in China</p> |

3.3.4 Specification

| Model | SSE-HL8K-P2SA-S | SSE-HL10K-P2SA-S | SSE-HL12K-P2SA-S | SSE-HL15K-P2SA-S |
|--|---|------------------|------------------|------------------|
| Product Type | Hybrid Inverter | | | |
| Battery | | | | |
| Battery type | Li-ion/Lead-acid | | | |
| Battery voltage range | 40-60V d.c | | | |
| Rated battery voltage | 51.2V d.c | | | |
| Max.charge/discharge Power | 8 kW | 10 kW | 12 kW | 15 kW |
| Rated charge/discharge current | 167A d.c. | 210A d.c. | 250A d.c. | 275A d.c. |
| Max. charge/discharge current | 167A d.c. | 210A d.c. | 250A d.c. | 275A d.c. |
| Reverse Connect Protection | Yes | | | |
| Communication interface | CAN/RS485 | | | |
| Input (PV) | | | | |
| Recommended Max. PV array power for each input | 12 kW | 15 kW | 18 kW | 22.5 kW |
| Max. operating PV input current (PV 1 /PV 2 / PV3) | 26A d.c+26A d.c+26A d.c | | | |
| Max. Isc PV (PV 1 /PV 2 / PV3) | 39A d.c+39A d.c+39A d.c | | | |
| Vmax PV (Max. PV input voltage) | 550V d.c | | | |
| MPPT Voltage Range | 120-480V dc | | | |
| Full power MPPT voltage range | 120-480V d.c | 125-480V d.c | 145-480V d.c | 195-480V d.c |
| Start-up Voltage | 120V dc | | | |
| Number of MPP Trackers | 3 | | | |
| Strings per MPP Tracker | 2 | | | |
| Number of PV input | 6 | | | |
| Grid AC input and AC output | | | | |
| Grid rated voltage | 120V a.c / 240V a.c (Split phase) , 208V a.c (2/3phase) | | | |
| Grid rated frequency | 50/60Hz | | | |
| Grid rated input active power | 8 kW | 10 kW | 12 kW | 15 kW |
| Grid rated input apparent power | 8 kVA | 10 kVA | 12 kVA | 15 kVA |
| Grid max. input active power | 15 kW | 15 kW | 15 kW | 19.2 kW |
| Grid max. input apparent power | 15 kVA | 15 kVA | 15 kVA | 19.2 kVA |
| Grid rated output active power | 8 kW | 10 kW | 12 kW | 15 kW |
| Grid rated output apparent power | 8 kVA | 10 kVA | 12 kVA | 15 kVA |
| Grid max. output active power | 8 kW | 10 kW | 12 kW | 15 kW |
| Grid max. output apparent power | 8 kVA | 10 kVA | 12 kVA | 15 kVA |
| Grid rated input current | 33.4A a.c | 41.7A a.c | 50A a.c | 62.5A a.c |
| Grid max. input current | 62.5A a.c | 62.5A a.c | 62.5A a.c | 80A a.c |
| Grid rated output current | 33.4A a.c | 41.7A a.c | 50A a.c | 62.5A a.c |
| Grid max. output current | 33.4A ac | 41.7A a.c | 50A a.c | 62.5A a.c |
| Grid power factor | 0.8 leading to 0.8 laggings | | | |
| Grid input and output Inrush current | 250A a.c @ 3μs | | | |
| Max. Grid output fault current | 67A a.c @0.2μs | 84A a.c @0.2μs | 100A a.c @0.2μs | 125 A a.c @0.2μs |
| Max. Grid output overcurrent protection | 240V a.c /80 A a.c | | | |
| Grid input Icc (Rated conditional short-circuit current) | 250A a.c | | | |
| Grid input Icw (Rated short-time withstand current) | 250A a.c | | | |
| Total Harmonic Distortion(THDi, rated power) | <3% | | | |

| EPS output | SSE-HL8K-P2SA-S | SSE-HL10K-P2SA-S | SSE-HL12K-P2SA-S | SSE-HL15K-P2SA-S |
|--|--|------------------|------------------|------------------|
| EPS rated output Voltage | 120V a.c / 240V a.c(Split phase), 208V a.c(2/3phase) | | | |
| EPS rated output frequency | 50/60Hz | | | |
| EPS rated output active power | 8 kW | 10 kW | 12 kW | 15 kW |
| EPS rated output apparent power | 8 kVA | 10 kVA | 12 kVA | 15 kVA |
| EPS max. output active power | 8 kW | 10 kW | 12 kW | 15 kW |
| EPS Max. output apparent power | 8 kVA | 10 kVA | 12 kVA | 15 kVA |
| EPS rate output current | 33.4 A a.c | 41.7 A a.c | 50 A a.c | 62.5 A a.c |
| EPS output power factor | 0.8 leading to 0.8 lagging | | | |
| EPS output peak power | 200% overload(<10s) | | | |
| EPS output Inrush current | 200A a.c @ 10ms | | | |
| EPS max. output fault current | 200A a.c @ 10ms | | | |
| Switch Time | <10ms | | | |
| Total Harmonic Distortion(THDv, linear Load) | <3% | | | |
| Compatible with the Generator | Optional | | | |
| Efficiency | | | | |
| MPPT Efficiency | 99.50% | | | |
| California-efficiency | 96.50% | | | |
| Max.efficiency | 97.50% | | | |
| Standard | | | | |
| Safety | UL1741 IEC62116 IEC61683 | | | |
| EMC | FCC Part15 Class B | | | |
| General Parameter | | | | |
| Degree of ingress protection | IP66 | | | |
| Protection class | I | | | |
| Environment category | Indoor&Outdoor | | | |
| Wet location classification | Yes | | | |
| Pollution degree | PD3 | | | |
| Operating altitude | 4000 m(>2000 Derating) | | | |
| Operating ambient temperature | -25 - +60 °C (linely derating to 60% when exceed +45 to +60 °C) | | | |
| Operating relative Humidity | 0-100% (non-condensing) | | | |
| Storage Temperature | -25- +60 °C | | | |
| Storage relative Humidity | 0-100% (non-condensing) | | | |
| Noise Emission(typical) | <45 db | | | |
| Over voltage Category | AC: III, PV: II | | | |
| Electrical supply system | TN, TT | | | |
| Dimension (WxHxD) | 466*756*242mm | | | |
| Net Weight | 45kg | | | |
| Cooling Mode | Intelligent Air Cooling | | | |
| Topology | Non-isolated | | | |
| Active anti-islanding method | Active frequency drift | | | |
| Communication | RS485/Wifi/Bluetooth/LAN/CAN/DRM/Meter Yes/ Yes/ Opt/Opt/ Yes/ Yes/ Opt | | | |
| LED indicator | LCD+LED+APP | | | |
| Warranty | 5 years | | | |













4. Check and Storage

4.1 Check Before Receiving

Check the following items before receiving the product.

1. Check the outer packing box for damage, such as holes, cracks, deformation, and others signs of equipment damage. Do not unpack the package and contact the supplier as soon as possible if any damage is found.
2. Check the inverter model. If the inverter model is not what you requested, do not unpack the product and contact the supplier.
3. Check the deliverable for correct model, complete contents, and intact appearance. Contact the supplier as soon as possible if any damage is found.

4.2 What's in the box?




| | | | |
|---|---|---|---|
|  <p>Hybrid inverter x1</p> |  <p>Tubular Terminal (20AWG) x10</p> |  <p>Stainless steel anti-collision bolt M12 x4</p> |  <p>communication cable x1</p> |
|  <p>Copper Terminal (1/0 AWG) x4</p> |  <p>Tubular Terminal (10AWG) x12</p> |  <p>User manual x1 Certification x1 Warranty card x1 Quick installation manual x1</p> |  <p>Wi-Fi-Plug x1</p> |
|  <p>Sensor Clamp x 2</p> |  <p>Tubular Terminal (6 AWG) x10</p> |  <p>Positioning Board x 1</p> |  <p>Desiccant 50g x 1</p> |

4.3 Storage

If the equipment is not to be installed or used immediately, please ensure that the storage environment meets the following requirements:

1. Do not unpack the outer package or throw the desiccant away.
2. Store the equipment in a clean place. Make sure the temperature and humidity are appropriate and no condensation.
3. The height and direction of the stacking inverters should follow the instructions on the packing box.

4. The inverters must be stacked with caution to prevent them from falling.
5. If the inverter has been long term stored, it should be checked by professionals before being put into use.
6. The storage temperature range is: -25°C~60°C, and the storage humidity is 0~100%.
7. The box should be suitable for loads more than 250kg.
















5. Installation

5.1 Installation Requirements


Installation Environment Requirements

1. Do not install the equipment in a place near flammable, explosive, or corrosive materials.
2. Do not install the equipment in a place that is easy to touch, especially within children's reach. High temperature exists when the equipment is working. Do not touch the surface to avoid burning.
3. Avoid the water pipes and cables buried in the wall when drilling holes.
4. Install the equipment in a sheltered place to avoid direct sunlight, rain, and snow. Build a sunshade if it is needed.
5. The place to install the equipment shall be well-ventilated for heat radiation and large enough for operations.
6. The equipment with a high ingress protection rating can be installed indoors or outdoors. The temperature and humidity at the installation site should be within the appropriate range.
7. Install the equipment at a height that is convenient for operation and maintenance, electrical connections, and checking indicators and labels.
8. The altitude to install the inverter shall be lower than the maximum working altitude 4000m.
9. The PV modules used with the inverter must have an IEC61730 class A rating.
10. There should be provided an over current protection (such as a breaker rated 250V a.c /80 A a.c) before AC input and after LOAD output, and make sure that the installation position shall not prevent access to the disconnection means.
11. Please ensure that there is adequate ventilation space for the inverter after installation, refer to the installation diagram below.
12. This inverter does not provide an internal isolated transformer between PV input and Battery / AC output circuits, But a basic insulation is provided between PV input / Battery / AC output circuits and metal enclosure / earth, and reinforced / double insulation between PV input / Battery / AC output and communication circuits (DRM / Meter / WiFi/ RS485)
13. The PV input ratings please refer to the specification table of subclause 3.3.5, and please make sure that PV array should not be grounded.
14. Install the equipment away from electromagnetic interference. If there are radio stations or wireless communication equipment below 30 MHz near the installation location, please install the equipment as follows:
 - Add a multi-turn winding ferrite core at the DC input line or AC output line of the inverter, or add a low-pass EMI filter.
 - The distance between the inverter and the wireless EMI equipment is more than 30m.



Installation Angle Requirements

- Install the inverter vertically or at a maximum back tilt of 15 degrees.
- Do not install the inverter upside down, forward tilt, back forward tilt, or horizontally.



Installation Tool Requirements

The following tools are recommended when installing the equipment. Use other auxiliary tools on site if necessary.




5.2 Inverter Installation

5.2.1 Moving the Inverter

CAUTION

•The unit is heavy. Do not lift it alone. During lifting procedures ensure that the unit is firmly secured to avoid the risk of accidental tipping or dropping. Parts serving for support or immobilization of unit shall be designed and manufactured so as to minimize the risk of physical injuries and of accidental loosening of fixing. Ensure that the method of lifting will not allow the unit to slip from chains and slings or turn-over or slide from lifting devices.



transport

- Transportation must be carried by specialized person (truck operators, Hook-up personal), equipped with the necessary protection equipment(overalls, safe shoes, protective gloves, helmets, goggles)
- Do not walk or stand beneath or in the proximity of the load. Avoid sudden movements and jolts when unloading and positioning the unit, Internal handling procedures must be conducted with care.
- Do not exert leverage on the components of the machine. If the unit is not balanced apply ballast, Any protruding parts should not be supported by hand. The inverter should be installed so that the operating panel shall be easily accessible- easy access to the electrical power connection point.
- Accessible for maintenance and repair work. Parts serving for support or immobilization of unit shall be designed and manufactured so as to minimize the risk of physical injuries and accidental loosening of fixings.
- Loading capacity and hardness of the supporting surface, load rating of mounting bracket should be at least four times the weight of the devices according to IEC62109-1. And supporting characteristics will be impaired by wear, corrosion, material fatigue or ageing, This should be calculated by inspection of the design data of supporting material and consulting construction engineer.

5.2.2 Installing Steps

NOTICE

- Use screws or anchors suitable for the support surface and capable of supporting the weight of the inverter.
- Avoid the water pipes and cables buried in the wall when drilling holes.
- Wear goggles and a dust mask to prevent the dust from being inhaled or contacting eyes when drilling holes.
- Make sure the inverter is firmly installed in case of falling down.


Step 1 : Attach the positioning paper to the wall.

Step 2 : Drill holes according to the marked positions on the positioning paper.

Step 3 : Install the expansion bolts.

Step 4 : Hang the inverter onto the expansion bolts.

Step 5: Install the nuts.



6. Electrical Connection

6.1 Safety Precaution

DANGER

- All operations, cables and parts specification during the electrical connection shall be in compliance with local laws and regulations.
- Disconnect the DC switch and the AC output switch of the inverter to power off the inverter at least 5 minutes for the capacitor to be electrically discharged before any electrical connections. Do not work with power on. Otherwise, an electric shock may occur.
- Tie the same type cables together, and place them separately from cables of different types. Do not place the cables entangled or crossed.
- If the cable bears too much tension, the connection may be poor. Reserve a certain length of the cable before connecting it to the inverter cable port.
- When crimping the terminals, ensure that the conductor part of the cable is in full contact with the terminals. Do not crimp the cable jacket with the terminal. Otherwise the inverter may not operate, or its terminal block getting damaged due to heating and other phenomenon because of unreliable connection after operation.

NOTICE

- Wear personal protective equipment like safety shoes, safety gloves, and insulating gloves during electrical connections.
- All electrical connections should be performed by qualified professionals.
- Cable colors in this document are for reference only. The cable specifications shall meet local laws and regulations.


6.2 Connection Requirements

6.2.1 AC / DC Connection Requirements


| Port | Terminal / Breaker Rating | Terminal Wire Size Range (min-max) |
|--------------|---------------------------|------------------------------------|
| GRID | 100A AC(15kW) | 4 AWG |
| LOAD | 100A AC(15kW) | 4 AWG |
| GEN | 90A AC | 6 – 4 AWG |
| MPPT | 27A DC | 12 – 10 AWG |
| Battery Port | 150A DC×2 | 2/0 – 4/0 AWG |

6.2.2 Sensors and Communications Requirements

| Component | Wire Size Range | Max Distance |
|-----------------------------|------------------|---|
| CT Sensor | 16-20 AWG | 0' – 13' [4 m]: 16 AWG included 13' – 20' [6 m]: CAT6 extendable |
| Communications | 24 – 23 AWG | 0' – 100' [30 m]: 24 AWG 100' – 400' [120 m]: 23 AWG |
| RJ45 Parallel Communication | CAT 5E or better | 0' – 7' [2.1 m]: Included 7' – 20' [6m]: Extendable |




CT Sensors (Included)



6.3 System Integration

The system connection diagram is as follows (SA. version):



Single System Installation Guide


For Partial Backup (Essential Loads Only):

Connect the output of the back-feed breaker or line-side tap (depending on your interconnection method) to the “GRID” terminal of the inverter.



Install an external disconnect switch between the point of interconnection and the inverter. The disconnect must be properly sized according to local electrical code.

Connect the “LOAD” terminal of the inverter to the Essential Loads Panel. Select the appropriate wire gauge in compliance with electrical code.

Bottom View of Cable Box Knockouts



Overview of Cable Box




- A. NTC: Connection for temperature sensor of Lead acid battery.
- B. CT Interface: please check Chapter 6.7.4 for Pin definition.
- C. GEN(NO): Connection for generator auto-start function. dry contact signal for startup the diesel generator. When the "GEN signal" is active, the open contact (GS) will switch on (no voltage output).
- D. $\pm 12V$ for RSD : Power supply for RSD PLC transmitter(Max current 500mA).
- E. EPO : Reserved for external EPO.
- F. Meter RS485 :for meter communication.
- G. ATS: 240V output port when inverter is on.
- H. Battery Communication port (CAN&485) : please check Chapter 6.6.2 for Pin definition.
- I. Parallel Communication port (CAN&485) : please check Chapter 6.9.1 for Pin definition.
- J. Parallel CAN matching resistance: Set DIP Switch when use inverters in Parallel.

6.4 PE Cable Connection



- The PE cable connected to the enclosure of the inverter cannot replace the PE cable connected to the AC output port. Both of the two PE cables must be securely connected
- Make sure that all the grounding points on the enclosures are equipotential connected when there are multiple inverters.
- To improve the corrosion resistance of the terminal, it is recommended to apply silica gel or paint on the ground terminal after installing the PE cable.
- Prepare PE cables with the recommended specification:
 - Type: Outdoor single-core copper wire
 - Cross-sectional area: $6\text{mm}^2(10\text{AWG})$



6.5 PV Connection


The photovoltaic connection of this hybrid inverter is the same as that of a traditional grid-tied solar inverter (string inverter).

WARNING

Please double-check the minimum ambient temperature at the installation location. The thermal Voc on the solar panel nameplate is measured at 25°C. As the ambient temperature decreases, the solar panel Voc increases. Ensure that the maximum solar string voltage, corrected for the lowest temperature, does not exceed the inverter's maximum input voltage of 525V.

NOTICE

- The inverter has three MPPTs. For each MPPT, the user can connect two strings of solar panels.
- When the user connects two strings to the same MPPT, ensure that the number of solar panels in each string is the same, and that the installation location and orientation are as consistent as possible. The inverter will automatically limit the total input current of each MPPT to 26A.
- The inverter limits the maximum solar input power to 22.5kW.
- Strings in parallel on the same MPPT must have the same designed open-circuit voltage (Voc), otherwise the system will be limited to the lowest string voltage.
- If the solar panels are oriented in different directions and connected in the same MPPT, there will be a loss in PV efficiency.
- For ground mounted arrays, We recommends installing an auxiliary grounding electrode placed near the array to ensure optimal earth-to-ground resistance of the grounding system. This auxiliary electrode would need to follow the Standard specification.
- Connect the solar panel string using the following configuration:



PV Connection Steps

- a. Strip 1/4-5/16 inch (6-8mm) of insulation from the positive and negative conductors of the PV string.
- b. If the PV string wires are stranded, use wire ferrules.
- c. Insert the conduit connector into the PV connection port.
- d. Pass the photovoltaic conductors through the conduit fittings and insert them into the inverter.
- e. Confirm that the cable connections are correct and secure. Then take appropriate measures to ensure that the conduit and conduit fittings are properly tightened and sealed into the cable hole

6.6 Battery Connection

Battery Connection Guidelines for SSE-HL8-15K-P2SA-S

Important: Ensure the SSE-HL8-15K-P2SA-S inverter is turned OFF before connecting any batteries.

Connect your battery bank according to the appropriate configuration based on the battery voltage (see wiring diagrams below if applicable).

Battery breakers must be OFF during wiring.

If your battery bank does not have built in breakers, take all necessary safety precautions when handling exposed terminals or cables.


The maximum battery charge/discharge current is 275A when both sets of battery terminals are used. If you are using only one set of battery terminals, the charge/discharge current will be limited accordingly.

This inverter is designed for a 48VDC nominal system.


❌ DO NOT connect it to battery configurations outside the 40–60VDC range.

❌ If you are using 12V batteries, you must not exceed 4 batteries in series (i.e., max 48V nominal).


The inverter supports various battery chemistries, provided the voltage remains within 40VDC to 60VDC. Depending on the battery voltage, wire up the battery bank in the possible configurations shown below.




48V batteries in parallel connection



12V batteries in series connection



Series and parallel connections for complete 48V battery bank



DO NOT reverse polarity. The system will be damaged, and warranty voided!

6.6.1 Battery Power Cable Connection

Procedure for connecting battery terminals:

Step 1: Strip 1/4 ~ 5/16 inch (6 ~ 8mm) of insulation from the cable ends and crimp the OT rings.


Step 2: Lay the battery power cables, connecting the positive terminal to BAT+ and the negative terminal to BAT-.

Step 3: Use the reverse nut to secure the conduit fittings to the enclosure.

Step 4: Secure the OT rings of the battery positive and negative cables onto the terminal block according to the markings.

Multi-Terminal Installation

The two battery input terminals of the SSE-HL8-15K-P2SA-Swill parallel batteries internally to ensure a common connection between battery banks and simplify battery installations. If a charge / discharge rate of 275A is needed, the batteries must be connected to both input terminals. If you use 3 or more batteries, use external busbars for (+) and (-) connections.



Multiple inverters in parallel system

Follow all battery manufacturer-specified values to ensure proper charging and discharging.

BATTERY CHARGING SETPOINT EXAMPLES (48V NOMINAL)

| Battery Type | Absorption | Float | Equalize (Every 30 days) |
|--------------|------------|-------|---------------------------|
| AGM | 57.6V | 53.6V | 57.6V |
| Gel | 56.4V | 54.0V | |
| Lithium | 54.6V | 54.3V | - |

CALCULATING BATTERY BANK AMP-HOURS EXAMPLES (AGM)

| # of batteries | Voltage per Battery | Ah per battery | Ah @48V(Chain of 4 batteries of 12V in series) | Max Charge / Discharge (A) |
|----------------|---------------------|----------------|--|----------------------------|
| 4 | 12V | 230Ah | 230Ah | 100A |
| 8 | 12V | 230Ah | 460Ah | 200A |
| 12 | 12V | 230Ah | 690Ah | 275A |
| 16 | 12V | 230Ah | 920Ah | 275A |

Please refer to Chapter **9.7 Battery Settings Menu** for the operation method of the screen.

! WARNING



Reverse polarity will damage the inverter!

Before connecting or disconnecting the battery, ensure that the built-in battery circuit breaker is in the "off"

6.6.2 Battery Communication Cable Connection

When the user selects the lithium-ion battery type, the correct battery communication cable must be used to connect the battery to the inverter. If the lithium battery cannot communicate with the inverter, please select the "lead-acid" type. The inverter's battery communication port is an RJ45 socket, and the pins of the RJ45 connector are as follows. Create the communication cable according to the correct pins of the inverter and the battery communication port. The inverter supports both CAN and RS485 communication.

| Pin | Description |
|-----|-------------|
| 1 | BAT RS485 A |
| 2 | BAT RS485 B |
| 3 | NC |
| 4 | BAT CAN H |
| 5 | BAT CAN L |
| 6 | NC |
| 7 | BAT RS485 B |
| 8 | BAT RS485 A |



! WARNING

- After the battery socket and communication socket are connected, you need to enter the advanced settings in the inverter's app to change the battery type and brand. After selecting the appropriate battery protocol, communication will be established within 1-2 minutes.
- Any damage caused by the improper use of the communication protocols (CANBUS or MODBUS) will not be covered by warranty. Modbus map is available upon request for "READ" operations only. Contact technical support to obtain the MODBUS map.

6.7 Grid & EPS Load Connection

6.7.1 Grid Type and Regulation Selection


This inverter can be used with 120/240V split-phase or 120/208V 2/3 phase systems. If connecting to the grid, ensure that the grid settings are configured correctly. The user can select different grid types and regulations in the advanced settings of the app.

6.7.2 Split-phase Grid and EPS Load Connection

The wiring diagram for 120/240V is shown below: The wiring diagram for the 120/208V 2/3 phase service is largely the same, except it does not support a generator.

When the main panel bus rating meets the NEC705.12(B)(3) requirements, the inverter can be connected to the load side of the service disconnecting device. Otherwise, a line-side connection can be made to avoid the costly upgrade of the main panel.


Grid and EPS Load Connection



6.7.3 AC Cable Connection

Strip 5/16-3/8 inch (8-10mm) of insulation from the cable.

- a. If the cable is stranded, use a cable sheath.
- b. Secure the conduit fitting to the enclosure using the top nut of the fitting.
- c. Secure the grid line and EPS load line onto the terminal block according to the markings.
- d. Fix the conduit onto the conduit fitting.
- e. Check that the cable connections are correct and secure. Take appropriate measures to ensure that the conduit and conduit fittings are properly tightened and sealed into the cable entry hole.





Before supplying power to the EPS load, ensure that the built-in load circuit breaker is in the "ON" position.

6.7.4 CT / Energy Meter Connection

To measure the input and output grid power, a pair of CTs or a three-phase meter must be installed at the service entrance point, either inside or near the main service panel. We standardly supply 2 CTs for one inverter.

CT Interface Pin Definition





Please refer to the wiring diagram to determine the correct placement of the CTs. Attach the two CTs to the L1 and L2 lines at the service entrance point of the main service panel.

- **CT1** (labeled L1) should be placed on **L1**.
- **CT2** (labeled L2) should be placed on **L2**.

WARNING

- Install sensors on incoming electrical service wires (L1, L2, and L3 if the system is 3Φ).
- Embossed arrows on the sensors must point toward the grid.
- If the system is 3Φ, the arrows must point toward the inverter(s).

(Incorrect installation of the CTs may result in incorrect readings on the display and may prevent the inverter from functioning properly.) If the CT is installed in the wrong direction, there is an option to reverse the direction in the inverter settings: **CT Direction Reversal** (only applicable if the CT1 or CT2 is not installed correctly). This can be done in the **Advanced Settings** tab. However, you should not need to change this if the CTs are installed correctly.

CT Clamping Ratio



CT (Current Transformer) Compatibility and Configuration

The CT included in the accessory package has a 1000:1 ratio and is pre-calibrated for use with the system.

If using a third-party CT, ensure that its ratio is either 1000:1, or 2000:1.

⚠ Be sure to set the correct CT ratio in the inverter's monitoring interface or LCD display, depending on the CT used. Incorrect CT ratio settings may result in inaccurate power measurements or system misbehavior.


Temperature Sensor




- This temperature sensor terminal is required when using lead-acid batteries.
- Place the sensor between two batteries as shown.
- Secure with tape and place away from the battery terminals to prevent overheating.
- This sensor has no polarity. The temperature sensor helps perform voltage charging adjustments and capacity calculations due to changes in temperature.
- Lithium Batteries DO NOT require our external temperature sensor.

Energy Meter Connection

If you need to use an energy meter for import/export monitoring instead of using CTs, it should be connected to the **485A** and **485B** terminals on the inverter for communication. These terminals support RS485



6.7.5 Emergency Stop and Rapid Shutdown Connection



Emergency Stop (E-Stop) & RSD Connection Guidelines

The Emergency Stop (E-Stop) button must be connected to the designated control pins on the inverter.

The Rapid Shutdown (RSD) transmitter should be connected to the corresponding RSD terminal, which supplies 12/24V DC power.

The maximum current output from the RSD terminal is 500mA.

Ensure that the connected RSD transmitter or device does not exceed this limit.

The emergency stop (E-Stop) pins on the SSE-HL8-15K-P2SA-S are a normally open (NO) contact. When the circuit is closed, it will trigger the Rapid Shutdown (RSD) function.

The SSE-HL8-15K-P2SA-S provides two power terminals for RSD (Rapid Shutdown) transmitter connection: +12V – 12V

For 12V RSD Transmitters:


Connect the transmitter to: +12V and GND

For 24V RSD Transmitters:

connect the transmitter to: +12V and – 12V

⚠ Make sure the RSD transmitter's current consumption does not exceed 500mA, which is the maximum output supported by the inverter's RSD terminal.

There is a way to set the transmitter to achieve fast shutdown, taking care to avoid the transmitter exceeding the current provided by the RSD terminal, the wiring diagram is provided below for user reference.



NOTICE

The Built-in 12Vdc power supply of the SSE-HL8-15K-P2SA-S is rated for 500mA . Do not exceed!
If you are unsure of the current (A) rating of the transmitter, contact the manufacturer before connecting.

6.8 Use a Generator


6.8.1 Generator System Connection

This hybrid inverter can be used with a generator. The inverter has a **Gen** port for connecting the generator.

Stator Requirements:

- The generator should use a **neutral-grounding connection** and provide both **240V/120V output**. The generator's capacity may be greater than the current system capacity.
- A THD (Total Harmonic Distortion) of less than 15% is preferred.
- Make sure the generator is correctly connected and meets the voltage and capacity requirements to ensure proper operation with the inverter. Always follow the manufacturer's guidelines for installation and connection.
- DO NOT use "Grid Sell" in Off-Grid systems. Potential to damage the generator.


Generator Connection-Partial Home Backup



When the generator starts, all loads connected to the EPS will be powered by the generator, and the battery will be charged simultaneously.

The AC circuit breaker on the **Gen** port is rated for 63A. When the generator is running, ensure that the total load and charging current do not exceed 63A.

If the user requires remote starting of the generator, the generator start signal should be connected to the **GEN_start** port on the I3 board.



6.8.2 Generator Start and Stop Settings

These conditions depend on the **Battery (Bat) Operation Mode** settings. The system uses the **battery's State of Charge (SOC)** or **battery voltage** to determine whether the generator needs to start or stop.

Generator Start Conditions:

The generator will start under the following circumstances:

Power failure: When there is a loss of grid power or other power sources.

Battery discharge cutoff: When the battery discharges to the cutoff voltage or SOC setting.

Forced charging requirement: If there is a need for forced charging of the battery.

Battery voltage or SOC below the generator start threshold: If the battery voltage or SOC falls below the set **generator charging start voltage/SOC**.

Generator Stop Conditions:

The generator will stop under the following conditions:

When the **battery voltage** or **SOC** is higher than the **charging endpoint voltage/SOC** setting, meaning the battery is sufficiently charged and the generator is no longer needed. By using these settings, the system ensures the generator only operates when necessary, optimizing battery performance and reducing unnecessary generator run time.

Please refer to Chapter 9.9 **Generator Port Settings Menu** for the operation method of the screen.

APP Setting:

The screenshot shows the 'Generator Control' app interface. At the top, there is a back arrow, the title 'Generator Control', and a 'Save' button. Below the title is a 'Generator Setting' section with a dropdown menu for 'Generator'. The settings are as follows:

- * Gen Warm Time(0-1000S): 10
- * Start Gen SOC(10-100%): 25 (highlighted with a red box)
- * Stop Gen SOC(10-100%): 95 (highlighted with a red box)
- * Gen Max Using Power(0.0-800.0kW): 8
- * Gen Max Running Time(0-1440min): 600

6.8.3 AC Coupling Installation and Connection


The SSE-HL8-15K-P2SA-S is a system that supports the addition of AC coupled solar panels. The max solar input power can be expanded by coupling micro or string inverters into the "GEN" or "LOAD" terminals. A full AC coupled solar system is not recommended as power control and monitoring is limited. Having DC coupled modules or a combination of DC coupled and AC coupled solar panels is always preferred.

Inverters that can be used for AC coupling should meet relevant industry specifications. This certification confirms the inverters' ability to disconnect from the grid based on frequency and ensures that the SSE-HL8-15K-P2SA-S will safely be able to frequency shift to control the AC coupled production.

AC coupling to "GEN" or "LOAD"

- Can produce solar power during grid outages.
- Can produce solar power for Off-Grid systems.
- Can monitor solar production.
- The "GEN" input cannot be used when AC is coupled to "LOAD". In addition, the backup power conversion time is extended.

Connection for AC coupled solar system



When the "Grid" is in the **ON** state, the **GEN** terminal connects to the internal "Grid" terminal of the inverter. In this case, the hybrid inverter will bypass the interactive inverter grid and EPS (Emergency Power Supply) system.

When the grid is disconnected, the **GEN** terminal connects to the inverter's internal **EPS** terminal. In this situation, the loads will be powered first by solar energy. If the solar power generated exceeds the load consumption, the excess energy will be stored in the battery.

When the solar power exceeds the sum of load power and the battery's maximum charging power (for example, when the battery is close to full), the inverter will signal the interactive inverter to reduce its power output using a **frequency shifting power reduction mechanism**. This helps maintain the balance between power generation and consumption within the microgrid system, ensuring that the system operates efficiently while preventing overproduction.


6.9 System Parallel Operation

6.9.1 Parallel System Connection

NOTICE

- The hybrid inverter supports parallel operation, allowing for scalable power and energy capacity to meet various usage scenarios. A total of up to 6 units can be connected in parallel, achieving a capacity of up to 90kW.
- Make sure all units in parallel have the same software version by verifying the “MCU” numbers on System Setup.
- Parallel systems REQUIRE a joint battery bank.
- All INPUTS/OUTPUTS must be shared among ALL parallel inverters, except for DC solar inputs.

DIP Switch Configuration for Parallel Systems



Please refer to **Chapter 9.10 Advanced Settings Menu** for the operation method of the screen.

The switch status in the table below refers to the switch status of DIP Switch 2, 3, 4. If Inverter 3 is ON, then switches 2, 3, and 4 should be set to the ON position. DIP Switch 1 should be set based on whether a lithium battery is present, indicating the BMS connection status.

| Inverter1(Master) | Inverter2 | Inverter3 | Inverter4 | Inverter5 | Inverter6 |
|-------------------|-----------|-----------|-----------|-----------|-----------|
| OFF | | | | | |
| ON | ON | | | | |
| ON | OFF | ON | | | |
| ON | OFF | OFF | ON | | |
| ON | OFF | OFF | OFF | ON | |
| ON | OFF | OFF | OFF | OFF | ON |

Parallel Systems in APP Setting

Master

Slave 1

Slave 2

Parallel Setting Save

Parallel Type

Parallel Master v

Parallel Number

3 v

Parallel Address

1 v

Shared Battery

Combined Three Phase

Local Phase

Phase A v

Parallel Setting Save

Parallel Type

Parallel Slave v

Parallel Number

3 v

Parallel Address

2 v

Shared Battery

Combined Three Phase

Local Phase

Phase A v

Parallel Setting Save

Parallel Type

Parallel Slave v

Parallel Number

3 v

Parallel Address

3 v


Shared Battery

Combined Three Phase

Local Phase

Phase A v

The wiring diagram for parallel connection is provided below.



Primary inverter 1


A.15KWx 3 Parallel system installation connection (3 @ 240V/120V)

For the **daisy chain** circuit, ensure that the **2-position CAN termination resistors** on the **first** and **last** inverters in the chain are set to the **ON** position.


Steps:

- 1.First Inverter:** Set the CAN termination resistor switch to **ON**.
- 2.Last Inverter:** Set the CAN termination resistor switch to **ON** as well.
- 3.Intermediate Inverters:** Leave the termination resistors in the **OFF** position for all inverters between the first and last units in the chain

B.15KW x 3 Parallel system installation connection (3 @ 208V/120V)



D,15KW x2 Parallel system installation connection (2 @ 240V/120V)



To properly configure the CAN communication for a daisy chain setup, follow these steps:

First Inverter:

Set the CAN communication pins to the ON position for the first inverter in the chain. This will enable communication and establish the starting point of the CAN bus.


Last Inverter:

Set the CAN communication pins to the ON position for the last inverter in the chain. This ensures the communication line is properly terminated at the end of the bus.

Intermediate Inverters:

For the inverters in between, the CAN communication pins should be left in the OFF position, as they act as repeaters but do not need to have the termination enabled.

If the **parallel cables** are not long enough or unavailable, you can create a **direct pin-to-pin cable** to extend the connections between the inverters.



7. Operating Modes and Functions

7.1 Operate the inverter and conduct a test


At least one energy source must be available to run this inverter: Battery, PV, or Grid.

7.1.1 Check the voltage of the battery bank

- Voltage of the battery must be between 40VDC - 60VDC.
- If applicable, turn ON internal switches of the batteries. Measure individual voltages.
- Verify that the voltage of the battery bank at the SSE-HL8-15K-P2SA-S terminals is adequate.
- DO NOT reverse polarity. DO NOT turn OFF battery disconnect if any current is flowing in or out of the battery.

7.1.2 Check the voltage of each PV input circuit

- Input voltage must not exceed 550VDC.
- Input voltage must be above the startup voltage of 120VDC.
- Do not ground PV+ or PV-.
- Verify polarity in each PV string. Backward polarity will measure 0Vdc by the SSE-HL8-15K-P2SA-S and will cause long term damage.
- PV alone turns LCD screen only. Inverter requires grid and/or batteries to operate.
- PV DC disconnect switch on the side of the inverter will turn the PV ON or OFF.




7.1.3 Check GRID input voltage

- Use the "GRID" terminals to measure AC voltage with a multimeter.
- Measure line (L) to neutral (N) voltages on "GRID" terminals. Ensure 120VAC on all phases.
- Measure line (L1) to line (L2) voltages on "GRID" terminals. Ensure 240VAC. (If voltage reading is close to 220V or 210V, verify if grid is single-phase or three-phase instead).
- Verify that voltage between Neutral and Ground is 0VAC.
- Verify that voltage between "GRID" L1 and "LOAD" L1 is 0V. Do the same for L2

7.1.4 Power ON SSE-HL8-15K-P2SA-S

- Turn ON the battery breaker(s).
- PRESS down the power button to the ON position. Wait for the LED indicator to turn on. This may take a few minutes.
- Turn ON the PV DC disconnect switch.
- Turn ON the external "GRID" disconnect.
- Turn ON the internal "LOAD" and external "GEN" breakers.



7.1.5 Power Cycle Sequence

1. TURN OFF all AC breakers / disconnects (“GRID”, “GEN” and “LOAD”).
2. TURN OFF the built-in PV DC disconnect switch on the side of the inverter.
3. PRESS the power button, making sure it is in the OFF position. An “OFF” message will appear after the LED turns off.
4. TURN OFF the battery breakers.
5. Wait a moment (~1 min) to ensure the inverter is completely de-energized.
6. Make sure that the SSE-HL8-15K-P2SA-S is properly connected to the batteries, solar panels, “GRID”, “GEN”, and “LOAD”.
7. Reverse the steps to turn ON the SSE-HL8-15K-P2SA-S.

7.2 Operating Modes and Functions

This inverter offers different operating modes and functions to meet a variety of customer needs. The operating modes and their functions are as follows:

7.2.1 Self-Use Mode (Default)

In **Self-Use Mode**, the system prioritizes energy flow as follows:

For powering loads: Solar → Battery → Grid

For using solar energy: Load → Battery → Grid


When solar power is available, it is first used to power local loads. Excess solar energy is stored in the battery, and any remaining surplus is exported to the grid. When solar power is insufficient, the system uses battery energy to support the loads. Only when both solar and battery are insufficient does the system draw power from the grid. This mode is set as the default operating mode. It is designed to **maximize self-consumption of solar energy**, thereby reducing reliance on the grid and lowering electricity costs.

Application Scenario

Self-Use Mode is ideal for residential or commercial users who want to reduce energy bills and improve energy independence by making full use of on-site solar generation.

Please refer to Chapter 9.6 **Work Mode Settings Menu** for the operation method of the screen.

APP Setting:



*On-grid Battery Reserve SOC (10-100%):When the battery is connected to the grid, it maintains its charge. When the battery is low on soc, the battery will be charged and discharging is not allowed .

*Off-grid Battery Reserve SOC (10-100%):The battery maintains its charge when off-grid, and will charge when the soc is low, and discharging is not allowed .

7.2.2 TOU ECO Mode

TOU Economy Mode is designed to optimize economic returns by adjusting energy usage and storage behavior according to time-of-use (TOU) electricity pricing.

During peak price periods, the system prioritizes: Load → Grid → Battery

Maximize revenue by selling solar energy to the grid at high prices.

During flat price periods, the system prioritizes: Load → Battery → Grid

Use solar power primarily for self-consumption and store excess in the battery.

During valley price periods, the system prioritizes: Battery → Load → Grid

Charge the battery from the grid when electricity prices are low, and use stored energy during expensive periods.


Users can define the peak, flat, and valley time periods according to local electricity rates and their own usage patterns via the system settings or monitoring platform.

Application Scenario

TOU Eco Mode is suitable for users in regions with significant differences in electricity prices across time periods. It helps reduce electricity costs and maximize profits by charging when electricity is cheap and discharging or selling when it is expensive.

Please refer to Chapter 9.6 **Work Mode Settings Menu** for the operation method of the screen.

APP Setting:



Time Setting

Set the time period for peak and valley electricity prices.

“+” is to add time period “-” is to delete time period

7.2.3 Backup Only Mode

Backup Only Mode is designed to maximize battery charging and reserve energy specifically for backup use during grid outages or instability. In this mode, the system prioritizes storing solar energy in the battery rather than supplying it to loads or exporting to the grid during normal operation. The battery will **only discharge when the grid fails or becomes unavailable**.

PV power priority: Battery → Load → Grid

Application Scenario

Backup Only Mode is ideal for users in areas with frequent power outages, unstable grid conditions, or where critical loads (such as medical equipment, servers, or refrigeration) must be kept running at all times. It prioritizes energy availability and system reliability over cost savings or feed-in profits.

Please refer to Chapter 9.6 **Work Mode Settings Menu** for the operation method of the screen.

APP Setting:

7.2.4 Grid priority Mode

Grid Priority Mode is designed to prioritize exporting electricity to the grid when sufficient power is available, in order to maximize feed-in profits.

In this mode, the system supplies power in the following order:

Power Supply Priority: Load → Grid → Battery


When solar energy is generated, it is first used to meet local load demand. Any excess energy is then exported to the grid for revenue. The battery will only be charged if there is additional surplus after meeting both load and grid feed-in needs.

Application Scenario

Grid Priority Mode is suitable for regions with **favorable feed-in tariffs (FITs)** or net metering policies. It is ideal for users who aim to **maximize income from solar generation**, rather than prioritize local energy consumption or backup capacity.

Please refer to Chapter 9.6 **Work Mode Settings Menu** for the operation method of the screen.

APP Setting:



7.3 Generator Function

The **Generator&Smart Load** function allows the power input connection point to act as a load connection point. When enabled, the inverter will supply power to the connected load when the **battery state of charge (SOC)** exceed the user-defined thresholds. **Please refer to Chapter 9.9 Generator Port Settings Menu for the operation method of the screen.**

Function Description:

Gen Warm Time: Generator warm-up time. After the inverter sends the start signal, it waits for this duration before accepting generator input.

Start SOC / Stop SOC: Battery SOC thresholds for starting and stopping the generator automatically.

Gen Rated Power: Maximum power output of the generator.

Max Run Time: Maximum continuous run time for the generator. Applies when the inverter is automatically controlling the generator.

Cooling Time: Generator cool down period after stopping. Applies to inverter-controlled generator operation.

Gen Force: Force Start Generator function. Should be enabled during the first-time connection of a generator to ensure recognition and activation.

For example:

- **Generator Start SOC = 20%**
- **Generator Stop SOC = 90%**

Operation:

- When the **battery SOC reaches 20%**, the Generator Port automatically turns on and supplies power to the connected load.
- When the **battery SOC falls below 90%**, the Generator Port will automatically shut off.

Application Scenario:

- This function is useful when you want to prioritize powering non-critical loads with solar energy when both the battery is sufficiently charged and solar power generation is above a certain level, ensuring that only excess power is used for loads.

Important Note:

- **Do not connect a generator** when enabling the Smart Load function, as this can **damage the equipment**.

Please refer to Chapter 9.6 **Work Mode Settings Menu** for the operation method of the screen.

7.4 Smart Load Function

The **Smart Load** function allows the power input connection point to act as a load connection point. When enabled, the inverter will supply power to the connected load when the **battery state of charge (SOC)** exceed the user-defined thresholds. **Please refer to Chapter 9.9 Generator Port Settings Menu for the operation method of the screen.**

Function Description:

Stop Output SOC: When the battery SOC drops to this threshold, the smart load output will automatically disconnect.

Stop Output Volt: If voltage-based control is selected, the smart load output will disconnect when the battery voltage reaches this value.

Control Start Time: Start of the time window during which the SOC or voltage control conditions are valid.

Control End Time: End of the time window during which the SOC or voltage control conditions are valid.

Note:

Outside the defined time window, the smart load output is not restricted by SOC or voltage conditions, and will follow the same discharge behavior as the EPS output.

For example:

- **Smart Load Start SOC = 90%**
- **Smart Load Stop SOC = 50%**

Operation:

- When the **battery SOC reaches 90%**, the Smart Load Port automatically turns on and supplies power to the connected load.
- When the **battery SOC falls below 50%**, the Smart Load Port will automatically shut off.

Application Scenario:

- This function is useful when you want to prioritize powering non-critical loads with solar energy when both the battery is sufficiently charged and solar power generation is above a certain level, ensuring that only excess power is used for loads.

7.5 Off-Grid Installation Tips

- **Limit sensors (CTs)** are **not required** for completely off-grid installations, **unless:**


"Grid Priority" is enabled using a generator connected to the **GRID** terminal.

- A **transfer switch is not required** in off-grid systems. The **LOAD** output can be connected directly to the main panel.
- **Do not use "Grid Sell" mode** in off-grid installations.
- When using a **generator in an off-grid scenario**, it is recommended to set the **Grid Mode** to "**General Standard**".
- The **Auto Generator Start (AGS)** function activates when the battery voltage or state of charge drops below the user-defined "**Start Voltage / SOC**" threshold.
- Ensure that the **battery capacity** is correctly configured and that charge/discharge current limits are set within safe operating ranges.

7.6 Battery Charge Controller

4-Stage Charging

The Inverter has a 4-stage battery charging algorithm for rapid, efficient, and safe battery charging. The next figure shows the stage sequence.



Bulk Charge Stage

In the Bulk Charge stage, the battery is not at a 100% state of charge and has not yet reached the Absorption voltage setpoint. The controller will deliver 100% of available solar power to recharge the battery.

Absorption Stage

When the battery has reached the absorption voltage setpoint, the inverter uses constant-voltage regulation to maintain battery voltage at the absorption setpoint, preventing overheating and excessive battery gassing. The battery is allowed to come to a full state of charge at the absorption voltage setpoint. Absorption lasts until the battery charge amperage (A) rate reaches 2% of the programmed capacity (Ah).

Float Stage

After the Absorption stage charges the battery fully, the MPPT reduces the battery voltage to the float voltage setpoint. If the batteries have 100% charge, there can be no more chemical reactions, and all the charging current turns into heat and gassing. The Float stage provides a minimum rate of maintenance charging while reducing the heating and gassing of a fully charged battery. The purpose of the Float stage is to protect the battery from long-term overcharge

8. Wi-Fi&BLE stick installation

8.1 Indication


A: Circular Connector Interface, Connect to inverter and communication

B: Green LED, Inverter communication indication

C: Green LED, Network communication indication

D: Green LED, Show WiFi data logger operating status

E: Label, Show SN and password of WiFi data logger



- 1.LED glow only when the Wi-Fi&BLE stick is powered on.
- 2.When the Wi-Fi&BLE stick is powered on, the green LED glows for 3S as a power on indication.
- 3.The more detail LED indication please refer chapter 8.5 “LED indication and trouble shooting”.




NOTICE

Router and ONT should not be connected to the load terminals of the inverter, as this may interfere with remote software updates. These devices can be connected to the Grid side to ensure uninterrupted network service.

8.2 Install the Wi-Fi&BLE stick

Follow the installation steps!

| | |
|--------------------------------|------------------------------------|
| 1.Remove the waterproof cover. | 2.Aligning groove. |
| 3.Plug in WiFi module. | 4.Revolve to lock the WiFi module. |



8.3 Web/APP


If you are an household user, please scan QR code below to download SOLARMAN Smart APP. Or you can log in to <https://home.solarmanpv.com>



SOLARMAN Smart

8.4 Wi-Fi Connection

8.4.1 Log in to your account




Step 1: Select language

Step 2: Create an account

Step 3: Enter your account and password to log in

8.4.2 Create a plant



Step 1: Click "Add Now" to create your plant



Plant Details

Basic Info

Plant Name Demo plant-Commercial >

Plant Loc Zhwjiang yuyao >

Time Zone ((UTC+08:00)Beijing,Chongqing,HongKong,Urumqi) >

Creation Date 2019-05-04 >

Founder Clavin >

System Info

Plant Type Residential Rooftop >


System Type All on Grid >

Installed Capacity (kWp) 18350 >


Finish

Step 2: Fill in plant basic information and other information here. Then click "Finish" option

8.4.3 Add a Logger



Step 1: Click the “+” icon in the upper-right corner, then click "Add a device"




Method 1: Enter logger SN manually


Method 2: Click the icon in the right and scan to enter logger SN

NOTE: You can find logger SN in the external packaging or on the logger body.



8.4.4. Network Configuration



Step 1: Click "Go to Configure" to set the network
(Please make sure Bluetooth and WiFi are ON.)



Step 2: Choose WiFi network and enter password to log in



Step 3: Please wait for a few minute. Then click "Done" and view plant data.

NOTICE




Notice:
5G WiFi is not supported .

8.5 LED indication and trouble shooting

| LED | State | Indication | |
|--|--|--|---|
|  | Red LED: Inverter communication indication |  | Green LED: Network communication indication |
|  | Cycle for 2S: flash once quickly, then glowing | Cycle for 2S: flash once quickly, then glowing | |
|  | Not glow more than 20S | <p>The power supply to the Wi-Fi&BLE stick is abnormal or damaged:</p> <ol style="list-style-type: none"> 1. Check whether the power supply of the Aerial Plug Interface on the inverter is normal 2. Wi-Fi&BLE stick abnormal, contact the dealer | |
|  | Cycle for 2S: flash once quickly, then off | <p>Communication failure:</p> <p>Check whether the connection between the Wi-Fi&BLE stick and inverter is loose or poor contact</p> | |
|  | When powered on, continuously glows 3S, and then off | Power on indication | |
|  | Glow more than 5S | Communication is normal | |
|  | During the long glowing, flash occasionally | Network transmit data | |
|  | Cycle for 20S: flash once quickly, then off | <p>The route is not connected:</p> <ol style="list-style-type: none"> 1. Check whether the password is right 2. Check the strength of the router | |
|  | Cycle for 20S: flash 3 times continuously, then off | <p>Connect to the route, but can't connect to the cloud server:</p> <ol style="list-style-type: none"> 1. Check whether the router has Internet access permission 2. Check the firewall setting | |
|  | Cycle for 20S: flash 4 times continuously, then off | Wi-Fi&BLE stick information error: Please contact the dealer | |


9.Operation

9.1 Indicator panel



| Name | Object | Function |
|---------------|--------|---|
| Indicator LED | A | Green : ON, The inverter is running ; Flash is Standby. |
| | B | Blue : ON, Communication with BMS normal. |
| | C | Yellow : ON, The inverter is in EPS mode. |
| | D | Red : The inverter is in fault mode. |
| | E | UP:To go to previous selection |
| | F | DOWN:To go to next selection |
| | G | ENTER:To confirm the selection |
| | H | ESC:To exit setting mode |


9.2 LCD operation flow chart



9.3 LCD Display Icons

9.3.1 Main Screen

The LCD is touchscreen, below screen shows the overall information of the inverter.



1. System Information Display

1.1 Date and Time

At the top of the screen displays the current system date and time.

1.2 Warning Icon ('!')

A red '!' mark indicates a system fault or abnormal condition.

Clicking the icon opens the fault detail page, where users can check the alarm messages and fault codes.

Follow the on-screen guidance or troubleshooting manual to resolve issues.

1.3 Settings Icon (Gear)

Click to access the system settings menu.

Includes configuration options such as operation mode, battery parameters, grid settings, etc.

2. Inverter Status and Operating Mode

2.1 Inverter Power Status

The icon in the center represents the inverter unit. Its power status is clearly shown as ON or OFF.

2.2 Current Operating Mode Display

The active system mode is shown above the inverter icon.

Possible modes include: TOU ECO, Self-Use, Backup, etc. This helps users understand how the system is currently operating.

3. Real-Time Energy Device Overview

The four blue icons visually represent the status and power of key energy components. Each icon is interactive:

3.1 Top Left--PV

Displays real-time solar generation power. Click to view detailed PV status.

3.2 Top Right--Grid

Shows grid import power. Click to view grid connection information.

3.3 Bottom Left--Battery

Displays current battery state of charge and charge/discharge power. Click to view battery details.

3.4 Bottom Right--Load

Shows real-time load consumption. Click to access detailed load information.

4. Energy Flow and Connection Indicators

4.1 Arrow Indicators

Arrows illustrate real-time energy flow paths. The direction indicates the power flow direction (e.g., from PV to Load).

4.2 Red "X" Icons

Indicate that a path or device is not connected or inactive.

Examples include: battery not installed, grid offline, etc.

-PV power and Load power always keep positive.

-Grid power negative means get from grid, positive means sell to grid.

-Battery power negative means charge, positive means discharge.

9.3.2 PV Information Page Overview

Solar

| | | |
|--------------|--------------|---------------|
| PV1-V: 0.0 V | PV1-I: 0.0 A | PV1-P: 0.0 kW |
| PV2-V: 0.0 V | PV2-I: 0.0 A | PV2-P: 0.0 kW |
| PV3-V: 0.0 V | PV3-I: 0.0 A | PV3-P: 0.0 kW |

Total Power: 0.0 kW

Today: 0.0 kWh Total: 0.0 kWh

(Subject to variation depending on project configuration)
When the PV icon on the main interface is clicked, the system navigates to the PV information page. Here, PV1 to PV3 display the voltage, current, and power data for each of the three PV input channels.

Below these readings, users can view the total current PV power, the energy generated today, and the historical cumulative generation. Page navigation arrows on the side of the screen allow users to scroll through additional data pages.

9.3.3 Grid Information Page Overview

Grid

| | | |
|-------------|----------------|----------------|
| Fault | Power: 0.0 kW | Freq: 0.0 Hz |
| L1-V: 0.0 V | L1-I: 0.0 A | L1-P: 0.0 kW |
| L2-V: 0.0 V | L2-I: 0.0 A | L2-P: 0.0 kW |
| BUY | Today: 0.0 kWh | Total: 0.0 kWh |
| SELL | Today: 0.0 kWh | Total: 0.0 kWh |

(Subject to variation depending on project configuration)
The Power field displays the total grid power. Freq refers to the present grid frequency. L-V represent the single phase voltage, each showing their respective voltage, current, and power values.

At the bottom of the page, the energy purchased from the grid is displayed, including both the daily purchased energy and cumulative purchased energy. (Note: These fields may vary depending on the specific project configuration.)

9.3.4 Battery Information Page Overview

Bat

| | | | |
|--------------|-------------|----------------|-------|
| Status: | No Ch&DisCh | Ch limit A: | 0.0 A |
| Bat-V: | 0.0 V | Disch limit A: | 0.0 A |
| Bat-I: | 0.0 A | Ch limit V: | 0.0 V |
| Bat-P: | 0 W | Disch limit V: | 0.0 V |
| temp: | 0.0 C | | |
| SOC: | 0 % | | |
| Ch rquest: | No | | |
| Ch limit: | No | | |
| Disch limit: | No | | |

This page displays the operating information of Battery 1 (subject to variation depending on the project configuration).

Key parameters include the current battery status, voltage, current, power, temperature, and State of Charge (SOC).

9.3.5 Load Information Page Overview

| Load | | |
|--------------------|----------------|-------------|
| EPS Load: 0.0 kW | Today: 0.0 kWh | |
| Home Load: 0.0 kW | Total: 0.0 kWh | |
| Smart Load: 0.0 kW | | |
| Total Load: 0.0 kW | | |
| EPS-RU: 0.0 V | EPS-RI: 0.0 A | Pwr: 0.0 kW |
| EPS-SU: 0.0 V | EPS-SI: 0.0 A | Pwr: 0.0 kW |

(Subject to variation depending on the project configuration)

This page includes readings for EPS load power, household load power, i load power, and the total load power.


Below these values, the page also displays the voltage, current, and power for the split AC phases: L1, and L2.

9.4 System Setup Menu

System Settings Page (Standard User Access)

This is the settings page available under standard user permissions.

| System Setup | | |
|--------------|---------------|--------|
| Work Mode | Basic Setting | Record |
| Device Info | | |


To enter basic settings mode, click the icon  in the upper-left corner and enter the password **0000**.

| | | | |
|------|---|---|--------|
| 0000 | | | Range |
| 7 | 8 | 9 | |
| 4 | 5 | 6 | DEL |
| 1 | 2 | 3 | CANCEL |
| | 0 | . | OK |

Advanced User Access

System Setup

| | | |
|---------------|-----------------|-----------------|
| Work Mode | Battery Setting | Grid Setting |
| Gen Port Use | Advanced Func | Factory Setting |
| Basic Setting | Record | Device Info |
| Quick Install | | |

To enter advanced settings mode, click the icon  in the upper-left corner and enter the password 7777.

Once verified, the system will open the Advanced Settings Page, where users can access additional configuration options not available under standard permissions.

| | | | |
|------|---|---|--------|
| 7777 | | | Range |
| 7 | 8 | 9 | |
| 4 | 5 | 6 | DEL |
| 1 | 2 | 3 | CANCEL |
| | 0 | . | OK |

9.5 Basic Settings Menu

Basic Setting

| | | | | | |
|---------------|-------|----------|---------|---|----|
| Time Setting | 2023 | - | 11 | - | 10 |
| | 12 | : | 8 | : | 58 |
| LCD Light | 100 % | Beep | No | | |
| Auto Dim Time | 600 s | Language | English | | |

-Time Setting:

Set the system's date and time, including year, month, day, hour, and minute.

-LCD Light:

Adjust the screen brightness level.

-Beep:

Enable or disable the buzzer.

Enabled by default; the buzzer will sound upon touch or key press.

-Auto Dim Time:

Set the duration before the screen automatically dims or turns off.

-Language:

Select the system display language.

9.6 Work Mode Settings Menu

Work Mode Settings-Page 1

Work Mode 1/4

| | |
|---------------------|---|
| Max Solar Power | <input type="text" value="0.0 kW"/> |
| Zero Export To Grid | <input type="button" value="No"/> |
| Max Sell Power | <input type="text" value="0.0 kW"/> |
| Zero Export Power | <input type="text" value="0.0 kW"/> |
| Energy Pattern | <input type="button" value="Load First"/> |

-Max Solar Power:

Sets the maximum PV input power.

Zero Export To Grid:

When enabled, the inverter limits the amount of power exported to the grid.

The actual export limit is defined by the Zero-export Power setting.

-Zero Export Power:

Specifies the inverter's export power limit to the grid.

This setting takes effect only when Zero Export to Grid is enabled.

-Max Sell Power:

Sets the maximum power that can be exported to the grid.

-Energy Pattern:

Defines the system's energy priority

strategy. Currently, only **Load First** mode is supported.

-Load First:

PV power is used first to supply the load.

Any surplus PV energy is then used to charge the battery.

If PV is insufficient, the grid will supply the load.

Work Mode Settings-Page 2

Work Mode 2/4

| | |
|--------------------------|--|
| Power On/Off | <input type="button" value="OFF"/> |
| Auto Power On | <input type="button" value="No"/> |
| Work Mode | <input type="button" value="TOU ECO"/> |
| On-Grid Bat Restart SOC | <input type="text" value="10 %"/> |
| Off-Grid Bat Restart SOC | <input type="text" value="10 %"/> |
| Charge Max SOC | <input type="text" value="100 %"/> |

-Power On/Off:

Manually switches the inverter ON or OFF.

-Auto Power On:

Enables automatic startup and shutdown.

When enabled, the inverter will power on automatically.

-Work Mode:

Sets the system's working mode. Available options include:

Self-USE, TOU ECO, Backup Power, and Grid Priority.

-On-Grid Bat Restart SOC:

When the inverter is connected to the grid:

Battery is allowed to discharge if SOC 10%.

If battery SOC drops below (Restart SOC-3), the inverter will trigger forced charging to

raise SOC back to 10%.

-Off-Grid Bat Restart SOC:

When the inverter is off-grid (not connected to the utility):

Battery is allowed to discharge if SOC 10%.

-Charge Max SOC:

Sets the maximum battery SOC for charging.

Once this limit is reached, charging will stop automatically.

Work Mode Settings-Page 3(TOU Mode Settings)

Work Mode--TOU 3/4

| | Time | Type | Curr | SOC |
|---|-------------|----------|------|-----|
| - | 00:00 12:30 | Disch | 0 A | 0 V |
| + | 12:30 23:59 | Self-Use | 0 A | 0 V |

To enable TOU scheduling, the Work Mode on Work Mode Settings – Page 2 must be set to **TOU ECO**.

Only then will the time-based configuration become effective.

-Time:Defines the time slots used for energy management.

The full 24-hour day must be divided into continuous,non-overlapping periods.Each time slot includes a start time and an end time.Up to 6 time slots can be added by clicking the "+"icon.

-Type:Defines the behavior of the system during the time slot:

-Discharge:Battery discharges according to the specified parameters.

Example Schedule:

| Time Period | Priority Type | Zero Export Disabled | Zero Export Enabled |
|---------------|---------------|---|--|
| 00:00 – 12:30 | Discharge | - Battery discharges if SOC > 20% (up to 50A limit) - Excess PV is exported to the grid | - Same discharge behavior - Excess PV charges battery to avoid waste |
| 12:30 – 16:30 | Self Use | - Battery discharges if SOC > 40% when PV cannot meet load - Battery charges if SOC < 36% using PV or grid - Remaining PV is exported | - Same behavior - No export allowed: Excess PV not used for load or charging is curtailed |
| 16:30 – 23:59 | Charge | - Battery charges if SOC < 90% using PV + grid (up to 30A) - Excess PV is exported | - Same charging behavior - No export allowed: Any excess PV after charging is curtailed |

Work Mode Settings-Page 4(iLoad Mode Settings)

iLoad 4/4

| | |
|--------------------|------------------------------------|
| Stop Output SOC | <input type="text" value="0 %"/> |
| Stop Output Volt | <input type="text" value="0 V"/> |
| Control Start Time | <input type="text" value="00:00"/> |
| Control End Time | <input type="text" value="00:00"/> |

iLoad: The port is used as a dedicated load output, with user-defined working conditions for iLoad control.

Stop Output SOC:
When the battery SOC drops to this threshold, the i load output will automatically disconnect.

Stop Output Volt:
If voltage-based control is selected, the i load output will disconnect when the battery voltage reaches this value.

Control Start Time:
Start of the time window during which the SOC or voltage control conditions are valid.

Control End Time:
End of the time window during which the SOC or voltage control conditions are valid.

9.7 Battery Settings Menu

Battery1 Setting1 – Page 1

Bat Setting1 1/2

| | | | |
|--------------------|-----------------------------------|-------------------------------------|-------------------------------------|
| Max A Charge | <input type="text" value="0 A"/> | Bat 1 Type | <input type="text" value="No_Bat"/> |
| Max A Disch | <input type="text" value="0 A"/> | Activate Bat | <input type="text" value="No"/> |
| Max Ch Power | <input type="text" value="0 kW"/> | Comm Type | <input type="text" value="1-CAN"/> |
| Max Disch Power | <input type="text" value="0 kW"/> | Company | |
| Grid Charge | <input type="text" value="No"/> | <input type="text" value="BYD_HV"/> | |
| Parallel Bat1&Bat2 | <input type="text" value="No"/> | Disch To Grid | <input type="text" value="No"/> |

1.-Max A Charge / Max A Disch:

Set the **maximum battery charging current** and **maximum battery discharging current**, respectively.

-Max Ch Power / Max Disch Power:

Set the **maximum charging power** and **maximum discharging power** for the battery.

-Grid Charge:

Enables or disables battery charging from the utility grid.

2.-Parallel Bat1 & Bat2:

For inverter models with two battery ports, enabling this function allows a single battery to be connected to both **Battery Port 1** and **Battery Port 2** simultaneously. In this case, the battery communication cable should be connected to the inverter's **BMS1 port**.

-Bat1 Type:

Select the battery type. Available options include: **Lithium**, **Lead-acid**, **DC Source**, and **No Battery**.

-Activate Bat:

Manually triggers battery activation or wake-up.

3.-Comm Type:

Select the battery communication protocol: **CAN** or **RS485**

-Company:

Select the battery manufacturer. The system will automatically match the correct communication protocol based on the selected brand.

Battery1 Setting2 – Page 2

Bat Setting2 2/2

| | | | |
|----------------|------------------------------------|-------------------|-----------------------------------|
| Float V | <input type="text" value="0.0 V"/> | Ch Ratio | <input type="text" value="0.00"/> |
| Equalization V | <input type="text" value="0.0 V"/> | TEMPCO(mV/C/Cell) | <input type="text" value="0"/> |
| Shutdown | <input type="text" value="0.0 V"/> | Parallel Num | <input type="text" value="0"/> |
| High Bat | <input type="text" value="0.0 V"/> | Bat Capacity | <input type="text" value="0 Ah"/> |
| Low Bat | <input type="text" value="0.0 V"/> | | |

Float V:

Sets the **battery float charging voltage**

Equalization V:

Sets the **equalization charging voltage**

Shutdown:

Sets the **battery discharge cutoff voltage** for protection

High Bat / Low Bat:

Define the **battery port over-voltage** and **under-voltage protection thresholds**, respectively

The following settings is **only applicable to lead-acid batteries**:

Ch Ratio:

Sets the **charging C-rate** (charging ratio)

TEMPCO:

Battery **temperature compensation coefficient**

Parallel Num:

Sets the number of parallel-connected battery groups, when used in multiple parallel clusters

Bat Capacity:

Set the battery capacity

9.8 Grid Settings Menu

Grid Settings – Page 1

Grid Code Selection 1/4

| | | | |
|-------------------|---------------|---------------|--------|
| Grid Code | Italy CEIO-21 | | |
| Grid Volt | 220V | Grid Sensor | None |
| Grid Freq | 50Hz | CT Ratio | 0 |
| Zero Export | No | Meter Addr | 1 |
| Zero Export Power | 0.0 kW | Meter Select | CHNT |
| Max Sell Power | 0.0 kW | Max Buy Power | 0.0 kW |

Grid Code: Select the national grid standard according to the installation region (e.g.,Italy-CEIO-21,Spain UNE217002).

Grid Sensor: Configuration of the grid-side current sampling method.

None:Inverter samples current internally at the grid port.

CT:External current transformer(CT)is used for sampling.

Meter:External smart meter connected via RS485 for grid data acquisition.

Grid Volt:Set the nominal grid voltage according to the country standard.

Grid Freq:Set the nominal grid frequency based on the local grid specification.

CT Ratio:Set the CT transformation ratio.

Zero Export:When enabled,the inverter will limit the power exported to the grid.

The limit is defined by the Zero-export Power setting.

Zero-export Power: Sets the maximum inverter export power.This is only effective when Zero Export is enabled.

Meter Addr: Set the RS485 address of the external energy meter.

Meter Select:Select the meter manufacturer.Please ensure the selected model matches the actual hardware.

Max Sell Power:Sets the maximum allowed output power exported to the grid.

Max Buy Power:Sets the maximum allowed input power drawn from the grid to the inverter

Grid Connect 2/4

| | | | |
|------------------------|-----|-------------|----|
| 10min Grid Volt | 0% | L/HVRT Mode | No |
| Normal Ramp rate | 0 s | L/HPRT Mode | No |
| Normal Connection Time | 0 s | P-V Mode | No |
| Reconnect Ramp rate | 0 s | P-QMode | No |
| Reconnection Time | 0 s | Q-V Mode | No |
| PF | 0.0 | SPF Mode | No |

Reserved: This function is reserved. It is not recommended. Please inform the manufacturer/installer before setting up

10min Grid Volt:

Set the voltage protection range within 10 minutes.

Normal Ramp Rate:

Sets the power ramp-up time after inverter startup.

Normal Connection Time:

Sets the time delay before the inverter injects active power to the grid after startup.

Reconnect Ramp Rate:

Sets the ramp-up time for active power after fault recovery.

Reconnection Time:

Sets the reconnection delay time after a fault is cleared.

Grid Settings-Page 3

Grid Protection1 3/4

| | | | |
|------------------|-------------------------------------|-----------------|-------------------------------------|
| High volt 1 | <input type="text" value="0.0 %"/> | Low volt 1 | <input type="text" value="0.0 %"/> |
| High volt 2 | <input type="text" value="0.0 %"/> | Low volt 2 | <input type="text" value="0.0 %"/> |
| | | Low volt 3 | <input type="text" value="0.0 %"/> |
| High volt time 1 | <input type="text" value="0.00 s"/> | Low volt time 1 | <input type="text" value="0.00 s"/> |
| High volt time 2 | <input type="text" value="0.00 s"/> | Low volt time 2 | <input type="text" value="0.00 s"/> |
| | | Low volt time 3 | <input type="text" value="0.00 s"/> |
| High volt recv | <input type="text" value="0.0 %"/> | Low volt recv | <input type="text" value="0.0 %"/> |

Reserved:This function is reserved.It is not recommended. Please inform the manufacturer/installer before setting up

High Volt 1/High Volt 2:Level 1 and Level 2 overvoltage protection thresholds (as a percentage of nominal voltage).

High Volt Time 1/High Volt Time 2:Time delays for triggering Level 1 and Level 2 overvoltage protection.

High Volt Recv: Grid overvoltage recovery threshold.

Low Volt 1 Low Volt 2:Level 1 and Level 2 undervoltage protection thresholds,also defined as percentages of the nominal voltage.

Example

To adjust the acceptable voltage range of the inverter for grid connection:

Simply configure High Volt 1 and Low Volt 1 values.

If the nominal voltage is 240V:

High Volt 1 at 120%-Overvoltage point 288V

Low Volt 1 at 80%-Undervoltage point 192V

Grid Protection2 4/4

| | | | |
|------------------|-------------------------------------|-----------------|-------------------------------------|
| High freq 1 | <input type="text" value="0.0 Hz"/> | Low freq 1 | <input type="text" value="0.0 Hz"/> |
| High freq 2 | <input type="text" value="0.0 Hz"/> | Low freq 2 | <input type="text" value="0.0 Hz"/> |
| High freq time 1 | <input type="text" value="0.00 s"/> | Low freq time 1 | <input type="text" value="0.00 s"/> |
| High freq time 2 | <input type="text" value="0.00 s"/> | Low freq time 2 | <input type="text" value="0.00 s"/> |
| High freq recv | <input type="text" value="0.0 Hz"/> | Low freq recv | <input type="text" value="0.0 Hz"/> |

Reserved:This function is reserved.It is not recommended. Please inform the manufacturer/installer before setting up

High Freq 1 and High Freq 2 refer to the first- and second-level over-frequency protection thresholds (in Hz). These values are typically based on the system's nominal frequency (e.g., 50Hz or 60Hz).

High Freq Time 1 and High Freq Time 2 define the delay time

before triggering protection actions when the grid frequency exceeds the corresponding threshold.

High freq recv: The recovery point frequency value of the power grid overfrequency protection. When the frequency recovers from too high to below this value, the system will allow reconnection to the grid or resume operation.

Low Freq 1 and Low Freq 2 represent the first- and second-level under-frequency protection thresholds. If the frequency falls below these values, protection will be triggered accordingly.

Low Freq Time 1 and Low Freq Time 2 set the delay durations before activating under-frequency protection once the frequency drops below the set limits.

Low Freq Recv: The recovery threshold for under-frequency protection. The system will reconnect or resume operation when the grid frequency rises above this value.

Example:

If the system nominal frequency is 50Hz, and the settings are as follows:

High Freq 1 = 52Hz, Low Freq 1 = 47Hz

The system will trigger first-level protection when the frequency goes above 52Hz or below 47Hz, based on the defined time delays.

High Freq 2 = 53Hz, Low Freq 2 = 46Hz

More severe deviations will activate second-level protection mechanisms.High Freq 1 and High Freq 2 refer to the first- and second-level over-frequency protection thresholds (in Hz). These values are typically based on the system's nominal frequency (e.g., 50Hz or 60Hz).

High Freq Time 1 and High Freq Time 2 define the delay time before triggering protection actions when the grid frequency exceeds the corresponding threshold.

High Freq Recv is the recovery point. The inverter will reconnect to the grid or resume operation only after the frequency drops below this value.

Low Freq 1 and Low Freq 2 represent the first- and second-level under-frequency protection thresholds. If the frequency falls below these values, protection will be triggered accordingly.

9.9 Generator Port Settings Menu

Gen Port Function

Select the functional mode of the generator port. Available options:

Generator Setting 1/3

| | | | |
|-------------------|---------|-------------|---------|
| Gen Port Function | Gen | | |
| Gen Warm Time | 8 s | Start SOC/V | 180.1 V |
| Gen Max Ch Pwr | 60 kW | Stop SOC/V | 450.0 V |
| Max Run Time | 600 min | Start Time | 08:00 |
| Cooling Time | 10 min | End Time | 16:00 |
| Gen Force | No | | |

Generator setting: The port is used as an input for generator power. Once the generator starts, its power is used to charge the battery.

Sets the Gen Port Function. Available options include: No, Gen, Smart Load, AC Coupling. Select the option to configure the corresponding parameters.

When Gen Port Function is set to Generator, the following parameters become effective:

Gen Warm Time:

Generator warm-up time. After the inverter sends the start signal, it waits for this duration before accepting generator input.

Start SOC / Stop SOC:

Battery SOC thresholds for starting and stopping the generator automatically.

Gen Rated Power:

Maximum power output of the generator.

Max Run Time:

Maximum continuous run time for the generator. Applies when the inverter is automatically controlling the generator.

Cooling Time:

Generator cooldown period after stopping. Applies to inverter-controlled generator operation.

Gen Force:

Force Start Generator function. Should be enabled during the first-time connection of a generator to ensure recognition and activation.

Smart Load Configuration

This configuration page becomes effective only when Gen Port Function is set to smart load.

Smart Load 2/3

| | |
|--------------------|------------------------------------|
| Stop Output SOC | <input type="text" value="0 %"/> |
| Stop Output Volt | <input type="text" value="0 V"/> |
| Control Start Time | <input type="text" value="00:00"/> |
| Control End Time | <input type="text" value="00:00"/> |

Smart load: The port is used as a dedicated load output, with user-defined working conditions for smart load control.

Stop Output SOC:
When the battery SOC drops to this threshold, the smart load output will automatically disconnect.

Stop Output Volt:
If voltage-based control is selected, the smart load output will disconnect when the battery voltage reaches this value.

Control Start Time:
Start of the time window during which the SOC or voltage control conditions are valid.

Control End Time:
End of the time window during which the SOC or voltage control conditions are valid.

Note:
Outside the defined time window, the smart load output is not restricted by SOC or voltage conditions, and will follow the same discharge behavior as the EPS output.

AC Coupling Function

AC Coupling 3/3

| | |
|----------------|----------------------------------|
| Start SOC/V | <input type="text" value="0 %"/> |
| Stop SOC/V | <input type="text" value="0 V"/> |
| Backlash SOC/V | <input type="text" value="0 %"/> |

The AC Coupling function allows the PV inverter connected to the generator port. When conditions are met, the power from the PV inverter can flow into the unit.

Start SOC/V: (used for lithium batteries)
The battery SOC or voltage threshold to activate AC Coupling.

Stop SOC/V: (used for non-lithium batteries)
The battery SOC or voltage threshold to deactivate AC Coupling.

Hysteresis SOC/V: The hysteresis value for the AC Coupling Start/Stop SOC or voltage thresholds.

Generator Details Page

Generator/AC Couple

| | |
|-------------|-------------|
| L1-V: 0.0 V | L2-V: 0.0 V |
| L1-I: 0.0 A | L2-I: 0.0 A |

Today: 0.0 kWh Total: 0.0 kWh

Total Power: 0.0 kW

(Subject to variation depending on the project configuration)

L1 / L2:
Displays the voltage, current, and power of each phase.

Additional Information:

Today's Generated Energy

Total Historical Generation

Total Generator Power Output

9.10 Advanced Settings Menu

This page allows configuration of parallel settings, Wi-Fi baud rate, and EMS communication parameters.

Advanced Function

| | |
|---------------|----------|
| Parallel Type | Single |
| Parallel Num | 1 |
| Parallel Addr | 1 |
| WiFi Baud | 19200 |
| EMS Port | AFCL_485 |
| EMS Baud | 19200 |

2. WiFi Baud:

Baud rate for communication between inverter and data logger.

EMS Port:

Designates the spare RS485 port on the inverter for EMS (Energy Management System) communication. Default setting: AFCL_485 (can be changed based on actual use).

EMS Baud:

Sets the communication baud rate for the EMS Port. Default value: 19200.

1. Parallel Settings

Parallel Type:

Sets the parallel operation mode of the system.

Parallel Num:

Specifies the total number of inverters in the system (Master + Slaves).

Parallel Addr:

Sets the inverter address in the system.

The master inverter is always set to address 1.

Slave inverters follow in sequential order (2, 3, ...).

3. Parallel Configuration Screens – Example of 3-Inverter System

The following screenshots demonstrate how to configure a parallel system with one master inverter and two slave inverters. All settings must be consistent across devices, except for Parallel Addr, which should be unique per unit.

(1) Master Inverter Configuration

Advanced Function

| | |
|---------------|----------|
| Parallel Type | Master |
| Parallel Num | 3 |
| Parallel Addr | 1 |
| WiFi Baud | 19200 |
| EMS Port | AFCL_485 |
| EMS Baud | 19200 |

Parallel Type: Master

Parallel Num: 3 (total number of inverters)

Parallel Addr: 1

WiFi Baud: 19200

EMS Port: AFCL_485

EMS Baud: 19200

This inverter is designated as the master unit, responsible for synchronization and control across the entire system.

(2) Slave Inverter 1 Configuration

Advanced Function

| | |
|---------------|----------|
| Parallel Type | Slave |
| Parallel Num | 3 |
| Parallel Addr | 2 |
| WiFi Baud | 19200 |
| EMS Port | AFCL_485 |
| EMS Baud | 19200 |

Parallel Type: Slave

Parallel Num: 3

Parallel Addr: 2

WiFi Baud: 19200

EMS Port: AFCL_485

EMS Baud: 19200

This inverter operates as Slave 1, assigned address 2.

(3) Slave Inverter 2 Configuration

Advanced Function

| | |
|---------------|----------|
| Parallel Type | Slave |
| Parallel Num | 3 |
| Parallel Addr | 3 |
| WiFi Baud | 19200 |
| EMS Port | AFCL_485 |
| EMS Baud | 19200 |

Parallel Type: Slave

Parallel Num: 3

Parallel Addr: 3

WiFi Baud: 19200

EMS Port: AFCL_485

EMS Baud: 19200

This inverter operates as Slave 2, assigned address 3.

-Important Notes:

1. All inverters must have the same WiFi Baud rate and EMS Baud rate.
2. Ensure proper wiring and grounding between all units.
3. Make sure firmware versions are consistent across all inverters.
4. Communication cables (e.g. RS485 or CAN) must be securely connected.

9.11 Record Menu

Records

Current Faults

History Faults

Operate Logs

History Fault

| Occurred | Alarms Code |
|-----------------|------------------------|
| '11/15 05:38:58 | F67 arm-dcdc comm lost |
| '11/15 05:38:58 | F66 arm-inv comm lost |
| 11/10 17:50:28 | F67 arm-dcdc comm lost |
| 11/10 17:50:28 | F66 arm-inv comm lost |
| 1/10 13:11:50 0 | F68 wifi comm lost |
| 0 13:10:50 23: | F67 arm-dcdc comm lost |
| | 1/184 |

Current Fault

| Occurred | Alarms Code |
|-------------------|------------------------|
| 23/11/10 12:03:26 | F66-arm-inv comm lost |
| 23/11/10 12:03:26 | F67-arm-dcdc comm lost |
| 23/11/10 12:04:16 | F68-wifi comm lost |

1/1

Operate Logs

| Occurred | Description |
|-------------------|---------------|
| 23/11/01 14:19:54 | INV power off |
| 23/11/01 14:19:53 | System start |
| 23/11/01 14:19:26 | INV power off |
| 23/11/01 14:19:25 | System start |
| 23/11/01 14:18:55 | INV power off |
| 23/11/01 14:18:54 | System start |
| | 1/72 |

Fault and Operation Logs

Current Fault:

Displays the inverter's active faults and alarms.

It includes the timestamp, fault code, and fault description of the current issue.

History Fault:

Shows the inverter's fault and alarm history.

It records the start time, recovery time, and details of each fault event.

Operate Logs:

Contains logs of user operations such as changing inverter modes, powering the system on/off, or adjusting system settings.

These logs are useful for tracking system changes and user actions.

9.12 Device Info Setup Menu

Device Info

Device type:
Rated Power:
SN:
Model:
ARM: L1.0S
INV:
DCDC:
Run Time: 00 : 00 : 01 : 56

This page displays basic information about the inverter, including:

Device Type:The category or class of the inverter.

Model Number:The specific model identifier.

Serial Number:The unique identifier assigned to each unit.

Software Version:The currently installed firmware/software version.(ARM,INV,DCDC)

Run Time:Total runtime of the inverter since initial operation.

This page is useful for system diagnostics, firmware tracking, and technical support.

9.13 Factory Setting Menu

Reserved: This function is reserved. It is not recommended. Please inform the manufacturer/installer before setting up

Factory Setting 1/3

| | | | |
|---------------|---------------------------------|----------------|---------------------------------|
| DRM | <input type="text" value="No"/> | Preventive PID | <input type="text" value="No"/> |
| Factory Reset | <input type="text" value="No"/> | Anti-Islanding | <input type="text" value="No"/> |
| AFCI | <input type="text" value="No"/> | BatTempCompen | <input type="text" value="No"/> |
| Bat Warn | <input type="text" value="No"/> | Bat Wake-up | <input type="text" value="No"/> |
| GRID Warn | <input type="text" value="No"/> | ISO | <input type="text" value="No"/> |
| Ext-Control | <input type="text" value="No"/> | Leakage Curr | <input type="text" value="No"/> |

Factory Setting 2/3

| | | | |
|------------------|---------------------------------|----------------|--------------------------------------|
| Device Reset | <input type="text" value="No"/> | MPPT Ctrl Mode | <input type="text" value="CVT"/> |
| Record Clear | <input type="text" value="No"/> | MPPT Para Mode | <input type="text" value="Indepec"/> |
| AFCI Alarm Clear | <input type="text" value="No"/> | MPPT Num | <input type="text" value="3"/> |
| Relay self-test | <input type="text" value="No"/> | MPPT Power | <input type="text" value="0 kW"/> |
| Device lock | <input type="text" value="No"/> | MPPT Disturbed | <input type="text" value="0"/> |
| Exec quick | <input type="text" value="No"/> | CVT Volt | <input type="text" value="0 V"/> |

Factory Setting 3/3

| | | |
|-----------------|---------------------------------|-------------------------------------|
| Schedule Enable | <input type="text" value="No"/> | |
| Schedule Power | <input type="text" value="Ch"/> | <input type="text" value="0.0 kW"/> |

10. Trouble Shooting

This section contains information and procedures for solving possible problems with the AP-HL8-15K-P2 series inverters, and provides you with trouble shooting tips to identify and solve most problems that could occur with the SSE-HL8-15K-P2SA-S series inverters.

This section will help you narrow down the source of any problems you may encounter. Please read the following trouble' shooting steps.

Check the warning or fault messages on the System Control Panel or Fault codes on the inverter information panel. If a message is displayed, record it before doing anything further. Attempt the solution indicated in below table.

| Error code | Description | Solutions |
|------------|--------------------------|--|
| F01 | inv over volt | The inverter is faulty. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved. Or seek help from us, if not go back to normal state. |
| F02 | inv under volt | |
| F03 | short circuit | |
| F04 | inv over curr | |
| F05 | over load | If the load power is too high or the device is downgraded, please reduce the power consumption. Or seek our help if you are unable to return to a normal state. |
| F07 | inv bus over volt | The inverter is faulty. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved. Or seek help from us, if not go back to normal state. |
| F08 | inv bus under volt | |
| F09 | bus unbalance | |
| F10 | leakage self-test fail | |
| F11 | leakage over limit | |
| F12 | relay self-test fail | |
| F13 | inv locked | The inverter is faulty. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved. Or seek help from us, if not go back to normal state. |
| F14 | busbar buffer fail | |
| F15 | inv over temp | |
| F17 | parallel total count err | |
| F18 | parallel comm fail | |
| F19 | parallel SW mismatch | |
| F20 | parallel HW mismatch | |
| F21 | parallel model mismatch | |
| F22 | parallel para sync | |
| F23 | master conflict | |
| F24 | slave id conflict | |
| F25 | parallel signal err | |
| F26 | master no salve | |
| F33 | inv flash fault | The internal communication and storage are abnormal. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved. Or seek help from us, if not go back to normal state. |
| F34 | inv-dc comm fault | |
| F35 | inv phase-locked | |
| F36 | inner para match fail | |

| | | |
|-----|----------------------------|---|
| F38 | inv master fault | The internal communication and storage are abnormal. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved.Or seek help from us, if not go back to normal state. |
| F39 | inv parallel comm fail | |
| F40 | inv parallel signal err | |
| F41 | inv curr DC component high | |
| F42 | inv parallel overload | |
| F43 | inv load curr unbalance | |
| F44 | inv parallel system fault | |
| F49 | dc bus over volt | |
| F50 | dc bus under volt | |
| F51 | midbus over volt | |
| F52 | midbus under volt | |
| F53 | dc bat disch OC | |
| F54 | dc bat ch OC | |
| F55 | LLC HW over curr | |
| F56 | dc bat over volt | |
| F57 | dc bat under volt | |
| F60 | bat reverse connect | Check whether the positive and negative terminals of the battery power line are connected in reverse mode. |
| F63 | dc over temp | Ensure that the inverter is installed in a place without direct sunlight. Make sure the inverter is installed in a cool/well-ventilated area. Ensure that the inverter is installed vertically and the ambient temperature is lower than the upper limit of the inverter temperature. |
| F64 | Fan fault | Please first power off the inverter,check whether the software version is the latest one with us.If not,please upgrade firmware. |
| F65 | meter comm lost | Check whether the meter communication line is normal. |
| F66 | arm-inv comm lost | The internal communication and storage are abnormal. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved.Or seek help from us, if not go back to normal state. |
| F67 | arm-dcdc comm lost | |
| F68 | wifi comm lost | Please check wifi LED light status.Or seek help from us, if not go back to normal state. |
| F69 | bms1-can comm lost | Make sure the battery you use is compatible with the inverter. Check whether the communication cables or ports between the battery and the inverter are properly connected |
| F70 | dsp para match err | The internal communication and storage are abnormal. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved.Or seek help from us, if not go back to normal state. |
| F71 | EPO | Seek help from us, if not go back to normal state. |

| | | |
|---------------------|--------------------------------|---|
| F72 | ambient temp high | Ensure that the inverter is installed in a place without direct sunlight. Make sure the inverter is installed in a cool/well-ventilated area. Ensure that the inverter is installed vertically and the ambient temperature is lower than the upper limit of the inverter temperature. |
| F73 | bms1-485 comm lost | Make sure the battery you use is compatible with the inverter. Check whether the communication cables or ports between the battery and the inverter are properly connected |
| F74 | arm flash error | The internal communication and storage are abnormal. Turn off the PV, grid, and battery, and wait 5 minutes before turning on the inverter. Check whether the problem is resolved.Or seek help from us, if not go back to normal state. |
| F75 | NTC disconnect | |
| F76 | dsp para set fail | |
| F81 | dc-inv comm lost | |
| F82 | dc flash fault | |
| F83 | dc fault locked | |
| F86 | PV1 over volt | |
| F87 | PV2 over volt | |
| F88 | PV1 over curr | |
| F89 | PV2 over curr | |
| F90 | PV1 reverse connect | Check whether the PV cables are correctly connected. |
| F91 | PV2 reverse connect | |
| F93 | PV3 overvoltage protection | |
| F94 | PV3 overcurrent protection | |
| F95 | PV3 reverse connect protection | |
| F96 | DC insulation fault | Seek help from us, if not go back to normal state. |
| Warning code | Description | Solutions |
| W01 | Overload alarm | If the load power is too high or the device is downgraded, please reduce the power consumption. Or seek our help if you are unable to return to a normal state. |
| W02 | INV overtemperature alarm | Ensure that the inverter is installed in a place without direct sunlight. Make sure the inverter is installed in a cool/well-ventilated area. Ensure that the inverter is installed vertically and the ambient temperature is lower than the upper limit of the inverter temperature. |
| W03 | Grid over frequency alarm | If the power grid is abnormal, the inverter automatically returns to the normal working state after the power grid recovers. |
| W04 | Grid under frequency alarm | |
| W05 | Grid overvoltage alarm | |

| | | |
|-----|--------------------------------------|--|
| W06 | Grid undervoltage alarm | Or seek help from us, if not go back to normal state. *GARDA(Power grid amplitude quick check alarm) |
| W07 | Gen freq abnormal alarm | Measure the generator output voltage using a multimeter. Ensure the generator is operating within its rated voltage (typically 220/230V or 380/400V depending on the system). Check for loose or faulty wiring between the generator and inverter input. |
| W08 | DC BAT overvoltage alarm | If the internal fault of the lithium battery occurs, Turn off the PV, grid, and battery, and wait 5 minutes to turn on the inverter and lithium battery. Check whether the problem is resolved. Or seek help from us, if not go back to normal state. |
| W09 | DC BAT undervoltage alarm | |
| W10 | BAT none-connected | |
| W11 | DC over-temp alarm | |
| W12 | grid phase rapid inspection | If the power grid is abnormal, the inverter automatically returns to the normal working state after the power grid recovers. Or seek help from us, if not go back to normal state. |
| W13 | Grid fast inspection alarm | |
| W14 | BAT Ch&Disch prohibited alarm | If the internal fault of the lithium battery occurs, Turn off the PV, grid, and battery, and wait 5 minutes to turn on the inverter and lithium battery. Check whether the problem is resolved. Or seek help from us, if not go back to normal state. |
| W19 | Grid phase deficiency alarm | If the power grid is abnormal, the inverter automatically returns to the normal working state after the power grid recovers. Or seek help from us, if not go back to normal state. *GARDA(Power grid amplitude quick check alarm) |
| W20 | Grid long time OV alarm | |
| W21 | Grid phase abnormal alarm | |
| W22 | Grid amplitude fast inspection alarm | |
| W23 | Grid DC component fast detection | If the internal fault of the lithium battery occurs, Turn off the PV, grid, and battery, and wait 5 minutes to turn on the inverter and lithium battery. Check whether the problem is resolved. Or seek help from us, if not go back to normal state. |
| W24 | Grid phase fast inspection alarm | Check the generator frequency output with a frequency meter. |

| | | |
|-----|------------------------|--|
| | | Make sure the generator engine speed is stable (RPM too high or low will affect frequency). Adjust the engine governor if needed. Avoid overloading the generator, which may cause frequency fluctuations. |
| W25 | PV1 undervoltage alarm | If the internal fault of the lithium battery occurs, Turn off the PV, grid, and battery, and wait 5 minutes to turn on the inverter and lithium battery. Check whether the problem is resolved. Or seek help from us, if not go back to normal state. |
| W26 | PV2 undervoltage alarm | |
| W27 | PV3 undervoltage alarm | |

 NOTICE

If your inverters information panel is not displaying a Fault light, check the following list to make sure that the present state of the installation allows proper operation of the unit.

Is the inverter located in a clean, dry, and adequately ventilated place?

Have the DC input breakers been opened?

Are the cables adequately sized and short enough?

Are the input and output connections and wiring in good condition?

Are the configurations settings correct for your particular installation?

Are the display panel and the communications cable properly connected and undamaged?

Contact Customer Service for further assistance. Please be prepared to describe details of your system installation and provide the model and serial number of the unit.

11. Maintenance

11.1 Power ON the Inverter for first time



Important: Please follow these steps to turn on the inverter.

Step 1: make the PV SWITCH to the ON position.

Step 2: Turn on the battery. Turn on the DC switch between battery and inverter.

Step 3: Turn on the AC circuit breaker between the inverter port and the power grid.

Step 4: Open the AC circuit breaker between the inverter load port and the emergency load.

Step 5: Manually send the startup command through the APP (for safety, it can be set to automatic startup after the initial power-on).

Step 6: The inverter should start running now.

11.2 Power Off the Inverter



- Power off the inverter before operations and maintenance. Otherwise, the inverter may shocks or occur.
- Delayed discharge. Wait until the components are discharged after power off.

Step 1: Turn off the AC breaker on the ON-GRID side of the inverter.

Step 2: Turn off the AC breaker on the BACK-UP side of the inverter.

Step 3: Turn off the battery breaker between the inverter and the battery.

Step 4: Turn off the PV switch of the inverter.

11.3 Removing the Inverter



- Make sure that the inverter is powered off.
- Wear proper PPE before any operations.

Step 1: Disconnect all the cables, including DC cables, AC cables, communication cables, the communication module, and PE cables.

Step 2: Remove the inverter from the mounting plate.

Step 3: Remove the mounting plate.

Step 4: Store the inverter properly. If the inverter needs to be used later, ensure that the storage conditions meet the requirements.

11.4 Disposing of the Inverter

If the inverter cannot work anymore, dispose of it according to the local disposal requirements, The inverter cannot be disposed of together with household waste.



- Make sure that the inverter is powered off.
- Wear proper PPE before any operations.

12 Appendix

12.1 Routine Maintenance

| Maintaining Item | Maintaining Method | Maintaining Period |
|-----------------------|---|--------------------|
| System Clean | Check the heat sink, air intake, and air outlet for foreign matter or dust. | Once 6-12 months |
| PV Switch | Turn the DC switch on and off ten consecutive times to make sure that it is working properly. | Once a year |
| Electrical Connection | Check whether the cables are securely connected. Check whether the cables are broken or whether there is any exposed copper core. | Once 6-12 months |
| Sealing | Check whether all the terminals and ports are properly sealed. Reseal the cable hole if it is not sealed or too big. | Once a year |

12.2 Limited Warranty

The warranty does not apply to any Product or Product part that has been modified or damaged by the following:

- Installation or Removal (examples: wrong voltage batteries, connecting batteries backward, damage due to water/rain to electronics, preventable damage to solar wires.)
- Alteration or Disassembly.
- Normal Wear and Tear.
- Accident or Abuse.
- Unauthorized Firmware updates/software updates or alterations to the software code.
- Corrosion.
- Repair or service provided by an unauthorized repair facility.
- Operation or installation contrary to manufacturer product instructions.
- Fire, Floods, or Acts of Nature.
- Shipping or Transportation.
- Incidental or consequential damage caused by other components of the power system.
- Any product whose serial number has been altered, defaced, or removed.



SOSEN expressly disclaims any responsibility for performance issues arising from improper installation. Installers and users are solely responsible for following proper installation procedures outlined in provided documentation. We disclaims any liability for changes in the installation that might result in electrical malfunctions or any other issues related to the our product.