

# RK100-02 Wind Speed Sensor

## User Manual



| Revision Time | Reviser | Current Version | Remarks |
|---------------|---------|-----------------|---------|
| 20250410      | SUN     | V5.0            |         |



## User Notice

Please read this manual carefully before use to ensure safe and optimal operation. Retain this manual for future reference.

### Pre-Use Instructions

- Carefully review this manual and follow all operational and safety guidelines to prevent malfunctions and hazards.

### Unpacking Inspection

- Upon receipt, carefully inspect the sensor device and accessories for any shipping damage.
- If damage is detected:
- Immediately notify the manufacturer and distributor.
- Retain all packaging materials for return or replacement processing.

### Parts List

| Item              | Quantity | Remarks                         |
|-------------------|----------|---------------------------------|
| Wind speed sensor | 1        |                                 |
| Cable             | 1        | The length depends on the order |

## 1. Product Introduction

The RK100-02 Wind Speed Sensor is a high-precision 3-cup anemometer designed for accurate wind speed measurement. The cups are made of carbon fiber, ensuring high strength and a low startup threshold. The sensor's signal processing unit is integrated into the housing for enhanced durability and reliability. It can be widely used in meteorology, marine applications, environmental monitoring, airports, harbors, laboratories, industrial settings and agricultural areas.

## 2. Product Features

- Low startup threshold
- Overall carbon fiber material
- Strong corrosion resistant ability
- Various optional output signals
- Light structure
- Easy installation

### 3. Specifications

| Output                | Pulses                                     | 4-20mA         | RS485    | 0-2V/0-5V/0-10V |
|-----------------------|--------------------------------------------|----------------|----------|-----------------|
| Supply Voltage        | 5-24VDC                                    | 12-24VDC       | 12-24VDC | 12-24VDC        |
| Load Capacity         | >2kΩ                                       | <500Ω(typ250Ω) |          | >2kΩ            |
| Range                 | 0-45m/s                                    | 0-45m/s        | 0-45m/s  | 0-45m/s         |
| Accuracy              | $\pm (0.3+0.03V) \text{ m/s}$              |                |          |                 |
| Starting Threshold    | <0.5m/s                                    |                |          |                 |
| Limit Wind Speed      | 50m/s                                      |                |          |                 |
| Ingress Protection    | IP65                                       |                |          |                 |
| Operating Temperature | -40℃-+50℃                                  |                |          |                 |
| Cable Grade           | Nominal voltage:300V,Temperature grade:80℃ |                |          |                 |
| Weight(Unpacked)      | 170g                                       |                |          |                 |
| Dimension             | Cup rotor:ø179mm, Height: 160mm            |                |          |                 |
| Main Material         | Carbon fiber                               |                |          |                 |
| Storage Condition     | 10℃-50℃@20%-90%RH                          |                |          |                 |

### 4. Electrical Connections

| Connector(Cable) | Pulses/Voltage/Current | RS485  |
|------------------|------------------------|--------|
| Red              | V+                     | V+     |
| Black/Green      | V-                     | V-     |
| Yellow           | Signal+                | RS485A |
| Blue             |                        | RS485B |

## 5. Output Types & Formulas

| Pulses Type  | $F=0, V=0; F \neq 0, V=0.1+0.0875 \times F$ |                                             |
|--------------|---------------------------------------------|---------------------------------------------|
| Current Type | 4-20mA                                      | $V=(I-4)/(20-4) \times 45$ (Range: 0-45m/s) |
| Voltage Type | 0-5V                                        | $V=U/5 \times 45$ (Range: 0-45m/s)          |
|              | 0-2.5V                                      | $V=U/2.5 \times 45$ (Range: 0-45m/s)        |

F: Output frequency in Hz;

V: Wind speed data in m/s;

U: Transmitter output voltage in V;

I: Transmitter output current in mA.

## 6. Product Dimensions

Unit:mm

ø15mm (recommended reserving ø 25mm for wiring)




Figure 6.1  
Top View




Figure 6.2  
Side View

## 7. Communication Protocol (MODBUS-RTU)

| Parameter     | Value                  |
|---------------|------------------------|
| Data Bits     | 8 bits                 |
| Check Bit     | None                   |
| Stop Bit      | 1 bit                  |
| Baud Rate     | 9600 bps               |
| Slave Address | 0x01 (Factory Default) |

### 7.1 Read Real-Time Data

Client sends:

01 03 00 00 00 01 840A

Return:

01 03 02 00 B4 B833

#### 7.1.1 Description of Return Data Format

| No. | Conception      | Byte Number | Description     | Remarks       |
|-----|-----------------|-------------|-----------------|---------------|
| 1   | Address block   | 1           | Address(0x01)   | 0x01          |
| 2   | Function code   | 1           | Only read(0x03) | 0x03          |
| 3   | Number of bytes | 1           | 0X02            | 2bytes        |
| 4   | Data block      | 2           | Wind speed data | 0x00B4(18m/s) |
| 5   | Check block     | 2           |                 | 0xB8 0x33     |

### 7.2 Modify Slave Address

Client sends:(Change slave address from 00H to 01H.)

| Slave id | Function code | New Address | CRC_L | CRC_H |
|----------|---------------|-------------|-------|-------|
| 0x00     | 0x10          | 0x01        | 0xBD  | 0xC0  |

Response:

| Slave id | Function code | CRC_L | CRC_H |
|----------|---------------|-------|-------|
| 0x00     | 0x10          | 0x00  | 0x7C  |

### 7.3 Read Sensor Address

Client sends:

| Slave id | Function code | CRC_L | CRC_H |
|----------|---------------|-------|-------|
| 0x00     | 0x20          | 0x00  | 0x68  |

Return:

| Slave id | Function code | Current Address | CRC_L | CRC_H |
|----------|---------------|-----------------|-------|-------|
| 0x00     | 0x20          | 0x01            | 0xA9  | 0xC0  |

## 8. Installation Guidelines

- Ensure no obstacles (e.g., buildings, trees, billboards) exist around the anemometer cups to prevent local airflow interference.
- Avoid areas with strong electromagnetic interference (e.g., high-voltage power lines, motors) and corrosive environments.

### 8.1 Installation Method

Flange mounted, fix four screws on the bracket and keep the product horizontal.




Figure 8.1.1

Wind Speed Sensor Mounted on a Support Structure




Figure 8.1.2

Mounting Plate Dimensions and Hole Specifications(Unit:mm)

## 9. Precautions

### Powered Wiring Prohibition

- Do not connect wires while powered. Only energize the sensor after confirming correct wiring.

### Component Modification Restriction

- Do not alter factory-soldered components or pre-connected wires.

### Precision Handling Requirement

The sensor is a precision device. Avoid:

- Unauthorized disassembly
- Do not touch internal components to prevent product damage

**Note:** Unauthorized modifications void the warranty.

## 10. Troubleshooting

### Incorrect Output Signals (Analog/RS232/RS485):

- Verify wiring correctness and secure connections.
- Check if the serial port is occupied or malfunctioning.
- Confirm serial port settings (baud rate, data/stop bits) match device requirements.

### Persistent Issues:

- Contact the manufacturer if the above steps fail to resolve the problem.

## 11. Product Maintenance

### Maintenance and Safety

- Regularly clean and inspect the sensor to maintain performance.
- Do not expose the sensor to extreme temperatures, moisture, or corrosive substances unless explicitly specified.
- Unauthorized disassembly, modification, or repairs may void the warranty and lead to malfunctions.

### Troubleshooting Protocol

- In case of malfunction, refer to the troubleshooting section of this manual.
- Do not attempt unauthorized disassembly or repairs.
- Contact the manufacturer's after-sales department directly for technical support.



## 12. Warranty Terms

This product comes with a one-year warranty, starting from the date of delivery. Within twelve months, the Company shall be responsible for free repair or replacement of any failure caused by sensor quality issues (non-human damage). Fees will be charged for repairs or replacements after the warranty period expires.

 Complies with applicable CE directives.

Manual subject to change without notice.

Copyright © 2015 Hunan Rika Electronic Tech Co.,Ltd