

指示卡



1. 安装原厂或STARTRC保护圈；



2. 将浮力防撞圈，从后向前安装在无人机两侧；



3. 如图所示，无人机凸起处需卡在浮力圈内；



4. 安装后，将浮力圈向内挤压，使其卡扣最终对位；

注意事项

- 1. 使用浮力防撞圈必须先安装原厂桨叶防撞圈或STARTRC防撞圈，否则有松脱风险；
- 2. 安装浮力防撞圈后需仔细检查卡位是否安装到位；
- 3. 不按操作说明使用造成的一切后果本司概不负责。

Instruction Card



1. Install the original or STARTRC propeller guard bumper;



2. Install the floating propeller guard bumper on both sides of the drone, moving from back to front;



3. As shown in the image, the drone's protruding parts need to be clipped inside the floating propeller guard bumper;



4. After installation, gently squeeze the floating propeller guard bumper inward to align the clips properly.

Notes

- 1. The floating propeller guard bumper must be used only after installing the original or STARTRC propeller guard bumper, otherwise there is a risk of detachment;
- 2. After installing the floating propeller guard bumper, carefully check that all clips are securely in place;
- 3. Our company is not responsible for any consequences resulting from improper use that does not follow the operating instructions.