

BOGIST

M1 Elite



BOGIST


CATALOGUE

1.APP download & Functions.....	02
2.Scooter display function.....	03
3.The Device& Accessory.....	04
4.Vehicle display.....	04
5.Assembling the device	05
6.Charge the scooter	06
7.Driving instruction.....	06-07
8.Safety Instructions.....	08-11
9.Safety Recommendations.....	12-13
10.Fold and Transportation.....	13
11.Daily Maintenance and Storage.....	14
12.Maintenance of Electric Scooter battery...	14-15
13.Adjusting a brake disc.....	16
14.Adjusting a handle bars.....	16
15.Model Specifications.....	17
16.Warranty.....	18-19


1.APP download & Functions

Android : Scan the QR code-select Android-click the three dots in the upper right corner to select browser download-install-open Bluetooth connection BOGIST.

ios: Scan the QR code-select ios-click the three dots in the upper right corner to select browser download-install-open Bluetooth connection BOGIST.



2.Scooter display function




3. The Device& Accessory



Accessory



4.Vehicle display




4

5. Assembling the device


1).fix the steering rod and




Using hex wrench in the packing box to tighten the screws on handle bar



2).Set handle bars vertical;




4. Testing the power switch after finish assembling




5

6. Charge the scooter



7. Driving instruction


Please wear helmet and knee pads when practice



1. Power on and check the battery led light




2. Stand on pedal with one leg, hit the ground with the other leg



3. Step on the other leg when the scooter is moving, then press the accelerate button (only accelerate when the scooter speed is beyond 5km/h)

4. loose the accelerate button when slow down. Energy recovery systems will open itself to slow down. Press the left disc brake tightly if want to brake urgently.

5. lean your body left slightly to turn left, lean your body right slightly to turn right. And turn the handlebar slowly



8. Safety Instructions

It is not recommended driving on the rain

安全隐患注意避免




It is recommend to slightly bend knees to better adjust to a rough road. If you are travelling on a rough road, stick to low speed (5-10km/h)



Entering into any room, elevator, etc.


Be careful not be injured by a door frame.




Please not add speed when descending a hill




While walking with a scooter, do not press a speed knob



When driving it is recommended to go around various obstacles on a road



Please do not hang backpacks and other heavy objects on handle bars




When driving is forbidden to place one foot on the running board



Preventing dangerous driving


It is forbidden to leave a scooter on a scooter wheel at high roadway for motor vehicles or ride in at a high speed




It is forbidden to drive through puddles, to which exceeds depth of 2cm.



It is forbidden to sharply turn a a residential area with a large flow of passers-by



Never rider a scooter more than or one person, hold a child in your arms.



Do not tread the back of the fender Do not touch the disc brake



Do not driving leaving your hands Do not riding electric scooter up, down steps or jump over obstacles

9. Safety Recommendations

1) Electric scooter - it is only a device for entertainment, not vehicle. But once you driving to public area, the electric scooter brings certain risks for your safety. For the sake of your safety and others safety, you must strictly follow the instructions, outlined in this driving manual.

2) You should understand that if you ride a scooter in a public place, you must comply with all recommendations for safety. Also do not forget that there is a possibility of collision, due to violation of pedestrians or vehicles traffic rules, there is also a risk of injury, due to improper operation of the unit. As in other types of vehicles, the higher a speed of electric scooter, the greater a braking distance. On some smooth road emergency braking may cause skidding of scooter, loss of balance and even fall. Therefore, during moving of scooter you need to be vigilant, to adhere to an appropriate speed, keep a safe distance from pedestrians and / or with other vehicles. Riding on unfamiliar terrain, keep vigilance and appropriate speed.

3) While riding scooter, respect rights of pedestrians. Do not scare them, especially children. Reduce speed, passing by them. If you are moving in the same direction with pedestrians, try to stick to the left side as much as possible (for right-hand traffic countries). If you are moving in the opposite direction, stick to the right and slow down.


4) Please strictly following your country road rules to driving, and also strictly abide by rules, set out in the instructions and safety recommendations. Violation of the above rules may result financial expenses, personal injury, occurrence of traffic accidents, legal disputes, conflict and other unpleasant situations. Our company does not bear any direct or joint and several liability.

5) To avoid personal injury, do not loan electric scooter to others whom do not know how to drive. Please spend a training before you transfer your scooter to friends, as well as teach he(her) must be wear the proper safety gear.

6) Please do inspect scooter carefully before each use. If you find shattered parts, battery life has decreased obviously, tires leak air or there are signs of excessive wear, uncharacteristic sounds when turning or other abnormal symptoms, please discontinue use of the scooter immediately, don't drive it reluctantly.

10. Fold and Transportation


Fold



Make sure scooter be off, hold the front pole, loosen a lock lever and lower a steering rack. Adding a steering rack in a horizontal position and secure it by inserting a hook through a special ring, which is located on the rear wheel mudguard. To Assemble the scooter, disconnect a steering rack lock from a hook of a mudguard, and then lift it into a vertical position and lock a lever.

Transportation

You can transfer folded scooter with one hand
Vous pouvez déplacer le trottinette pliage avec seule main



11. Daily Maintenance and Storage

If you find any stains on electric scooter housing, use a soft,damp cloth to wipe the vehicle;You can use toothpaste and a toothbrush to clean the scooter from stains, and then wipe it clean with a damp cloth. If you find scratched on parts , made of plastic, use sandpaper or other grinding materials for their polishing .

Warning : Do not use alcohol, petrol,kerosene or other corrosive solutions , volatile chemical solvents to clean the vehicle. Otherwise,it will cause serious damage to the scooter body and can disrupt a structure of internal elements. Do not wash electric scooter under a strong pressure of the water, make sure the scooter in the off status. In addition, after charging of the vehicle, it is necessary to insert a plug back to a charging connector,otherwise you may get an electric shock , or may have serious water damage cause from water falling into this hole ,may have serious water damage.

If you do not use the scooter ,store it in a dry ,cool place and do not leave the unit for a long time on the street.Leaving the device under the sun/in extremely high temperature/over-low temperature can cause rapid aging of an outer body and wheels of Electric Scooter or reduce battery life.

12.Maintenance of Electric Scooter battery

- 1)Do not use batteries from other brands in order to avoid a dangerous situation;
- 2)Do not open or disassemble the battery to prevent electric shock.Avoid contact with metal objects to prevent an occurrence of a short circuit. Otherwise,the battery may have malfunction or can injure the user;
- 3)It is recommended to use an AC adapter,that comes in original configuration of

the device,to prevent an occurrence of an accident or fire of the vehicle;
4) Improper disposal of used batteries and accumulators is the cause of severe environmental pollution.Please,dispose of batteries in accordance with local laws.Please do not dispose of batteries together with food waste.Protecting the environment together!

5)After each use of the device,charge the battery to prolong its service life.

Do not store the scooter battery in rooms with temperatures,that exceed 50°C or -20°C(for example,do not leave the battery of Electric Scooter and other batteries in cars in summer time on the hot sun),do not leave the battery near fire.As a result of these actions may deteriorate the battery,overheating and can even cause inflammation.

If within 30 days the scooter is not used,charge the battery and keep the device in a cool,dry place.Every 60 days you need to charge the battery,otherwise there is the likelihood of its failure,which is not subject to warranty services.


Avoid a full discharge of the device,it will to extend battery life.When using the device at normal room temperature,the battery will be able to ride much greater distance and its performance will be better;but if you use the scooter at temperatures below 0°C,vehicle performance and permeability decrease.

At-20°C a traveled distance is less,than the scooter in the normal conditions of half or even less.If a temperature rises,a traveled distance by the vehicle will also increase.You can check remaining distance in the Application.

Note:A fully charge scooter runs about 120-180 days of standby time.The battery has a smart chip,that stores information about its charging-discharging.If you are not charging the battery for a long time,it can cause serious damage,for which it is impossible to charge the device again.This kind of damage is not included in free warranty service.(Caution:Do not disassemble the device by unauthorized people,as there is a risk of electric shock or serious injury as result of a short circuit.


13.Adjusting a brake disc

If a brake is very tight:using M5 hex wrench and scroll counterclockwise screws of brake disc tensioner pulley,slightly shorten a length of a tail brake cable,then tighten a tensioner pulley.If you think that brake is very free,loosen a tension pulley,pull a brake cable to slightly increase a length of its tail.Tighten a tension pulley.



14.Adjusting a handle bars

Staggering of steering rack: using a M5 hex wrench,tighten two screws near the folding mechanism.



15. Model Specifications

M1	Item	Electric Scooter
Dimensions	Unfolded (Length. x Width x Height)	42.5*17*45 inch/108*44*114 cm
	Folded (Length. x Width x Height)	42.5*17*19 inch/108*44*49 cm
weight	Net Weight	26.5lbs/12 kg
User	Load	220 lbs/100 kg
	Recommended Age	18+
	Recommended Height	47.24~78.74 inch/120~200cm
Scooter	Max.Speed	18.6mph/30 km/h
	Max.Range	15.5-22 mile /25-35 km
	Max. Slope (%)	15%
	Operating Temperature	32°F~104°F
	Protection level	IPX4
Battery	Voltage	36 V
	Max.Charging Voltage	42 V
	Capacity	10.4 AH
Motor	Nominal Power	350 W
Charger	Input Voltage	110-240 V
	Output Voltage	42 V
	Output Current	2A
	Charging Time	5-7 h

(1) The height of the body: Distance from the ground to the highest end of the body.

(2) Description of the battery life: It is measured under the condition of full charge, a load of 150 lb, at 77°F, on a flat road without wind, and at a speed of 9.3mph. The real battery life will differ with different factors of the load, humidity, wind speed and operation habits.

(3) The maximum allowable weight shall be kept within 220 lb (driver and objects included) in any case. Consider an extra weight of the clothes or other accessories with us during the trip and the gravity generated by speed, the scooter will not support it if this load limit is exceeded.

17. Warranty

Warranty service is carried out in accordance with the law on 《consumer rights》 and the 《Law on the quality of products.》 The warranty service includes:

Recommendation: use the packaging for safe transport of the device. We recommend keeping the original packaging within 15 days after receipt of goods.

II. Warranty terms

Name	Information on warranty maintainance	Term
Main Unit	hub motor, controller, steering	1 year
Accessories	Battery, power supply,	6 Months

Caution:

Hex wrench,connecting pipe and other consumable component parts have no warranty.

III. Non - warranty regulations

1. Authorized maintenance, misuse, collision, negligence, abuse, intake, accident. Improper use of non-product accessories, or tear up the modified label, anti-counterfeit mark.

2.The warranty period has expired;

3.Damage, caused by force majeure;

4.Failures, which do not correspond to the 《List of faults》 of EcoRider service center;

5.A failure of the device or its components from the 《Fault list》, which arose in connection with the human factor, and which interfere with normal operation.

6.Failures, that have arisen in connection with the human factors (including, but not limited to, excessive wetting device, puncture, drop, scratch and damage an outer casing,which have arisen as a result of normal use of goods)

7.If this product is used for commercial purposes,all warranty conditions are not maintained.

IV. List of faults

Name of fault	
Electric Scooter	Incorrect motor operation
	Problems with operation of the controller
	Problems with charger
	Problems with battery
	In use,the occurrence of cracks,deformation, etc